



Philips DiamondVision
Halogen

Type of lamp: H7

Pack of: 1
12 V, 55 W
Style



12972DVB1

Drive with style

Up to 5000K ultimate white light

Philips DiamondVision halogen headlamp is the ultimate style upgrade for your car with up to 5000K white light. With the specially designed blue coating, DiamondVision makes you stand out from the crowd.

Stylish white light stands out

- Cool elegance for your headlights

High quality and ultra resistant headlamp

- Change both your headlamps simultaneously for more safety
- Philips car lamps are made of high-quality quartz glass[^]
- Wide range of 12V lamps for all functions
- Philips is the choice of major car manufacturers.
- Philips car lamps are highly resistant against humidity[^]
- Philips car lamps are highly UV resistant

PHILIPS

Halogen
Type of lamp: H7 Pack of: 1, 12 V,55 W, Style

Highlights

Change by pairs



Highly recommended to change them by pairs for symmetric light performance

5000K white light for style

Philips DiamondVision Vision headlight lamps provide the perfect choice for drivers who want a crisp white look for their headlights. Thanks to the Philips patented coating technology, DiamondVision provide a truly white light for great visibility and style.

Car manufacturers' choice

For 100 years, Philips has been on the forefront of the automotive lighting industry, introducing technological innovations that have become standards on modern automobiles. Today, one in two cars in Europe and one in three worldwide, is equipped with Philips lighting.

Designed for multiple usage



Which 12V lamp for which function? Philips Automotive offers all car specific functions : high beam, Low beam, front fog, front indicator, side

indicator, rear indicator, stop light, reversing light, rear fog light, license plate lights, rear position/parking light, interior lights

High quality quartz glass



UV-Quartz glass is stronger than hard glass and highly resistant to temperature extremes and vibrations, eliminating the risk of explosion. Philips quartz-glass lamps (filament 2 650° C and glass 800° C) are able to withstand severe thermal shock. With the capability to withhold increased pressure inside the lamp, UV-quartz glass is able to produce more powerful lighting. ^Application varies per bulb type.

Resistance against humidity

Only a burning bulb made of quartz glass (filament 2650°c, glass 800°c) can resist thermal shocks : such as, if a drop of cold water touches the hot bulb, when you drive through water with a broken headlight unit. ^Application varies per bulb type

UV Resistant



Philips special anti-UV coating technology protects the headlights against harmful ultraviolet radiation, making Philips UV-coated quartz glass perfect for all driving conditions and ensures their longevity

12972DVB1

Specifications

Marketing specifications

- Expected benefits: Style
- Product highlight: 5000K

Product description

- Application: Additional high beam, High beam, Low beam
- Base: PX26d
- Designation: H7
- Homologation ECE: NO
- Marking ECE: N/A
- Range: DiamondVision
- Technology: Halogen
- Type: H7

Lifetime

- Life time: B3/Tc = 200/400

Light characteristics

- Color temperature: up to 5000 K
- Lumens: 935 ±15% lm

Electrical characteristics

- Wattage: 55 W
- Voltage: 12 V

Ordering information

- Ordering code: 53293730

Packaging Data

- EAN1: 8727900532937
- EAN3: 8727900532944



Issue date 2023-09-14

Version: 7.0.1

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Application varies per bulb type