



Philips X-tremeVision  
Headlight bulb<br>

Type of lamp: D2R

Pack of: 1  
85 V,35 W



85126XVS1

## Feel safe, drive safe

Up to 50% more vision

Producing up to 50% more vision, this high-power xenon lighting solution provides maximum brightness for maximum visibility to satisfy the needs of the most demanding drivers. Philips Xenon X-tremeVision is the ultimate choice for drivers.

### Xenon quality and ultra resistant car lamp

- Philips is the inventor of Xenon HID technology
- Philips car lamps are highly UV resistant
- Philips car lamps are made of high-quality quartz glass
- Philips car lamps are highly resistant against humidity

### Brighter light for maximum visibility and safety

- Better visibility for safer driving
- Xenon X-treme vision is the ultimate performance solution

### Original Equipment manufacturer

- Philips is the choice of major car manufacturers
- Respecting high quality standards of the ECE homologation
- Award winning car lamp manufacturer

# PHILIPS

Headlight bulb  
Type of lamp: D2R Pack of: 1, 85 V,35 W

85126XVS1

# Highlights

## Car manufacturer choice



For 100 years, Philips has been on the forefront of the automotive lighting industry, introducing technological innovations that have become standard on modern automobiles. Today, one in two cars in Europe and one in three worldwide is equipped with Philips lighting

## ECE homologation

Philips automotive products and services are considered best-in-class in the Original Equipment Manufacturer market and the aftermarket. Manufactured from high quality products and tested to the highest specifications, our products are designed to maximize the safety and comfort of our customers' driving experience. Our entire product range is thoroughly tested, controlled and certified (ISO 9001, ISO 14001 and QSO 9000) to the highest ECE requirements. Put simply, this is quality you can trust.

## Rewarded Car lamps



Our lamps are often rewarded by automotive experts

## Maximum safety and visibility

Xenon X-treme Vision provides you with a better reactivity thanks to an earlier recognition of obstacles and traffic signs. Light is a fundamental part of the driving experience and light is the first and only part of the safety circle that actually helps prevent accidents. Philips promotes active safety protection to prevent accidents by increasing overall visibility and road illumination as a matter of fact the 4800K color temperature increases the visual confort.

## Original Xenon technology



Xenon HID (High Intensity Discharge) lamps offer twice as much light for safer driving in all conditions. As a matter of fact, the intense white light produced by the Xenon HID lamps is comparable to daylight. Studies have demonstrated that xenon automotive lighting helps drivers to concentrate on the road and to distinguish obstacles and road signs much faster than traditional lamps.

## Up to 50% more vision

Xenon X-tremeVision lamps are engineered with Philips Xenon technology for ultimate performance. Producing a longer beam, Xenon X-treme vision helps you to see obstacles earlier and improves the side perception. By producing even more light, Xenon X-treme vision lamps satisfy the most demanding drivers while maintaining its high Original Equipment quality and superior performance.

## UV Resistant



Philips special anti-UV coating technology protects the headlights against harmful ultraviolet radiation, making Philips UV-coated quartz glass perfect for all driving conditions and ensures their longevity

## High quality quartz glass



UV-Quartz glass is stronger than hard glass and highly resistant to temperature extremes and vibrations, which eliminates the risk of explosion. Philips quartz-glass lamps are able to withstand severe thermal shock. With the capability of increased pressure inside the lamp, UV-quartz glass is able to produce a more powerful light.

## Resistance against humidity

Only a burning bulb made of quartz glass can resist thermal shocks : if a drop of cold water touches the hot bulb, which can happen when you drive through water with a broken headlight unit.

Headlight bulb<br>  
Type of lamp: D2R Pack of: 1, 85 V,35 W

85126XVS1

# Specifications

## Marketing specifications

- Expected benefits: More light
- Product highlight: Up to 50% more light

## Product description

- Application: High beam, Low beam
- Base: P32d-3
- Designation: D2R X-tremeVision
- Homologation ECE
- Range: X-tremeVision
- Technology: Xenon
- Type: D2R

## Lifetime

- Life time: 2500h

## Light characteristics

- Lumens: 2800 ±450 lm
- Color temperature: 4700 K

## Electrical characteristics

- Wattage: 35 W
- Voltage: 85 V

## Ordering information

- Order entry: 85126XVS1
- Ordering code: 36464433

## Packaging Data

- Packaging type: S1
- EAN1: 8727900364644
- EAN3: 8727900364651

## Packed product information

- Width: 6.8 cm
- Height: 14 cm
- Net weight per piece: 18.1 g
- Gross weight per piece: 100.5 g
- Length: 12.5 cm
- Pack Quantity: 1
- MOQ (for professionals): 2

## Outerpack information

- Length: 14.6 cm
- Width: 13.1 cm
- Height: 14 cm
- Gross weight per piece: 0.2 kg



Issue date 2023-09-14

Version: 6.0.1

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)