



Philips WeatherVision  
Headlight bulb

Type of lamp: HB4

Pack of: 2  
12 V, 55 W



9006WVS2

## Feel safe, drive safe

### Ultimate yellow light

Philips WeatherVision halogen headlamp offers up to 60% more yellow light\* improving your visibility to drive safely through bad weather conditions such as rain, fog and snow. It is ECE compliant\*\* for road legal usage.

#### Enhancing safety by increased visibility

- Greater driving comfort and safety

#### Ultimate yellow light for better contrast

- Homogeneous yellow light for better contrast on the road

#### High quality and ultra resistant headlamp

- Change both your headlamps simultaneously for more safety
- Philips car lamps are highly UV resistant
- Wide range of 12V lamps for all functions
- Philips is the choice of major car manufacturers.
- Philips car lamps are made of high-quality quartz glass
- Philips car lamps are highly resistant against humidity^
- Complying with high quality standards of ECE homologation

# PHILIPS

Headlight bulb  
Type of lamp: HB4 Pack of: 2, 12 V,55 W

9006WVS2

# Highlights

## Change by pairs



Highly recommended to change them by pairs for symmetric light performance

## Increased contrast



With homogeneous yellow coating, WeatherVision offers the ultimate yellow light that penetrates better in adverse weather conditions to ensure a safer drive.

## High quality and visibility

WeatherVision provides you with up to 60% more vision\* on the road so you see further ahead and notice obstacles and traffic signs earlier. \*Performance varies per bulb type

## Car manufacturers' choice

For 100 years, Philips has been on the forefront of the automotive lighting industry, introducing technological innovations that have become standards on modern automobiles. Today, one in two cars in Europe and one in three worldwide, is equipped with Philips lighting.

## Designed for multiple usage



Which 12V lamp for which function? Philips Automotive offers all car specific functions : high beam, Low beam, front fog, front indicator, side indicator, rear indicator, stop light, reversing light, rear fog light, license plate lights, rear position/parking light, interior lights

## ECE homologation

WeatherVision is fully compliant to ECE for road-legal use.

## High quality quartz glass

UV-Quartz glass is stronger than hard glass and highly resistant to temperature extremes and vibrations, which eliminates the risk of

explosion. Philips quartz-glass lamps (filament 2 650° C and glass 800° C) are able to withstand severe thermal shock. With the capability to withstand increased pressure inside the lamp, UV-quartz glass is able to produce more powerful light. ^Application varies per bulb type

## Resistance against humidity

Only a burning bulb made of quartz glass (filament 2650°c, glass 800°c) can resist thermal shocks : such as, if a drop of cold water touches the hot bulb, when you drive through water with a broken headlight unit. ^Application varies per bulb type

## UV Resistant



Philips special anti-UV coating technology protects the headlights against harmful ultraviolet radiation, making Philips UV-coated quartz glass ideal for all driving conditions and ensures their longevity at the same time.

Headlight bulb  
Type of lamp: HB4 Pack of: 2, 12 V,55 W

9006WVS2

# Specifications

## Marketing specifications

- Expected benefits: Ultimate yellow light
- Product highlight: 2900K

## Product description

- Application: Additional high beam, High beam, Low beam
- Base: P22d
- Designation: HB4 WeatherVision
- Homologation ECE
- Marking ECE: N/A
- Range: WeatherVision
- Technology: Halogen
- Type: HB4

## Lifetime

- Life time: 400 h

## Light characteristics

- Color temperature: 2900 K
- Lumens: 1095 ± 15% lm

## Electrical characteristics

- Wattage: 55 W
- Voltage: 12 V

## Ordering information

- Ordering code: 35381530

## Packaging Data

- Packaging type: S2
- EAN1: 8727900353815
- EAN3: 8727900353822

## Packed product information

- Width: 5.3 cm
- Height: 10.9 cm
- Net weight per piece: 20,4 g
- Gross weight per piece: 126,5 g
- Length: 10.9 cm
- Pack Quantity / MOQ: 20

## Outerpack information

- Length: 27.6 cm
- Width: 22.8 cm
- Height: 12.6 cm
- Gross weight per piece: 2,53 kg



Issue date 2023-09-14

Version: 7.1.1

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Compared to standard halogen bulbs  
\*\* Application varies per bulb type