



Philips WhiteVision
car headlight bulb

Type of lamp: HB4

Pack of: 2+2
12 V,51 W
w5w position lamps included

9006WHVSM

Safety has never been so attractive

Brightness has never been so attractive

Philips WhiteVision lamps add an intense white Xenon look to your car headlights for a premium driving experience. The increased brightness with significantly whiter light makes WhiteVision the perfect combination of style and safety.

Maximum white light for greater contrast

- Greater contrast for improved visibility and safer driving

Maximum visibility, premium look

- Crisp beam with intense white light
- Up to 60% more vision to maximize clarity
- A premium driving experience with intense white Xenon effect
- White Xenon effect color match for high end look

Original equipment, 100% road legal

- Best-in-class lifetime for extended driving pleasure
- Philips car lamps are highly resistant
- 100% road legal, 100% intense white light

High quality and ultra resistant headlamp

- Philips is the choice of major car manufacturers

PHILIPS

car headlight bulb

Type of lamp: HB4 Pack of: 2+2, 12 V,51 W, w5w position lamps included

Highlights

A premium driving experience

Outperforming any blue car bulbs on the market, Philips WhiteVision headlights are the right choice for drivers who want to drive with style without compromising on safety. With a high color temperature and a stylish white cap, WhiteVision is the ultimate upgrade for your headlamps. The Philips patented 3rd generation coating technology* is an evolutionary masterpiece making WhiteVision the first headlamp with a truly white light. *(available for H4, H7, H11, HB3, HB4)

Crisp white beam

WhiteVision



With up to 3700 Kelvin and an intense white light, Philips WhiteVision headlights illuminate the road ahead with a crisp white beam that eliminates darkness instantly. The premium beam for a premium driving experience.

White Xenon effect

Supplied with two colour matching w5w position lamps, WhiteVision gives your car lights the premium look of high end cars.

Up to 60% more vision

An light output improved by 60% m enables you to be seen by other road users more clearly. It improves safety, giving you them more time to react to potential hazards.

Greater contrast, safer drive

Maximum white light with a color temperature of 3700 Kelvin means your headlights give better reflections from road markings and signs. Whiter

light keeps you alert at night, so you can enjoy a more comfortable driving experience at night.

100% road legal



WhiteVision is ECE certified and the first road-legal intense white light. It gives you the ultimate in high visibility without compromising safety by dazzling the car in front.

Best-in-class lifetime

Philips WhiteVision headlights (available in H1, H3, H4, H7, HB3) are designed to last. They offer you a long and reliable lifetime of 450 hours*. That's significantly higher than competitive offerings. This results in fewer replacements and more value for money. (*H4 and H7 tested at 13,2V standard voltage)

High quality, high resistance

UV-Quartz glass is stronger than hard glass and highly resistant to temperature extremes and vibrations, which eliminates the risk of early failure. Philips UV-Quartz glass car lamps allow more pressure inside the lamp to produce a more powerful light and extended lifetime.

Car manufacturers' choice

For 100 years, Philips has been at the forefront of the automotive lighting industry, introducing technological innovations that have become standard on modern automobiles. Today, one in two cars in Europe and one in three worldwide is equipped with Philips lighting.

9006WHVSM

Specifications

Marketing specifications

- Expected benefits: Style
- Product highlight: Intense white xenon effect

Product description

- Application: High beam, Low beam, Additional high beam
- Base: P20d
- Designation: HB4 WhiteVision
- Homologation ECE
- Range: WhiteVision
- Technology: Halogen
- Type: HB4

Lifetime

- Life time: 240h

Light characteristics

- Lumens: 1095 ±15% lm
- Color temperature: up to 3700 K

Electrical characteristics

- Voltage: 12 V
- Wattage: 51 W

Ordering information

- Order entry: 9006WHVSM
- Ordering code: 34036530

Packaging Data

- EAN1: 8727900340365
- EAN3: 8727900340372
- Packaging type: SM

Packed product information

- Gross weight per piece: 85.3 g
- Length: 10.9 cm
- Width: 5.9 cm
- Height: 10.9 cm
- Net weight per piece: 19.267 g
- MOQ (for professionals): 20

Outerpack information

- Length: 34.7 cm
- Width: 26.8 cm
- Height: 13.6 cm
- Net weight per piece: 385 g
- Gross weight per piece: 1.706 g



Issue date 2023-09-14

Version: 1.0.3

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com