



Philips LongLife EcoVision
car headlight bulb

Type of lamp: H18

Pack of: 1
12V, 65W
More Durability



12643LLC1

Drive with care

Longer lifetime, less replacement

Philips LongLife EcoVision headlight bulbs last much longer than standard lamps. This makes them the natural choice for drivers seeking to minimise maintenance on their vehicles.

Lasts significantly longer than a standard lamp

- No replacement necessary for up to 1,100 hours

The top-quality, ultra-durable car lamp

- Philips car lamps are made of high-quality quartz-glass
- Change both headlight bulbs at once for greater safety.

Original Equipment Manufacturer quality

- Philips is the choice of major car manufacturers

PHILIPS

car headlight bulb2

Type of lamp: H18 Pack of: 1, 12V, 65W, More Durability

12643LLC1

Specifications

Marketing specifications

- Expected benefits: Long lasting
- Product highlight: Longer lifetime

Product description

- Application: High beam, Low beam
- Base: PY26d-1
- Designation: H18 LongLife EcoVision
- Homologation ECE
- Range: LongLife EcoVision
- Technology: Halogen
- Type: H18

Lifetime

- Life time: 1100h

Light characteristics

- Lumens: 1700 +/-8%
- Color temperature: N.A.

Electrical characteristics

- Wattage: 65 W
- Voltage: 12 V

Ordering information

- Order entry: 12643LLC1
- Ordering code: 35603830

Packaging Data

- Packaging type: C1
- EAN1: 8727900356038
- EAN3: 8727900356045

Packed product information

- Gross weight per piece: 15.34 g
- Length: 3.5 cm
- Width: 3.5 cm
- Height: 6.5 cm
- Net weight per piece: 11 g
- Pack Quantity: 1
- MOQ (for professionals): 10

Outerpack information

- Length: 18.5 cm
- Width: 7.5 cm
- Height: 7 cm
- Gross weight per piece: 0.192 kg

Highlights

Lamps that last longer

It's the high-quality materials and robust filament design that let Philips LongLife EcoVision lamps last up to 1,100 hours. That means less time replacing spent bulbs, minimizing maintenance. Their durability makes Philips LongLife EcoVision lamps ideal for high-voltage cars, too.

Top-quality car lighting

Technologically advanced Philips lighting is renowned in the automotive industry, and has been for over 100 years. Philips Original Equipment Quality products are designed and developed following strict quality control processes (including applicable ISO norms), leading to consistently high production standards. LongLife EcoVision is compatible with car models of major brands, such as Audi, BMW, Ford, GM, Toyota and Volkswagen. See the product selector guide for more information.

High-quality quartz-glass

UV quartz-glass is stronger than hard glass and highly resistant to temperature extremes, humidity and vibration, eliminating the risk of explosion. Philips quartz-glass lamps (filament 2 650° C and glass 800° C) can withstand severe thermal shock. With higher pressure inside the lamp, UV-quartz glass is able to produce a more powerful light.

Change headlight bulbs in pair

There are good reasons to change headlight bulbs in pairs. The filament of older headlamps will break sooner. At the end of their life, lamps project less light, thereby reducing visibility. It's faster, easier and cheaper to change both headlamps rather than just one. Choosing Original Equipment bulbs reduces the chance of early failure thanks to their higher quality standards and raw materials.



Issue date 2023-09-14

Version: 1.0.1

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com