

Philips Xperion 3000  
Flood

1000 lm Boost/500 lm Eco

300 lm Spotlight  
Battery life: 3 h (Eco: 6 h)  
180° pivoting handle

LUMX30FLX1



# Quality light to get the job done

## Portable LED projector light

Small but powerful, versatile yet robust, the Philips Xperion 3000 Flood LED projector light provides the bright white light you need to illuminate large dark areas. Enjoy up to six hours of continuous use before charging the battery.

### **Bright, comfortable work light**

- Light up your whole work area

### **Sturdy lamp for daily use**

- Shock resistance proven in drop tests
- Water resistant against splashes

### **Versatile for hands-free use**

- Rotating handle for hands-free use
- Magnetic mounting accessory for hands-free lighting

### **Handy and easy to operate**

- Recharge other devices with the useful USB port
- Rechargeable battery lasts up to 6 hours
- Indicator shows how long the battery will last

# PHILIPS

Flood  
1000 lm Boost/500 lm Eco 300 lm Spotlight, Battery life: 3 h (Eco: 6 h), 180° pivoting handle

# Specifications

## Marketing specifications

- Product highlight: Dual lights: flood + spotlight
- Expected benefits: Portable LED projector light

## Product description

- Impact protection rating (IK): IK08
- Ingress protection rating (IP): IP65
- Magnet: Magnetic handle
- Materials and finishing: Nylon+ rubber
- Operating temperature: 0°C to 40°C
- Orientable light: 180° pivoting handle
- Pointing light
- Range: Xperion 3000
- Resistant to: grease, oil, workshop solvents
- Technology: LED
- UV leak detector: No
- Hook: 180° rotatable

## Light characteristics

- Colour temperature: 6000 K
- LED lifetime: 30000 hour(s)
- Light output (pointer): 300 lumens
- Beam angle: 110°
- Light output: 1000 lumens
- Light output (eco): 500 lumens
- Beam angle (pointer): 30°

## Electrical characteristics

- Wattage: 10 W + 3 W Spot W
- Voltage: 3.7 V

- Battery capacity: 4400 mAh
- Battery run time (boost): Up to 3 hours
- Battery run time (eco): Up to 6 hours
- Battery type: Li-ion battery
- Plug type: Plug not included
- Charging cable type: USB-C cable
- Battery charging time: Up to 5.5 hours
- Power Source: Li-ion battery

## Ordering information

- Order entry: X30FLX1
- Ordering code: 02504331

## Packaging Data

- EAN1: 8719018025043
- EAN3: 8719018025050

## Packed product information

- Length: 10,8 cm
- Width: 4,5 cm
- Height: 13 cm
- Pack Quantity / MOQ: 1
- Weight with batteries: 235 g
- Cable length: 100 cm USB-C cable

## Outer pack information

- Length: 28 cm
- Width: 12,8 cm
- Height: 17,6 cm
- Gross weight per piece: 1,81 g

LUMX30FLX1/10

# Highlights

## Bright, comfortable work light

Whether you need to light up a work site, temporarily replace a wall lamp or illuminate outdoor activities, the Philips Xperion 3000 Flood is perfect for lighting up large dark areas. Delivering 1000 lumens (10 W), its homogeneous bright light produces an extra-wide beam. If you need less light and more battery life, you can switch to the 500 lumen (5 W) Eco mode.

## Shock resistant

We've made our Philips Xperion 3000 Flood tough enough for use both indoors and outside. Built to last, this lamp has been subjected to 1.5 metre drop tests and can easily survive occasional drops during use.

## Water resistant

Whether you use our Philips Xperion 3000 Flood indoors or outdoors, the lamp is designed to survive in tough conditions. Resistant to water, it will continue to work when splashed, such as during light rain.

## Versatile rotating handle

Sometimes you need hands-free lighting so you can focus on your task. The 180° rotating handle on the back of our Philips Xperion 3000 Flood allows you to position the projector as needed. You can also use the handle as a hook to hang the lamp or as a support to stand it up. This versatility enables you to direct the light just where you need it.

## Useful USB charging port

The Philips Xperion 3000 Flood can also be used as a power bank to charge other devices, such as your smartphone. Plug your device into the USB port on the back of the lamp, and it will begin charging.

## Magnetic mounting accessory

The Philips Xperion 3000 Flood also comes with a magnetic mounting accessory. Attach it to the handle to mount your projector onto any metal surface. Perfect for use in a garage or other work environments.

## Up to 6 hours of battery life

Once fully charged, your Philips Xperion 3000 Flood delivers bright white light (1000 lumens/10 W) for up to three hours in Boost mode. If you need longer battery life, switch to Eco mode (500 lumens) and enjoy up to six hours of continuous light.

## Battery-life indicator

No more worries about your light dying just when you need it most. On the back of the Philips Xperion 3000 Flood is a battery-life indicator which tells you exactly how long you've got before needing to recharge the battery.



Issue date 2024-02-03

Version: 2.2.1

EAN: 87 19018 02504 3

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)