

Philips Xperion 3000
Headlight

300 lm Boost / 100 lm Eco

200 lm Spotlight
Battery life: 2h (Eco: 6h)
3 light modes

LUMX30HEADX1



Quality light to get the job done

Dual-mode LED headlight

The lightweight Philips Xperion 3000 Headlight provides bright white light where you need it. Two preset modes of up to 300 lumens and a comfortable headband make it a versatile, hands-free tool for everyday use.

Dual-mode, natural white LED light

- Light up your whole work area
- 200-lm pointer for spot inspection

Versatile for hands-free use

- Comfortable headband

Handy and easy to operate

- Fast-charge, long-life battery

Sturdy lamp for daily use

- Resistant to impacts, water and solvents (IP65/IK07)

PHILIPS

Headlight

300 lm Boost / 100 lm Eco 200 lm Spotlight, Battery life: 2h (Eco: 6h), 3 light modes

Specifications

Marketing specifications

- Product highlight: 3 light modes
- Expected benefits: Dual-mode LED headlight

Product description

- Headband
- Impact protection rating (IK): IK07
- Ingress protection rating (IP): IP65
- Materials and finishing: Rubber +PC
- Operating temperature: 0°C to 40°C
- Orientable light: No
- Pointing light
- Range: Xperion 3000
- Resistant to: grease, oil, workshop solvents
- Technology: LED
- UV leak detector: No

Light characteristics

- Colour temperature: 6000 K
- LED lifetime: 30000 hour(s)
- Light output (pointer): 200 lumen
- Beam angle: 120°
- Light output: 300 lumens
- Light output (eco): 100 lumen

Electrical characteristics

- Wattage: 3W+2W Spot W
- Voltage: 3.7 V
- Battery capacity: 1200 mAh

- Battery run time (boost): Up to 2 hours
- Battery run time (eco): Up to 6 hours
- Battery type: Li-ion battery
- Plug type: Plug not included
- Charging cable type: USB-C cable
- Battery charging time: Up to 2.5 hours
- Power Source: Li-ion battery

Ordering information

- Order entry: X30HEADX1
- Ordering code: 02490931

Packaging Data

- EAN1: 8719018024909
- EAN3: 8719018024916

Packed product information

- Length: 9,5 cm
- Width: 4,5 cm
- Height: 12,3 cm
- Pack Quantity / MOQ: 6
- Weight with batteries: 100 g
- Cable length: 100 cm USB-C cable

Outer pack information

- Length: 20 cm
- Width: 15,6 cm
- Height: 14 cm
- Gross weight per piece: 1,08 g

LUMX30HEADX1/10

Highlights

Bright, comfortable work light

The Philips Xperion 3000 Headlight projects a broad white light to illuminate the whole area in front of you. The 6000-Kelvin light is easy on the eyes, improving visual comfort and reducing eye strain for fatigue-free working.

LED spotlight

The Philips Xperion 3000 Headlight features a 200-lumen spotlight to direct the light exactly where you need it and get the job done.

Comfortable headband

The Philips Xperion 3000 Headlight boasts an anti-slip elastic headband that fits comfortably around your head. The headband is easily adjustable.

Fast-charge, long-life battery

The Philips Xperion 3000 Headlight takes less than 2.5 hours to charge fully. A battery designed to last 2 to 6 hours lets you work a whole day without interruption. Then recharge overnight, ready to go again the next day.

Sturdy lamp for daily use

Designed to handle challenging work environments with IK07 shock resistance, water resistant to IP65 standards, and a surface that withstands chemicals and workshop solvents, the Philips Xperion 3000 Headlight is built to last because we know that even the steadiest hands need extra help.



Issue date 2024-01-23

Version: 1.1.1

EAN: 87 19018 02490 9

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com