

Philips Xperion 3000
Zoom

1000 lm Boost / 200 lm Eco

1000/200 lm Spotlight
Battery life: 1,5/3h (Eco: 9h)
Light zoom 20° to 130°

LUMX30ZOOMX1



Quality light to get the job done

Powerful LED zoom light

With its powerful bright light, non-slip grip, and versatile design, the Philips Xperion 3000 Zoom is an excellent LED work lamp for everyday use. Its zoom lens allows you to adjust your light from wide flood to focused brightness easily.

Bright, comfortable work light

- Powerful light suitable for daily use
- Focused light to illuminate smaller areas

Versatile for hands-free use

- Magnet for convenient hands-free lighting

Handy and easy to operate

- Rechargeable lithium battery lasts up to 9 hours

Sturdy lamp for daily use

- Robust housing and shock resistant

PHILIPS

Zoom

1000 lm Boost / 200 lm Eco 1000/200 lm Spotlight, Battery life: 1,5/3h (Eco: 9h), Light zoom 20° to 130°

Specifications

Marketing specifications

- Product highlight: Light zoom 20° to 130°
- Expected benefits: Powerful LED zoom light

Product description

- Hook: No
- Impact protection rating (IK): IK07
- Ingress protection rating (IP): IP54
- Magnet: 1 magnet
- Materials & finishing: Nylon+ rubber
- Operating temperature: 0°C to 40°C
- Orientable light: 180° pivoting head
- Pointing light
- Range: Xperion 3000
- Resistant to: grease, oil, workshop solvents
- Technology: LED
- UV leak detector: No

Light characteristics

- Color temperature: 6000 K
- LED lifetime: 30000 hour(s)
- Light output (pointer): 1000/200 lumens
- Beam angle: Zoom 20° to 130°
- Light output: 1000 lumens
- Light output (eco): 200 lumens

Electrical characteristics

- Wattage: 6 W
- Voltage: 3.7 V
- Battery capacity: 2500 mAh

- Battery run time (boost): Up to 1,5 hours
- Battery run time (eco): Up to 9 hours
- Battery type: Li-ion battery
- Plug type: Plug not included
- Charging cable type: USB-C cable
- Battery charging time: Up to 3.5 hours
- Power Source: Li-ion battery

Ordering information

- Order entry: X30ZOOMX1
- Ordering code: 02500531

Packaging Data

- EAN1: 8719018025005
- EAN3: 8719018025012

Packed product information

- Length: 10,8 cm
- Width: 5,1 cm
- Height: 20 cm
- Pack Quantity / MOQ: 6
- Weight with batteries: 245 g
- Cable length: 100 cm USB-C cable

Outerpack information

- Length: 26 cm
- Width: 24 cm
- Height: 17,9 cm
- Gross weight per piece: 2,17 g

LUMX30ZOOMX1/10

Highlights

Bright, comfortable work light

Whether you're in your garage, completing some DIY, or trying to fix an appliance, it's always handy to have a small lamp around you. The Philips Xperion 3000 Zoom delivers a powerful light beam of 1000 lumens to help you see the details you need to complete the task.

Handy spotlight

The Philips Xperion 3000 Zoom can focus its beam to a spotlight, illuminating those hard-to-see areas. The intense spotlight delivers up to 1000 lumens, so you can see small details even in dark corners.

Hands-free lamp

You often need both hands when working on a task. The Philips Xperion 3000 Zoom comes with an in-built magnet, so you can easily mount the lamp on any nearby metal surface, such as under a sink or the bonnet of a car.

Up to 9 hours of battery life

Once fully charged, your Philips Xperion 3000 Zoom delivers bright white light from its main beam for up to 1,5 hours (1000lm Boost mode). If you use the Eco mode, the battery will last up to nine hours. So with occasional use, the lamp can last days before needing to recharge.

Shock resistant

Even the most careful person sometimes drops things. That's why the Philips Xperion 3000 Zoom is designed with a robust housing, which means it will survive being dropped occasionally.



Issue date 2024-05-02

Version: 3.3.1

EAN: 87 19018 02500 5

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com