

Philips Ultinon Drive 5100  
15.2 cm (6") LED light bar

Road-legal ECE R149- 20  
2000 lm, 198 m beam length  
Dual-colour position light  
IP69K waterproof



LUMUD5104LX1

## Powerful brightness driving safety at the wheel

### Bright, durable gear for overland journeys

The Philips UD5104L LED light bar has the power to keep you safer, wherever you're headed. Spot hazards up to 198 metres away with lighting that performs in the most hostile environments and gives your vehicle a touch of style.

#### **Brilliance that makes you a safer driver**

- Intense, far and wide illumination for superior visibility

#### **Dual-color position lights that get you noticed**

- Choose your position-light colour
- Sturdy one-piece body for tough environments

#### **Designed to handle hostile environments**

- IP68 and IP69K-rated to master the elements
- Corrosion-free body, stainless-steel mounting brackets

#### **Road-legal auxiliary lights**

- Powerful road-legal LED lightbars

#### **Easy to install with flexible mounting options**

- Low-profile design for simpler fitting

# PHILIPS

15.2 cm (6") LED light bar  
Road-legal ECE R149- 20 2000 lm, 198 m beam length, Dual-colour position light, IP69K waterproof

# Specifications

## Product description

- Boost mode activation: No
- Break resistance
- Corrosion-free brackets: Side mounting brackets
- ECE R10
- ECE R149
- ECE reference number: 20
- Impact protection rating (IK): IK07
- Ingress protection rating (IP): IP68 and IP69K
- Installation angle: 360°
- Material: Aluminium extruded
- Off-road boost: No
- One-piece body design
- Operating temperature: -40° C to 80° C
- Range: Ultinon Drive 5100
- Scratch-resistant lens
- Technology: LED
- Width: 6 inch
- ECE R148
- Parking position light: yes, white or amber
- Plug type: 4-pin DT Connector with 0.5 m cable

## Light characteristics

- Colour temperature: 6500 K K
- Beam length 1 lux: 298 m
- Beam length 1 lux (boost): N/A
- Effective lumen output: 2000 lumens

- Raw lumen output: 6800 lumens
- Effective lumen output (boost): N/A

## Electrical characteristics

- Voltage: 9-30 Volt DC

## Ordering information

- Order entry: UD5104LX1
- GOC: 02440431

## Packaging Data

- EAN1: 8719018024404
- EAN3: 8719018024411

## Packed product information

- MOQ (for professionals): 8
- Box dimensions-L (mm): 100
- Box dimensions-W (mm): 100
- Box dimensions-H (mm): 1100
- Gross weight box-g: 1100
- Number of products in the box: 1

## Outer pack information

- Length: 75 cm
- Width: 14 cm
- Height: 115 cm

LUMUD5104LX1/10

# Highlights

## Up to 198 metre visibility

The Philips UD5104L LED light bar provides a brilliant light beam that illuminates the road ahead for up to 198 metres\*. Its effective 2000 lumens are homogeneously distributed in an optimised indirect beam, generating intense illumination far and wide with reduced glare for everyday use. This enables drivers to react faster on dark, rural and dirt roads. Its cool light colour of 6500 Kelvin produces daylight conditions, improving contrast and helping drivers stay focused.

## Brilliant white or amber LED

Never go unnoticed on side roads or in parking areas with the extra LED position lights of our Philips UD5104L LED light bar. Express your style and personality by choosing your light colour, either intense amber or cool white.

## Sturdy one-piece body

The Philips UD5104L LED light bar is built in a single piece to withstand the toughest conditions. Its design provides excellent heat management and consistently high light output throughout your journey. Rated IK07, it is shock-resistant to ensure faultless performance on and off the road. Its unbreakable polycarbonate lens can take any hit without damage or scratches.

## Waterproof for durable light

With its ingenious screwless design, the UD5104L LED light bar can withstand the wettest conditions. Its IP69K certification means it will perform, wherever your road leads and whatever the weather. And it will be more than a match for any power washer you use to clean your car afterwards.

## Corrosion-free

With its anodised, pre-treated and automotive-grade powder-top-coat body, the Philips UD5104L LED light bar offers ultimate corrosion protection. Its mounting brackets are made of stainless steel, which is corrosion-free. It can withstand snow, ice and even salt. Built from durable, high-quality materials, your Philips auxiliary LED lights will provide years of reliable service.

## Road-legal lights

The Philips UD5104L LED light bar meets ECE standards and is 100% road-legal for high-beam and position-light functions. For added safety, Philips LED light bars are tested to EMC R10 specification to ensure that they will function smoothly with your vehicle's electrical systems.

## Easy and flexible installation

The sleek, low-profile design makes installation easier, and flexible fitting options are possible with side-mounting brackets (included) and back-mounting brackets (UD1001M optional). Supplied with a pre-wired male/female 3-pin superseal DT connector, it is voltage-overload and reverse-polarity protected to make installation secure and easy.



Issue date 2023-09-28

Version: 2.2.1

EAN: 87 19018 02440 4

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* \*\*Beam length measured on 1 lux.