

Philips Xperion 3000  
Pillar

500 lm Boost / 200 lm Eco

120 lm Spotlight  
Battery life: 2.5h (Eco: 8h)  
180° pivoting head

LUMX30PILLX1



# Quality light to get the job done

## Bright LED hand lamp

With its powerful bright light, non-slip grip, lightweight design and versatility, the Philips Xperion 3000 Pillar is an excellent cordless LED work lamp for everyday use. There's even a handy spotlight to help you see in confined spaces.

### **Bright, comfortable work light**

- Bright, eye-friendly light suitable for daily use
- Spotlight to illuminate tight spaces

### **Versatile for hands-free use**

- 3 magnets for convenient, hands-free lighting
- 2 retractable hooks for convenient hands-free lighting

### **Handy and easy to operate**

- Rechargeable lithium battery

### **Sturdy lamp for daily use**

- Robust, shock-resistant housing

# PHILIPS

Pillar

500 lm Boost / 200 lm Eco 120 lm Spotlight, Battery life: 2.5h (Eco: 8h), 180° pivoting head

# Specifications

## Marketing specifications

- Product highlight: Dual lights: flood + spotlight
- Expected benefits: Bright LED hand lamp

## Product description

- Hook: 360° retractable hook
- Impact protection rating (IK): IK08
- Ingress protection rating (IP): IP20
- Magnet: 3 magnets
- Materials & finishing: Nylon +PC
- Operating temperature: 0°C to 40°C
- Orientable light: 180° pivoting head
- Pointing light
- Range: Xperion 3000
- Resistant to: grease, oil, workshop solvents
- Technology: LED
- UV leak detector: No

## Light characteristics

- Color temperature: 6000 K
- Light output (Eco): 200 lumens lm
- LED lifetime: 30000 hour(s)
- Light output (pointer): 120 lumens
- Beam angle: 90°
- Light output: 500 lumens
- Beam angle (pointer): 15°

## Electrical characteristics

- Wattage: 5W +1W Spot W
- Voltage: 3.7 V

- Battery capacity: 2500 mAh
- Battery run time (boost): Up to 2.5 hours
- Battery run time (eco): Up to 8 hours
- Battery type: Li-ion battery
- Plug type: Plug not included
- Charging cable type: USB-C cable
- Battery charging time: Up to 3.5 hours
- Power Source: Li-ion battery

## Ordering information

- Order entry: X30PILLX1
- Ordering code: 02496131

## Packaging Data

- EAN1: 8719018024961
- EAN3: 8719018024978

## Packed product information

- Pack Quantity / MOQ: 1
- Weight with batteries: 275 g
- Cable length: 100 cm USB-C cable
- Length [cm]: 10,8
- Width [cm]: 4,6
- Height [cm]: 28,2

## Outerpack information

- Length: 34,1 cm
- Width: 25 cm
- Height: 15,8 cm
- Gross weight per piece: 2,53 g

LUMX30PILLX1/10

# Highlights

## Bright, comfortable work light

Whether you're in your garage, completing some DIY, or trying to fix an appliance, it's always handy to have a reliable lamp around you. The Philips Xperion 3000 Pillar delivers a powerful main beam of 500 lumens, providing ample illumination to complete the task.

## Handy spotlight

The Philips Xperion 3000 Pillar also features a handy spotlight to illuminate those hard-to-see spaces. This high-power spotlight on the top of the lamp delivers 120 lumens for a clear, detailed view even in dark corners.

## 3 magnets

You often need both hands when working on a task. The Philips Xperion 3000 Pillar features three in-built magnets so you can easily mount the lamp on any nearby metal surface, such as under a sink or the bonnet of a car.

## 2 hooks for hands-free use

When you need both hands free to work, hang the Philips Xperion 3000 Pillar nearby with its two in-built 360 retractable hooks.

## Up to 8 hours of battery life

Once fully charged, your Philips Xperion 3000 Pillar delivers bright white light from its main beam for up to 3 hours in Boost mode. If you use the Eco mode, the battery will last up to eight hours. So with occasional use, the lamp can operate for several days before recharging.

## Shock resistant

Even the most careful person sometimes drops things. That's why the Philips Xperion 3000 Pillar is designed with a robust housing, which means it will survive being dropped occasionally.



Issue date 2024-02-06

Version: 3.3.1

EAN: 87 19018 02496 1

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)