



Philips Xperion 6000  
Pillar

500 lm Boost / 250 lm Eco

180 lm Spotlight  
Battery life: 4,5h (Eco: 10h)  
Ergonomic and foldable



X60PILLX1

## Designed with you in mind

Advanced lighting performance that lasts

The Philips Xperion 6000 Pillar lasts all day on a single charge. Its bright 250 and 500 lm main light and inbuilt 180 lm torch will meet multiple needs. Foldable for easy carrying and adjustable lighting angles.

### Accessories available to upgrade your work lamp

- Smart solutions for charging and finding your device

### Extended warranty

- Extend your warranty online to 3 years

### Handles tough conditions easily

- Resistant to impacts, water and solvents (IP65/IK07)

### Smart, ergonomic design

- Smart rotatable hook with magnet and ergonomic body

### See where others can't

- Long running time in different light modes
- Premium LED light with multiple outputs

# PHILIPS

# Highlights

## Multiple light modes



Featuring high-quality and bright LED light, the Philips Xperion 6000 Pillar displays objects faithfully and vibrantly via a high-luminosity, wide-beam main source producing 250 lm in Eco and 500 lm in Boost mode. Use the strong spotlight with a 180 lm torch beam to see better and spot the smallest details.

## Light modes for multiple needs



The Philips Xperion 6000 Pillar is designed to be ready for action. A single charge provides enough energy for a full day's work: up to 10 hours in Eco mode, 4,5 hours in Boost mode, and 12 hours with the torch beam. Powered by a powerful Li-ion battery, the Philips Xperion 6000 Pillar can be fully charged within 4,5 hours via USB-C, ensuring maximum usage of its bright LED light.

## Enables hands-free working



Designed with you in mind, the ergonomically shaped handle with anti-slip coating allows you to hold this work light securely. If you need both hands free for work, position the light securely thanks to the 360° rotatable, retractable hook and a strong magnet. The power button is located on the back to ensure the light does not glare directly at your eyes when you turn it on.

## Designed for resistance



Designed to handle tough work environments with IK07 shock resistance, water-resistant to IP65 standards, and a surface to withstand chemicals and workshop solvents, the Philips Xperion 6000 Pillar is built to last because we know that even the steadiest hands need the extra support.

## Up to 3 years warranty



Benefit from Philips standard 2-year warranty plus 1 additional year<sup>1</sup>

## Upgrade your work light



Don't worry about losing your device anymore. You can find it easily with the "Find My Device" function. Use the remote control to trigger an audible buzzer and flashing light to locate your device. The vibrant lime-green body will help you spot your device even in dark settings. To keep your work light to hand and ready to use, try the Philips Dock station. Placed on a table, it provides cordless charging for your lamp.<sup>2</sup> Find out more: [Philips.com/Xperion-6000](https://philips.com/Xperion-6000)

# Specifications

## Marketing specifications

- Product highlight: Ergonomic and foldable
- Expected benefits: Designed with you in mind

## Product description

- Hands free options: Rotatable hook, strong magnet
- Hook: 360° rotatable
- Impact protection rating (IK): IK07
- Magnet: 2 magnets
- Materials & finishing: Robust ABS + Soft rubber
- Operating Temperature: -10°C to 40°C
- Range: Xperion 6000
- Technology: COB LED
- UV leak detector: No
- Ingress protection rating (IP): IP65
- Resistant to: Grease, oil, workshop solvents

## Light characteristics

- Beam angle: 100° degree
- Color temperature: 6000 K
- Light output (pointer): 180 lumens
- Light output (eco): 250 lumens
- Beam angle (pointer): 15°
- Light output (boost): 500 lumens

## Electrical characteristics

- Voltage: 3.7 V
- Power source: Rechargeable battery
- Battery capacity: 4400 mAh

- Battery run time (boost): Up to 4,5 hours
- Battery run time (eco): Up to 10 hours
- Battery type: Lithium battery
- Plug type: EU plug (not included for UK)
- Charging cable type: Type C USB
- Battery charging time: Up to 4.5 hours
- Wattage: 5W
- Battery run time (Pointer): Up to 12 hours

## Ordering information

- Order entry: X60PILLX1
- Ordering code: 01469631

## Packaging Data

- EAN1: 8719018014696
- EAN3: 8719018014702

## Packed product information

- Length: 5.2 cm
- Height: 23 cm
- Pack Quantity / MOQ: 6
- Weight with batteries: 412 g
- Cable length: 100cm USB cable, 5V 1A adaptor

## Outerpack information

- Length: 25 cm
- Width: 17 cm
- Height: 18 cm



Issue date 2023-10-12

Version: 11.11.1

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* 1 to be claimed on the Philips extended-warranty webpage

\* 2 Compatible with Xperion 6000 UV Pillar, Pillar, Slim, and Pocket