

Philips Xperion 6000  
Flood

1000 lumens /250 lm Spotlight

Light zoom function  
Motion-sensing  
Highly versatile

LUMX60FLX1



## Designed with you in mind

### Multipurpose LED projector light

With its 1000-lm flood light and variable beam, the Philips Xperion 6000 Flood multipurpose projector gets the job done. The smart-zoom knob and motion sensor simplify control, while resistance to impacts and water guarantees durability.

#### **Extended warranty**

- Extend your warranty online to 3 years

#### **Highly versatile**

- Recharge other devices with a useful USB port

#### **Handles tough conditions easily**

- Resistant to impacts, water and solvents (IP65/IK07)

#### **Smart, ergonomic design**

- Motion detection enables remote control for your light
- Smart-zoom knob to easily control your light
- Smart handle to position light for hands-free use
- Rechargeable via USB type C or wireless dock station

#### **See where others can't**

- Powerful white light (1000 lumen / 10W) lights up large area
- The two most used lights combined into one lamp

# PHILIPS

# Specifications

## Marketing specifications

- Product highlight: Powerful and ergonomic
- Expected benefits: Designed with you in mind

## Product description

- Hands free options: Rotatable hook, strong magnet, Smart handle
- Impact protection rating (IK): IK07
- Magnet: Magnetic handle
- Materials & finishing: Robust ABS
- Operating Temperature: -10°C to 40°C
- Range: Xperion 6000
- Technology: COB LED
- UV leak detector: No
- Hook: 180° rotatable
- Ingress protection rating (IP): IP65
- Resistant to: Grease, oil, workshop solvents
- Bluetooth connection

## Light characteristics

- Beam angle: 100 degree
- Color temperature: 6000 K
- Beam angle (pointer): 15 degree
- Light output (pointer): 250 lumens
- Light output (eco): 100 lumens
- Light output (boost): 1000 lumens

## Electrical characteristics

- Voltage: 3.7 V
- Power source: Rechargeable battery
- Battery capacity: 4400 mAh
- Battery run time (boost): 3h
- Battery run time (eco): 22h
- Battery type: Lithium battery
- Plug type: EU plug (not included for UK)
- Charging cable type: Type C USB
- Battery charging time: Up to 5h
- Wattage: 10W
- Battery run time (Pointer): 9h

## Ordering information

- Order entry: X60FLX1
- Ordering code: 1909731

## Packaging Data

- EAN1: 8719018019097
- EAN3: 8719018019103

## Packed product information

- Length: 90 cm
- Height: 140 cm
- Pack Quantity / MOQ: 6
- Width: 60
- Cable length: 100cm USB cable, 5V 1A adaptor

# Highlights

## Illuminate the whole work area

Whether you need to light up a work site, temporarily replace a wall lamp, or illuminate outdoor activities, the Philips Xperion 6000 Flood projector is perfect for lighting up large dark areas. Delivering a powerful 1000 lumen (10W), its consistently bright light gives off a super wide beam. If you need less light and more battery life, you can easily dim the lamp to a 100 lumen output.

## Multipurpose light

Different jobs demand different amounts of light. The Philips Xperion 6000 Flood projector combines in one lamp the two most commonly used forms of workshop lighting. A wide-angle homogeneous flood light for working on big areas over longer periods, and a focused light that concentrates illumination within small areas to get the best contrast and brightness, ideal for detailed inspections and narrow spaces.

## Smart-zoom knob

Co-designed with mechanics, the ergonomic smart-zoom knob allows you to adjust your light from wide flood illumination to focused brightness easily, even with your gloves on. Positioned on the side of the lamp, the rotatable smart-zoom knob is always within reach, meaning you don't have to move the lamp from its mounted position. The lamp's smart design enables it to remember your last setting and restart directly at the desired intensity.

## Control your light remotely

If you need both hands free for work, you can remotely power the light on or off by simply waving your hand. Designed to ignore unintended movements, the sensor only responds to a specific double-wave gesture.

## Versatile attachments

The smart handle can be used as a support to hold the projector up by itself, as a hook to hang the light from, screwed on to a tripod, or attached to any metal surface with its integrated magnets. This versatility allows you to position the light easily and at the right angle, directing the beam just where you need it.

## Designed for durability

Designed to handle tough work environments with IK07 shock resistance, water-resistant to IP65 standards, and a surface to withstand chemicals and workshop solvents, the Philips Xperion 6000 Flood is built to last because we know that even the steadiest hands need extra help.

## Recharge other devices

The Philips Xperion 6000 Flood projector can be also used as a power bank to charge other devices, such as your phone. Simply plug your device into the USB port on the back of the lamp and it will begin charging.

## Up to 3 years' warranty

Benefit from Philips standard 2-year warranty plus 1 additional year\*.

## Ready for action

The Philips Xperion 6000 Flood projector can be charged by USB type C cable (included in the pack), or directly on the Philips wireless dock station. Find out more: [Philips.com/Xperion-6000](https://philips.com/Xperion-6000)



Issue date 2024-05-02

Version: 4.4.1

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](https://www.philips.com)

\* To be claimed on the [//Philips.com/extended-warranty](https://philips.com/extended-warranty) webpage