

Philips Xperion 6000  
Flood Mini

500 lumens / 250 lm Spotlight

Light zoom function  
Battery life: 3h (Eco: 9h)  
Versatile

LUMX60FLMIX1



# Designed with you in mind

## Compact LED projector light

With its 500-lm flood light and variable beam, the Philips Xperion 6000 Flood compact projector gets the job done. The smart-zoom knob simplifies control, while resistance to impacts and water guarantees durability.

### Accessories available to upgrade your work lamp

- Smart solutions for charging and finding your device

### Extended warranty

- Extend your warranty online to 3 years

### Handles tough conditions easily

- Resistant to impacts, water and solvents (IP65/IK07)

### See where others can't

- Combines the two most commonly used work lights in one lamp

### Smart, compact design

- Compact and lightweight to take with you everywhere
- Indicator shows remaining battery life
- Smart-zoom knob to easily control your light
- Smart handle to position light for hands-free use
- Rechargeable via USB type C or wireless dock station

# PHILIPS

## Flood Mini

500 lumens / 250 lm Spotlight Light zoom function, Battery life: 3h (Eco: 9h), Versatile

# Specifications

### Marketing specifications

- Product highlight: Compact and ergonomic
- Expected benefits: Designed with you in mind

### Product description

- Hands free options: Rotatable hook, strong magnet, Smart handle
- Impact protection rating (IK): IK07
- Magnet: Magnetic handle
- Materials & finishing: Robust ABS
- Operating Temperature: -10°C to 40°C
- Range: Xperion 6000
- Technology: COB LED
- UV leak detector: No
- Hook: 180° rotatable
- Ingress protection rating (IP): IP65
- Resistant to: Grease, oil, workshop solvents

### Light characteristics

- Beam angle: 100 degree
- Color temperature: 6000 K
- Beam angle (pointer): 15 degree
- Light output (pointer): 250 lumens
- Light output (eco): 100 lumens
- Light output (boost): 500 lumens

### Electrical characteristics

- Voltage: 3.7 V

- Power source: Rechargeable battery
- Battery capacity: 2500 mAh
- Battery run time (boost): 3h @ 500 lumens
- Battery run time: 3h @ 500 lumens
- Battery run time (eco): 9h @ 100 lumens
- Battery type: Lithium battery
- Plug type: EU plug (not included for UK)
- Charging cable type: Type C USB
- Battery charging time: Up to 3,5 hours
- Wattage: 5W
- Battery run time (Pointer): 5h @ 250 lumens

### Ordering information

- Order entry: X60FLMIX1
- Ordering code: 1913431

### Packaging Data

- EAN1: 8719018019134
- EAN3: 8719018019141

### Packed product information

- Length: 70 cm
- Height: 120 cm
- Pack Quantity / MOQ: 6
- Width: 50
- Cable length: 100cm USB cable, 5V 1A adaptor

LUMX60FLMIX1/10

# Highlights

### Multipurpose light

Different jobs demand different amounts of light. The Philips Xperion 6000 Flood compact projector combines in one lamp the two most commonly used forms of workshop lighting. A wide-angle homogeneous flood light for working on big areas over longer periods, and a focused light that concentrates illumination within small areas to get the best contrast and brightness, ideal for detailed inspections and narrow spaces.

### Compact, lightweight design

Philips Xperion 6000 Flood compact projector allows you to take your rechargeable projector light with you, wherever you go. Easy to store in a glove box.

### Smart-zoom knob

Co-designed with mechanics, the ergonomic smart-zoom knob allows you to adjust your light from wide flood illumination to focused brightness easily, even with your gloves on. Positioned on the side of the lamp, the rotatable smart-zoom knob is always within reach, meaning you don't have to move the lamp from its mounted position. The lamp's smart design enables it to remember your last setting and restart directly at the desired intensity.

### Versatile attachments

The smart handle can be used as a support to hold the projector up by itself, as a hook to hang the light from, screwed on to a tripod, or attached to any metal surface with its integrated magnets. This versatility allows you to position the light easily and at the right angle, directing the beam just where you need it.

### Don't get left in the dark

Never worry about your light dying just when you most need it. On the back of the Philips Xperion 6000 Flood compact projector you will find a battery-life indicator, which tells you exactly how long you've got before you need to recharge the battery.

### Designed for durability

Designed to handle tough work environments with IK07 shock resistance, water-resistant to IP65 standards, and a surface to withstand chemicals and workshop solvents, the Philips Xperion 6000 Flood is built to last because we know that even the steadiest hands need extra help.

### Upgrade your work light

Don't worry about losing your device anymore. You can add the "Find My Device" function to your Philips Xperion Flood compact projector. Use the remote control to trigger an audible buzzer and flashing light to locate your device. The vibrant lime-green body will help you spot your device even in dark settings.

### Up to 3 years' warranty

Benefit from Philips standard 2-year warranty plus 1 additional year\*.

### Ready for action

The Philips Xperion 6000 Flood compact projector can be charged by USB type C cable (included in the pack), or directly on the Philips wireless dock station. Find out more: [Philips.com/Xperion-6000](https://www.philips.com/Xperion-6000)



Issue date 2024-05-02

Version: 4.4.1

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](https://www.philips.com)

\* To be claimed on the [//Philips.com/extended-warranty](https://www.philips.com/extended-warranty) webpage