



Philips Ultinon Pro3100 SI  
Signalling bulb

LED-White [≈W16W]

Number of bulbs: 1  
12 V, 6000 K, daylight effect  
Advanced automotive system

11067CU31B1

## Stand out from the crowd

Durable and vibrant LED signalling

For a stylish drive, upgrade to Philips Ultinon Pro3100 LED white [≈W16W] for your reverse and rear fog lights. They are bright and look good so you can signal safely and stylishly.

### Superior visibility for safer driving

- Instant safety information for other drivers

### Long-lasting performance

- Durable, long-lasting LED lighting

### Simple plug-and-play replacement

- Easy to install and compatible with most vehicles
- Easy to install on your vehicle

### Bright LED lights

- Signal your intent with brighter exterior lighting

### Good light distribution

- Optimised for enhanced visibility

# PHILIPS

## Signalling bulb

LED-White [W16W] Number of bulbs: 1, 12 V, 6000 K, daylight effect, Advanced automotive system

# Specifications

### Marketing specifications

- Expected benefits: Transform your lights
- Product highlight: High brightness, Polarity-free, Easy to install

### Product description

- Application: Rear fog and reverse lights
- Base: W21x9.5d
- Designation: LED-White [W16W]
- ECE certification: NO
- Range: Ultinon Pro3100
- Technology: LED
- Type: LED-White [W16W]

### Lifetime

- Life time: 3000 hrs

### Light characteristics

- Lumens: 160
- Colour temperature: 6000K

### Electrical characteristics

- Wattage: 1.8 W
- Voltage: 12 V

### Ordering information

- Order entry: 11067CU31B1
- Ordering code: 02204230

### Packaging Data

- EAN1: 8719018022042
- EAN3: 8719018022059
- Packaging type: B2

### Packed product information

- Length: 9.5 cm
- Width: 1.5 cm
- Height: 13.5 cm
- Pack Quantity: 2
- MOQ (for professionals): 10

### Outer pack information

- Length: 14.2 cm
- Width: 12.1 cm
- Height: 10.3 cm
- Gross weight per piece: 0.49 kg

11067CU31B1/10

# Highlights

### Bright and vibrant signals

Signalling the intended movement of your vehicle is vital to your safety. To avoid collisions, other people need to know what you're doing, whether it's reversing, manoeuvring, turning or stopping. And when poor weather reduces visibility, bright and vibrant signalling is even more crucial. Philips Ultinon Pro3100 signalling lights give you the performance you need: as reversing lights, they illuminate the area immediately behind your car or motorcycle (the more you can see, the safer you'll be); as rear fog lights, they give other drivers vital extra time to react to your movements.

### Good light distribution

The Philips Ultinon Pro3000 LED exterior lighting range is designed for smarter light distribution to project exterior signalling light where you need it (whether that's reversing, stopping or signalling). With wide-angle, uniform light, not only can you see more of the road, but other drivers can also see more of you.

### Long-lasting LED lighting

You want bright and stylish lights, but you don't want to keep replacing failed lamps. That's a major weakness of conventional signal lights - the more powerful the light, the shorter its lifespan. At the same light intensity, LEDs last much longer. Philips Ultinon Pro3100 LED lights are extremely durable with their lifetime of 3,000 hours which is up to 4 times the lifespan of conventional W16W signalling bulbs (Philips W16W 12V). Replacing your conventional W16W with Philips Ultinon Pro3100 LED lights will avoid multiple replacements in the future to save you money and time.

### Ready, steady, installed!

Enjoy the plug-and-play experience: the Philips Ultinon Pro3100 comes with standard caps so replacement is easy and quick.

### Polarity-free design

Enjoy the plug-and-play experience: the Philips Ultinon Pro3100 comes with polarity-free design, so you don't need to worry about the polarity during installation. It will save you time and make installation easier.

### Instant-on technology

Compared to incandescent lamps, Philips Ultinon Pro3100 LEDs light up instantly to ensure that other drivers can react faster, keeping you safer.



Issue date 2023-10-12

Version: 2.0.1

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* It is your own responsibility to ensure that the use of the LED retrofit lights complies with applicable local legal requirements.