



Philips Xperion 6000
Line

300 lm Boost / 150 lm Eco

120 lm Spotlight
Battery life: 4,5h (Eco: 8h)
Durable with broad light beam



X60LINEX1

Designed with you in mind

Advanced lighting performance that lasts

Designed with a 110° broad beam of 150 lm in Eco and 300 lm in Boost mode, the Philips Xperion 6000 Line is ideal for lighting up larger areas. It is equipped with a 120 lm torch beam to direct the light where it is needed.

Extended warranty

- Extend your warranty online to 3 years

Handles tough conditions easily

- Resistant to impacts, water and solvents (IP65/IK07)

Smart, ergonomic design

- Smart rotatable hook with magnet and ergonomic body
- Precision light with wide beam angle

See where others can't

- Long running time in different light modes
- Premium LED light with multiple outputs

PHILIPS

Line

300 lm Boost / 150 lm Eco 120 lm Spotlight, Battery life: 4,5h (Eco: 8h), Durable with broad light beam

X60LINEX1/10

Highlights

Multiple light modes



The Philips Xperion 6000 Line produces bright natural LED white light to maximize visual comfort and reduce eye strain for fatigue-free work. The main beam on the Philips Xperion 6000 Line offers two output levels: 150 lm in Eco mode with extended battery life and 300 lm in Boost mode. This flexibility allows you to choose the right amount of brightness for the job at hand.

Light modes for multiple needs



The Philips Xperion 6000 Line is designed to be ready for action. A single charge provides enough energy for a full day's work: up to 8 hours in Eco mode, 4,5 hours in Boost mode, and 9 hours with the torch beam. Powered by

a powerful Li-ion battery, the Xperion 6000 Line can be fully charged within 3,5 hours via USB-C, ensuring maximum usage of its bright LED light.

Illuminate your work



The Philips Xperion 6000 Line features a 110° beam-angle light module ensuring broader illumination of your work area.

Enables hands-free working



Designed with you in mind, the ergonomically shaped handle with anti-slip coating allows you to hold this work light securely. If you need both hands free for work, position the light securely thanks to the 360° rotatable, retractable hook and a strong magnet. The

power button is located on the back to ensure the light does not glare directly at your eyes when you turn it on.

Designed for resistance



Designed to handle tough work environments with IK07 shock resistance, water-resistant to IP65 standards, and a surface that withstands chemicals and workshop solvents, the Philips Xperion 6000 Line is built to last because we know that even the steadiest hands need the extra support.

Up to 3 years warranty



Benefit from Philips standard 2-year warranty plus 1 additional year¹

Specifications

Marketing specifications

- Product highlight: Durable with broad light beam
- Expected benefits: Designed with you in mind

Product description

- Hands free options: Rotatable hook, strong magnet
- Hook: 360° rotatable
- Impact protection rating (IK): IK07
- Magnet: 1 magnet
- Materials & finishing: Robust ABS
- Operating Temperature: -10°C to 40°C
- Range: Xperion 6000
- Technology: SMD LED
- UV leak detector: No
- Ingress protection rating (IP): IP65
- Resistant to: Grease, oil, workshop solvents

Light characteristics

- Beam angle: 110 degree
- Color temperature: 6000 K
- Beam angle (pointer): 40 degree
- Light output (pointer): 120 lumens
- Light output (eco): 150 lumens
- Light output (boost): 300 lumens

Electrical characteristics

- Voltage: 3.7 V
- Power source: Rechargeable battery
- Battery capacity: 2200 mAh

- Battery run time (boost): Up to 4,5 hours
- Battery run time (eco): Up to 8 hours
- Battery type: Lithium battery
- Plug type: EU plug (not included for UK)
- Charging cable type: Type C USB
- Battery charging time: Up to 3,5 hours
- Wattage: 3W
- Battery run time (Pointer): Up to 9 hours

Ordering information

- Order entry: X60LINEX1
- Ordering code: 01473331

Packaging Data

- EAN1: 8719018014733
- EAN3: 8719018014740

Packed product information

- Length: 5 cm
- Height: 31 cm
- Pack Quantity / MOQ: 6
- Weight with batteries: 382 g
- Cable length: 100cm USB cable, 5V 1A adaptor

Outerpack information

- Length: 33 cm
- Width: 23.5 cm
- Height: 12.5 cm



Issue date 2023-10-12

Version: 11.11.1

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* 1 to be claimed on the Philips extended-warranty webpage