



Philips Ultinon Drive 2000
7 inch round LED driving
light

Road-legal ECE R149 - 37,5

4200 lm, +390m beam length
LED position-light function
All terrain, all weather

LUMUD2001RX1

Boosted visibility brings safer driving

Extra brightness for everyday use

See far and wide with crisp, white light projected up to 390 meters. The Ultinon Drive 2001R LED driving light is 100% road-legal with a tough, one-piece design integrating advanced cooling tech. It shrugs off water, dust, rust and impacts.

Road-legal auxiliary lights

- Powerful road-legal LED driving light

Built to withstand difficult driving conditions

- Robust design for tough environments

Boosted visibility makes you safer on the road

- Extra brightness for superior visibility

Robust design for challenging conditions

- Corrosion-free body, stainless-steel mounting brackets

PHILIPS

7 inch round LED driving light

Road-legal ECE R149 - 37,5 4200 lm, +390m beam length, LED position-light function, All terrain, all weather

LUMUD2001RX1/10

Specifications

Product description

- Boost mode activation: No
- Break resistance
- ECE R10
- ECE R149
- ECE reference number: 37.5
- Impact protection rating (IK): IK07
- Ingress protection rating (IP): IP68 & IP69K
- Installation angle: 360°
- Material: Aluminum die-cast
- Number of LEDs: 40x 5W
- Offroad boost: No
- One-piece body design
- Operating temperature: -40° C to 80° C
- Range: Ultinon Drive 2000
- Scratch resistant lens
- Technology: LED
- Width: 180 mm / 7 inch
- Boost function installation: No
- corrosion-free brackets: Side mounting brackets
- ECE R148: n/a
- Parking position light
- Plug type: 2-pin DT Connector with 0.5m cable
- Heat sink: Aluminum powder coated die-cast
- Corrosion protection: Yes, aluminum powder coated

Light characteristics

- Color temperature: 6500 K K
- Beam length 1 lux-m: 390
- Effective lumen output: 4200 lumens
- Raw lumen output: 10000 lumens
- Beam pattern: Combo beam

Electrical characteristics

- Voltage: 9-30 Volt DC

Ordering information

- Order entry: UD2001RX1
- GOC: 01852633

Packaging Data

- EAN1: 8719018018526
- EAN3: 8719018018533

Packed product information

- MOQ (for professionals): 2
- Box dimensions-L(mm): 362
- Box dimensions-W(mm): 105
- Box dimensions-H(mm): 90
- Number of product in the box: 1 lamp

Highlights

Up to 390-meter visibility

The Philips Ultinon Drive 2001R gives you extra high-beam brightness to illuminate the road ahead for up to 390 meters*. Producing 4400 lumens (effective), our LED light bar complies with ECE-R149 and provides ample visibility ahead and at the road's edges for faster reactions. Its cool light color of 6500 Kelvin creates better contrast and keeps drivers focused.

Built for tough environments

The Philips Ultinon Drive 2001R is built to withstand tough conditions throughout your journey. It is shock-resistant (IK07-rated) to ensure faultless performance on and off the road, with an unbreakable polycarbonate lens. It can handle immersion in water and power washing (IP68 & IP69K-rated) to provide reliable illumination for your overland adventures, wherever your trail leads.

Corrosion-free brackets

The mounting brackets for the Philips Ultinon Drive 2001R are made of stainless steel, which is corrosion-free. They can withstand snow, ice and even salt. Built from durable, high-quality materials, your Philips auxiliary LED light will provide years of reliable service.

Road-legal LED light

The Philips Ultinon Drive 2001R meets ECE-R149 standards and is 100% road-legal for high-beam and position-light functions. For added safety, Philips LED driving lights are tested to EMC R10 specification to ensure they will function smoothly with your vehicle's electrical systems.



Issue date 2023-10-15

Version: 5.5.1

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Beam length measured on 1 lux.