

Philips Ultinon Drive 7000
20 inch LED light bar

Road-legal ECE R149 - 30+30
4000 lm, 480m beam, 520m boost
Offroad light boost
Heated de-icing lens

LUMUD7050LX1



Powerful brightness driving safety at the wheel

Bright, durable gear for overland journeys

The Philips Ultinon Drive 7050L LED light bar has the power to keep you safer, wherever you're headed. Spot hazards up to 520 meters away with lighting that performs in the most hostile environments and gives your vehicle a touch of style.

Designed to handle hostile environments

- Robust design for tough environments

Road-legal auxiliary lights

- Powerful road-legal LED lightbars

Easy to install with flexible mounting options

- Low-profile design for simpler fitment

Brilliance that makes you a safer driver

- Intense, far and wide illumination for superior visibility

Greater safety with powerful brightness

- Enhanced safety off-road with boost function for more power

PHILIPS

Specifications

Product description

- Boost mode activation
- Break resistance
- Corrosion-free brackets: Yes, included
- ECE R10
- ECE R149
- ECE reference number: 30+30
- Impact protection rating (IK): IK07
- Ingress protection rating (IP): IP68 & IP69K
- Installation angle: 360°
- Material: Aluminum extruded
- Offroad boost: No
- One-piece body design
- Operating temperature: -40° C to 80° C
- Range: Ultinon Drive 7000
- Scratch resistant lens
- Technology: LED
- Width: 573 mm / 20 inch
- Boost function installation
- Accessories (optional): LUMUD1001M, LUMUD1003W, LUMUD1004W
- corrosion-free brackets: Side mounting brackets
- ECE R148
- Parking position light: No
- Plug type: 4-pin DT Connector with 0.5m cable

Light characteristics

- Color temperature: 6500 K K

- Beam length 1 lux-m: 480
- Beam length 1 lux (boost)-m: 520
- Effective lumen output: 4000 lumens
- Raw lumen output: 19800 lumens
- Effective lumen output (boost): 5300 lumens

Electrical characteristics

- Voltage: 9-30 Volt DC

Ordering information

- Order entry: UD7050LX1
- GOC: 01848994

Packaging Data

- EAN1: 8719018018489
- EAN3: 8719018018496

Packed product information

- MOQ (for professionals): 4
- Box dimensions-L(mm): 865
- Box dimensions-W(mm): 90
- Box dimensions-H(mm): 90
- Number of product in the box: 1 lamp

Outerpack information

- Length: 880 cm
- Width: 20 cm
- Height: 20 cm

Highlights

Up to 480-meter visibility

The Philips Ultinon Drive 7050L LED light bar provides a brilliant light beam that illuminates the road ahead for up to 480 meters*. Its effective 4000 lumens are homogeneously distributed in an optimized indirect beam, generating intense illumination far and wide with reduced glare for everyday use. This enables drivers to react faster on dark, rural and dirt roads. Its cool light color of 6500 Kelvin produces daylight conditions, improving contrast and helping drivers stay focused.

Boost for extra off-road power

The Philips Ultinon Drive 7050L comes with two light functions. For on-road driving, our LED light bar brings you outstanding road-legal brightness and greater safety. Off-road, you can opt for increased intensity of 5300 lumen. Switch on the boost function to unleash full power and increase the beam length up to 520 meters. More performance for tougher conditions.

Heated de-icing lens

Winter can cause snow and ice build-up on your LED light bars, changing the beam pattern and endangering visibility. With the Philips Ultinon Drive UD7050L de-icing function, keep snow and ice off your lens for great lighting performance even in the worst weather conditions.

Road-legal lights

The Philips Ultinon Drive 7050L LED light bar meets ECE standards and is 100% road-legal for high-beam and position-light functions. It can be installed individually and centrally on vehicles, and still be ECE-compliant on high beam, thanks to its twin light-module design in a single bar.

Easy and flexible installation

The sleek, low-profile design makes installation easier, and flexible fitment options are possible with side-mounting brackets (included) and back-mounting brackets (UD1001M optional). Supplied with a pre-wired male/female 4-pin superseal DT connector, it is voltage-overload and reverse-polarity protected to make installation secure and easy.

Built for tough environments

The Philips Ultinon Drive 7050L LED light bar is built from durable, high-quality materials to withstand the toughest conditions. It is shock-resistant (IK07-rated) to ensure faultless performance on and off the road, with an unbreakable polycarbonate lens. It can handle immersion in water and the power washer you use to clean your car afterwards (IP69K-rated). Its anodised pre-treated and powder coated body offers ultimate corrosion protection, to withstand snow, ice and even salt. Philips Ultinon Drive will ensure durable light on your overland journey, wherever your trail leads.



Issue date 2023-10-15

Version: 3.3.1

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Beam length measured on 1 lux.