

Philips  
On tap water purifier

Micro X-Pure  
Digital

WP3822



## Pure water made easy

with Digital Pure Protect Alert

Compact and sophisticated water purifier that gives you safe pure water by removing bacteria, soluble lead, harmful organic compounds and chlorine with a Micro X-Pure filter. Its precise display tells you exactly when to replace the filter.

### Pure water

- Removes bacteria, soluble lead & harmful organic compounds

### Made easy

- Hi-flow with maximum rate of 2 liters per minute
- LCD display informs you when to replace the filter

### Simplicity

- Quick Fit tap adapters for easy installation on your tap
- Advanced Quick Twist mechanism for easy filter replacement

# PHILIPS

# Specifications

## Purification system

- Bacteria removal: 99.99 %
- Turbidity removal: 3000 liters or approx. 1 year
- VOC Removal
- Pesticides removal
- Chlorine removal: >75 %
- Hormones removal

## Design specifications

- Color(s): white and silver
- Materials: plastic
- Product weight: 390 g
- Product dimensions (L x W x H): 93 x 144 x 112 mm

## Filter specifications

- Filter lifetime: 1500 L or approx. 3 months
- Major filter components: hollow-fiber membrane, granular activated carbon GAC, ion exchange resin, pre-filter of sediments

## Input water conditions

- Min. input water pressure: 0.7 bar
- Max. input water pressure: 3.5 bar
- Max. input water temperature: 50 °C

## General specifications

- Replacement filter cartridge: WP3922
- Accessories: 8 QuickFit tap-mounting adapters, color coded PureProtect Alert
- Water selection: filtered spray, unfiltered spray, unfiltered stream
- Water flow rate: 1.6 l/min
- Water flow rate: 5 °C

## Sustainability

- Packaging: > 90% recycled materials
- User manual: 100% recycled paper

## Country of origin

- Water purifier: Japan
- Replacement filter: Japan

# Highlights

## Micro X-Clean filter

The Micro X-Clean is multi-filtration system. It consists of a hi-tech hollow-fibre membrane, which contains more than 300 billion micro-pores for the efficient removal of 99.99% of all bacteria, an ion exchanger to remove harmful soluble lead, a fine granular activated carbon to remove the harmful chlorination by-products, harmful industrial pollutants such as volatile organic chemicals, and agricultural pollutants such as the pesticide CAT. It also removes unpleasant chlorine, bad taste and odors. The filter preserves the good minerals in drinking water that are vital for human health.

## Electronic Pure Protect alert

The electronic flow meter of your water purifier shows in a LCD display the actual remaining filter capacity, in liters. A blinking signal is activated once the filter reaches its lifetime, warning you precisely when the filter needs replacing.

## Hi-flow

This compact water purifier has a maximum flow rate of 2 liters per minute, which makes little change to the normal flow rate of unfiltered water. By simply rotating the water selection lever, you also have a choice of either a stream or a spray of unfiltered water or spray of filtered water.

## Quick Fit tap adapters

This advanced water purifier comes with a number of tailor-made Quick Fit tap adapters, to help you having an easy and simple installation of your purifier in your tap. Real sense and simplicity.

## Quick Twist filter change

The advanced Quick Twist filter change mechanism makes changing the filter quick, easy and secure, bringing sense and simplicity to your water purifier.

