

Philips Wall charger

USB A and USB C charging ports

Power Delivery
QC 4+
PPS

DLP2682CW



Wall charger with 2 charging ports, USB-C and USB-A

65 W with QC 4+ and PD 3.0

Charge your laptop and latest devices from a USB-C port. Supports PD 3.0 and QC 4+ charging modules to minimise the charging time. USB-A port for charging your other devices simultaneously. Available with detachable EU, UK and AU plugs.

Superior Charging Design

- Smart protection against overheating, overvoltage and overcurrent
- 50% charge in 30 minutes
- Wall charger with GaN technology
- Charging using USB-C Programmable Power Supply (PPS)

Top Performance

- USB-C port with Power Delivery support

PHILIPS

Specifications

Packaging dimensions

- Packaging type: Box
- Number of products included: 1
- Packaging dimensions (W x H x D): 7.8 x 12.8 x 5.1 cm
- Packaging dimensions (W x H x D): 3.1 x 5.0 x 2.0 inch
- Gross weight: 0.215 kg
- Net weight: 0.185 kg
- Tare weight: 0.030 kg
- Gross weight: 0.474 lb
- Net weight: 0.408 lb
- Tare weight: 0.066 lb
- EAN: 48 95229 13265 8

Outer Carton

- Number of consumer packages: 36
- Outer carton (L x W x H): 34.3 x 25.3 x 35.5 cm
- Outer carton (L x W x H): 13.5 x 10.0 x 14.0 inch
- Gross weight: 8.99 kg
- Net weight: 6.660 kg
- Tare weight: 2.330 kg

- Gross weight: 19.819 lb
- Net weight: 14.683 lb
- Tare weight: 5.136 lb
- GTIN: 1 48 95229 13265 5

Power

- Adapter type: Detachable with UK, EU, AU socket
- Output: 65 W (Max)
- Power input: 100-240 V, 1.5 A 50/60 Hz

Inner Carton

- Number of consumer packages: 6
- Inner carton (L x W x H): 24.7 x 16.3 x 11.1 cm
- Inner carton (L x W x H): 9.7 x 6.4 x 4.4 inch
- Gross weight: 1.415 kg
- Net weight: 1.110 kg
- Tare weight: 0.305 kg
- Gross weight: 3.120 lb
- Net weight: 2.447 lb
- Tare weight: 0.673 lb
- GTIN: 2 48 95229 13265 2



Highlights

USB-C port with PD

USB-C is the latest charging connector standard, which is now adopted by mobile devices such as mobile phones, cameras and tablets. PD (Power delivery) is the USB standard for power delivery for more power and fast charging.

Smart Protection

Smart protection against overheating, overvoltage and overcurrent

Charger with GaN technology

Wall chargers that adopt GaN (Gallium Nitride) technology will use less electrical components with better heat performance. These compact chargers can provide more power with faster charging times, so they are capable of delivering power to modern laptops with USB-C connection.

50% charge in 30 min

Fast charging - charge your mobile phone from 0 to 50% in 30 minutes time.

Programmable Power Supply PPS

PPS (Programmable Power Supply) is a standard for fast charging technology for USB-C devices. This technology adjusts the voltage and current in real time, depending on a device's charging status, feeding it with maximum power. A smart way to safely reduce charging time.



Issue date 2023-03-22

Version: 1.3.2

12 NC: 8670 001 88376
EAN: 48 95229 13265 8

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com