



Philips
Surge protector

6 outlets
with Surge
2 USB

SPP6069D



Power your USB devices directly

Fast charging in 2.1A 10.5W

Home electronics surge protector features advanced technology to keep your equipment and devices safe from electrical surges/spikes. Features three AC outlets and two USB ports for charging USB devices.

Plug more

- Expands 1 grounded outlet into 6

Pure Protection

- 15 amp circuit breaker
- \$50,000 connected equipment warranty
- 600 Joules

Built-in convenience

- 3 ft power cord
- USB Charging 2.1
- 6 Outlets - 1 adapter spaced

PHILIPS

Surge protector
6 outlets with Surge, 2 USB

Specifications

Product dimensions

- Product dimensions (W x H x D):
1.7 x 11.8 x 1.1 inch
- Weight: 0.750 lb
- Product dimensions (W x H x D):
4.2 x 30 x 2.8 cm
- Weight: 0.34 kg

Packaging dimensions

- Packaging dimensions (W x H x D):
3.1 x 13.0 x 1.2 inch
- Nett weight: 0.750 lb
- Gross weight: 0.783 lb
- Tare weight: 0.033 lb
- UPC: 8 89446 00103 7
- Number of products included: 1
- Packaging type: Card

- Packaging dimensions (W x H x D): 8 x 33 x 3 cm
- Gross weight: 0.355 kg
- Nett weight: 0.34 kg
- Tare weight: 0.015 kg

Outer Carton

- Outer carton (L x W x H): 13.4 x 3.5 x 7.9 inch
- Gross weight: 5.798 lb
- Tare weight: 1.301 lb
- GTIN: 1 08 89446 00103 4
- Number of consumer packagings: 6
- Nett weight: 4.497 lb
- Gross weight: 2.63 kg
- Outer carton (L x W x H): 34 x 9 x 20 cm
- Nett weight: 2.04 kg
- Tare weight: 0.59 kg

SPP6069D/37

Highlights

15 amp circuit breaker

Safeguards against overburdening the surge protector by sensing when the connected equipment is drawing more electricity than the surge protector can handle. It then disconnects from the power, guarding against electrical fires.

1 grounded outlet into 6

A power multiplier that expands 1 grounded outlet in to 6 grounded outlets by plugging directly into the wall

\$50,000 CEW

Protects your connected equipment for the life of the product.

3 ft power cord

Provides power to the unit which can be 3 feet from the AC outlet.

USB Charging 2.1

USB Charging ports rated at 2.1 amps enable you to charge your mobile devices-compatible with smart phones, iPOD, iPhone, and iPad

600 Joules

Prevent thousand of dollars of damage of your electronic devices

6 Outlets - 1 adapter spaced

6 Outlets - 1 adapter spaced outlet that allows you to plug in an oversized adapter plug without blocking other outlets.



Issue date 2018-01-13

Version: 1.3.5

12 NC: 8670 001 27566
UPC: 8 89446 00103 7

© 2018 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com