



Philips
docking station for iPod/
iPhone

- App-enhanced
- 20 W

AJ7034D



Wake up to great sound from your iPod/iPhone

Start your day with this Philips Docking system. It offers Bass Reflex Speaker System for deep powerful bass, 20 W RMS output and a dock that takes any iPod/iPhone. Also enjoy enhanced waking and radio experiences via the free Philips App.

Enrich your sound experience

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Dock any iPod/iPhone, even in its case
- FM digital tuning with presets
- MP3 Link for portable music playback
- 20 W RMS total output power

Easy to use

- Free HomeStudio app for enhanced wake-up and radio experiences
- Auto clock synchronisation with iPod/iPhone when docked
- Time and alarm backup to wake up on time even with power cut
- Adjustable alarm volume for reliable wake-up calls

Start the day your way

- Wake up to your iPod/ iPhone music or radio tunes
- Dual alarm to wake you and your partner at different times
- Gentle wake for a pleasant waking experience

PHILIPS

Highlights

Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimise the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by causing the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a completely new dimension of deep bass.

Dock iPod/iPhone in its case



Smartly designed spring-loaded docking port effortlessly accommodates any iPod or iPhone, without special adapters. What's more, it

works even when most protective cases are on – just dock your iPod or iPhone as it is. Now you can truly have fuss-free enjoyment of your music.

FM digital tuning with presets



Digital FM radio offers you additional music options to your music collection on your Philips audio system. Simply tune into the station that you want to preset, press and hold the preset button to memorise the frequency. With preset radio stations that can be stored, you can quickly access your favourite radio station without having to manually tune the frequencies each time.

Free HomeStudio app



There's no better way to wake up or listen to the radio than with the free Philips HomeStudio app. Simply download the app

from the Apple App Store to enjoy a host of exciting features. Advanced alarm set up, for example, gives you greater flexibility in alarm settings - including alarm volume, duration, date and sound. You also get better user interface when you listen to the radio, with easy-to-use station preset functions.

Adjustable alarm volume



Philips clock radios let you rise and shine the way you want to. An adjustable alarm volume allows you to set the loudness of your wake up call. Whether you need a louder alarm to get out of bed on time, or prefer a softer alarm for gentle rousing, the adjustable volume gives you the flexibility to start the day your way.



Specifications

iPod compatibility

- Compatible with: iPod touch, iPod touch 2nd Generation, iPod touch 2nd Gen 8/16/32 GB, iPod touch 4th generation, iPod classic, iPod nano 1st Generation, iPod nano 2nd Generation, iPod nano 3rd Generation, iPod nano 4th Generation, iPod nano 5th Generation, iPod nano 6th generation, iPod 5th Generation, iPod mini

iPhone compatibility

- Compatible with: iPhone, iPhone 3G, iPhone 3GS, iPhone 4, iPhone 4S

iPod/iPhone App

- App name: HomeStudio, Free download from App store
- Compatibility: Dock radio for iPod/iPhone, iPod Touch, iPhone
- 5-day weather forecast
- Playback: album/track navigation, playback controls
- Clock: analogue display, digital display
- Alarm: multiple alarms, sleep timer
- Radio: FM radio, preset, scan, tune

Audio Playback

- Cradle playback mode: Charging iPhone, Charging iPod, Fast forward and reverse, Next and Previous track, Play and Pause

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- Station presets: 20
- Antenna: FM Antenna

Convenience

- Clock/Version: Digital

- Alarms: Dual alarm time, Buzzer Alarm, Radio Alarm, Repeat alarm (snooze)
- User convenience: Sleep Timer
- Backlight colour: Amber
- Display Type: LED

Sound

- Output power (RMS): 20 W
- Sound System: Stereo
- Volume Control: rotary

Loudspeakers

- Built-in speakers: 2
- Main Speaker: Bass Reflex Speaker System

Connectivity

- MP3-Link: Yes, 3.5 mm jack

Power

- Mains power
- Power supply: 100-240 V, 47-63 Hz

Dimensions

- Product dimensions (WxDxH): 283 x 112 x 118 mm
- Weight: 1.36 kg
- Packaging dimensions (WxDxH): 319 x 144 x 180 mm
- Weight incl. Packaging: 1.73 kg
- Master carton dimensions: (WxDxH) 298 x 327 x 375 mm
- Master carton weight: 7.55 kg
- Master carton quantity: 4

Accessories

- Included accessories: Warranty certificate, Quick Use Guide



Issue date 2013-06-08

Version: 3.0.5

12 NC: 8670 000 84821
EAN: 87 12581 62601 3

© 2013 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com