

Philips
Micro music system

- Dock for iPod/iPhone/iPad
- DAB+

DCB2070



Sound that fits your home

Obsessed with sound

Dock and listen to your iPod/iPhone/iPad, or turn on the radio and get crystal-clear DAB+. This Philips DCB2070/10 micro sound system sounds sensational, and offers an added bonus - it looks great in any home.

Enrich your sound experience

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 20W RMS total output power

Enjoy your music from multiple sources

- Play and charge your iPod/iPhone/iPad
- DAB and FM compatible for a complete radio experience
- Play MP3/WMA-CD, CD and CD-RW
- USB Direct for MP3/WMA music playback
- MP3 Link for portable music playback
- Radio Data System for station information and data services

Design that blends into your interior

- Wall-mountable option for flexible placement
- Motorized sliding front door adding style and elegance

PHILIPS

Highlights

Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen

music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Play & charge iPod/iPhone/iPad



Enjoy your favorite MP3 music while charging your iPod/iPhone/iPad! The dock lets you connect your portable device directly to the Philips system so you can listen to your favorite music in superb sound. It also charges

your iPod/iPhone/iPad while it plays so you can enjoy your music and not have to worry about your portable player battery running out. The system automatically charges your portable device while it is docked.

DAB and FM compatible



DAB (Digital Audio Broadcasting) digital radio is, on top of FM analog transmission, a new way of broadcasting radio via a network of terrestrial transmitters. It provides listeners with more choices and information delivered in clear, crackle-free sound quality. The technology allows the receiver to lock on to the strongest signal it can be find. With DAB digital stations there are no frequencies to remember, and sets are tuned by station name, so there is no returning on the move.

USB Direct



With the USB Direct mode, simply plug in your USB device to the USB port on your Philips device and your digital music will be played directly from the Philips device.



Specifications

Sound

- Output power: 2 x 10 W RMS
- Sound enhancement: digital sound control, Dynamic Bass Boost
- Volume control: up/down

Loudspeakers

- No. of built-in speakers: 2
- Speaker drivers: 2.75" woofer
- Speaker types: bass reflex speaker system

Audio playback

- Disc playback modes: fast forward/backward, next/previous track search, repeat/shuffle/program
- Playback media: CD, CD-R/RW, MP3-CD, USB flash drive, WMA-CD
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, repeat, shuffle, stop
- Docking playback modes: fast forward and backward, menu, up and down, next and previous track, play and pause
- Others: ID3-tag support

Tuner/Reception/Transmission

- Tuner bands: FM mono, FM stereo
- Station presets: 20
- RDS: program type, radio text, RDS clock set, station name
- Tuner enhancement: auto digital tuning, auto scan, Easy set (plug & play)
- DAB/DAB+: Info display, Menu, Smart scan

Connectivity

- Headphone: 3.5 mm
- MP3 Link: 3.5mm stereo line in
- USB: USB host

Convenience

- Alarms: CD Alarm, Radio Alarm, USB alarm, iPod

Alarm

- Clock: On main display, sleep timer
- Charging device: iPad, iPhone, iPod
- Display type: LCD display
- Loader type: front, motorised

Accessories

- Included accessories: 3.5mm stereo line in cable, AC-DC Adapter, DAB antenna, Quick Use Guide, Screws for wall mounting x2
- Remote control: 31-key remote
- User Manual: English, German, French, Danish, Norwegian, Italian

Dimensions

- Set dimensions (W x D): 400 x 98 mm
- Set height (with stand): 235 mm
- Packaging width: 456 mm
- Packaging height: 251 mm
- Packaging depth: 197 mm
- Gross weight: 4.2 kg
- Net weight: 3.3 kg

Power

- Power supply: 110-240V, 50/60 Hz

iPod compatibility

- Compatible with: iPod nano 2nd Generation, iPod nano 3rd Generation, iPod nano 4th Generation, iPod nano 5th Generation, iPod nano 6th generation, iPod touch, iPod touch 2nd Generation, iPod touch 3rd generation, iPod touch 4th generation

iPhone compatibility

- Compatible with: iPhone, iPhone 3G, iPhone 3GS, iPhone 4

iPad compatibility

- Compatible with: iPad, iPad 2



Issue date 2013-05-10

Version: 2.4.7

12 NC: 8670 000 79028
EAN: 87 12581 61088 3

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com