



Philips
Micro music system

Bluetooth
CD, MP3-CD, USB, FM
15 W max

BTB2515

Ready for the sounds you love

Hear more from your playlists and podcasts. Rediscover your CD collection. Connect almost any source via USB or audio-in. This classic micro system gives you all the music you need and looks great too.

At home in your home

- 2-way bass-reflex loudspeakers. Richer low tones
- 3" woofer and dome tweeter
- 15 W maximum output power
- Digital Sound Control. Choose a preset sound style

All your music

- CD player. DAB+/FM digital radio
- Digital tuning with up to 20 presets
- Bluetooth wireless music streaming
- USB. Instantly connect music devices. Charge smart devices
- Audio-in. Connect to almost any source

Fill the room with tunes

- Mains-powered (AC-in). Remote control
- Main unit dimensions: 220 x 104 x 242 mm
- Speaker dimensions: 150 x 238 x 125 mm

PHILIPS

Highlights

All your music

This smart, compact music system lets you stream playlists and more with rich, room-filling sound. Dust off the classics in your CD collection thanks to a CD player that also plays MP3 CDs and recorded CDs. The digital radio tuner delivers crystal-clear reception and you can set up to 20 presets for your favourite DAB+ or FM stations.

Rich sound with good bass

The bookshelf-style loudspeakers give you crisp high ends from dome tweeters and good bass from 3" woofers and bass-reflex ports. 15 W maximum output brings decent sound to

smaller spaces: perfect for a home office, kitchen or student bedroom.

Old school, meet new school

The two-tone central unit and speaker cabinets recall the design of hi-fi separates. The textured volume-control dial adds a satisfying analogue feel to operation. There are buttons on top of the unit for pairing, source selection and playback/tuning control.

Digital Sound Control

Hip-hop or choral, symphony or rock opera? Whatever you love, this micro system's Digital

Sound Control function lets you enjoy it more. Pick from preset sound styles designed to bring out the best in your music.

At home in your home

This AC-powered micro system looks great in any room. The Bluetooth wireless range is 10 m, and you can charge a smart device via the USB port when the system is in standby mode. An easy-to-use remote puts key system functions at your fingertips—so you can control the mood without breaking the mood.

Specifications

Audio playback

- Disc playback modes: fast forward/reverse, next/previous track search, repeat/shuffle/programme
- Playback media: CD, CD-R/RW, MP3-CD, USB flash drive
- USB Direct playback modes: fast reverse/fast forward, play/pause, previous/next, stop, repeat, shuffle, programme play
- Bluetooth: Play/Pause, Previous/Next

Tuner/Reception/Transmission

- Tuner bands: FM stereo
- Station presets: 20 FM, 20 DAB
- Antenna: FM antenna (75 ohm)
- Tuner enhancement: auto digital tuning, auto scan
- DAB/DAB+: Info display, Smart scan

Connectivity

- Audio in (3.5 mm)
- Bluetooth
- Bluetooth profiles: A2DP, AVRCP
- USB: USB host, Max. 2A Charging

Sound

- Sound enhancement: digital sound control
- Maximum output power (RMS): 15 W

Loudspeakers

- Speaker drivers: 3" woofer
- Speaker types: bass reflex speaker system

Convenience

- Alarms: CD Alarm, Radio Alarm, USB alarm
- Clock: On main display, sleep timer
- Display type: LED display
- Loader type: tray

Accessories

- Remote control: 21-key remote
- Included accessories: DAB antenna
- Quick start guide

Power

- Power supply: 50 Hz, 100-240 VAC, 50/60 Hz

Dimensions

- Main unit width: 220 mm
- Main unit height: 104 mm
- Main unit depth: 242 mm
- Main speaker dimensions (W x H x D):
150 x 238 x 125 mm
- Packaging width: 646 mm
- Packaging height: 343 mm
- Packaging depth: 220 mm
- Gross weight: 5.8 kg
- Net weight: 3.8 kg



Issue date 2022-05-12

Version: 3.0.7

12 NC: 8670 001 46785
EAN: 69 59033 84806 3

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com