

Philips Weather Clock Radio

A|260

Personal weather forecaster

with wireless outdoor temperature sensor

Start your day the right way - every day! The compact AJ260 features a radio-controlled clock and graphical weather forecast icons with multi-colour light indicators. Your trusty weather forecaster also keeps you punctual - always.

Stylish design with all the functions you need

- Display weather forecast with graphical animations
- · Multi-colour light weather indicator
- Temperature display for both indoor and outdoor temperature
- Built-in hygrometer displays indoor humidity
- · Digital tuning with preset stations for extra convenience

Start the day your way

- Wake up to your favourite radio tune or a buzzer
- · Gentle wake for a pleasant waking experience
- Dual alarm time

Keeps you punctual - always

- Digital radio-controlled clock for accurate time settings
- Large backlit LCD display for easy viewing in low light



Highlights

Radio-controlled clock

Radio-controlled clock automatically synchronises with the local radio broadcast's standard time, so you never need to worry about checking for accuracy or making adjustments. Accurate time without latency is ensured daily or while the clock's power is on. Rest assured you'll always be punctual for every appointment!

Digital tuning with presets

Simply tune into the station that you want to preset, then press and hold the preset button

to memorise the frequency. With preset radio stations that can be stored, you can quickly access your favourite radio station without having to manually tune the frequencies each time.

Gentle wake

Start your day the right way by waking up gently to a gradually increasing alarm volume. Normal alarm sounds with a pre-set volume are either too low to wake you up or are so uncomfortably loud that you are rudely jolted awake. Choose to wake up to your favourite

music, radio station or buzzer alarm. Gentle wake's alarm volume gradually increases from subtly low to reasonably high in order to gently rouse you.

Large backlit LCD display

Backlit LCD display ensures easy viewing and operation in low light conditions, and provides clear information at a glance.

















Specifications

Weather Forecast

- Status: Sunny, Cloudy, Partly cloudy, Rainy, Stormy, Snow
- Light indicator: Amber (Sunny), Blue (Cloudy), Light blue (Partly cloudy), Purple (Rainy), Red (Stormy), White (Snow)

Indoor Thermometer

- Temperature range: -20°C to 70°C
- Temperature resolution: 0.1°C

Outdoor Thermometer

- Wireless transmission: 50 metre (Open area)
- RF transmission frequency: 433 MHz
- Temperature range: -20°C to 70°C
- Temperature resolution: 0.1°C

Indoor Hygrometer

- Relative humidity range: 20% to 90% RH
- Humidity resolution: 1% RH

Tuner/Reception/Transmission

- Tuner Bands: FM
- · Auto digital tuning
- Station presets: 10

Convenience

- Radio-controlled clock: Synchro time with the radio signal MSF60 generated from Rugby, England
- Alarms: Dual alarm time, 24-hour alarm reset, Radio Alarm, Buzzer Alarm, Gentle Wake, Repeat

alarm (snooze), Sleep timer

- Backlight
- · Backlight colour: White
- Clock/Version: Digital
- Display Enhancements: Brightness Control
- Display Type: LCD

Sound

- Output power (RMS): 80 mW
- Sound System: Mono
- Speaker diameter: 2.5"
- Volume Control: rotary

Accessories

Included accessories: User Manual, Warranty certificate, AC-DC Adapter

Dimensions

- Packaging dimensions (W x H x D): 288 x 140 x 80 mm
- Product dimensions (W \times H \times D): 169 \times 105 \times 43 mm
- Weight: 0.4 kg
- Weight incl. Packaging: 0.55 kg

Power

- Battery type: AAA/LR03 Alkaline
- Battery voltage: 1.5 V
- Mains power
- Number of batteries: 4



Issue date 2013-01-10

Version: 2.0.10

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 31336 EAN: 87 12581 34445 0

www.philips.com