

Philips  
CD Soundmachine

VCD

AZ2536



## Ultimate Entertainment Experience

with VCD playback and Karaoke

Maximize your entertainment experience with the assertive AZ2536! With an awesome mix of VCD playback and powerful Max Sound, you can totally immerse in music, movies and karaoke – and never leave your room!

### **Share your movie and Karaoke experiences**

- Video CD2.0 playback with powerful playback control function
- Karaoke for endless singing entertainment
- PAL/NTSC compatible

### **Powerful sound you can hear and feel**

- MAX Sound for instant power boost
- Bass Reflex Speaker System delivers a powerful, deeper bass

### **Enjoy favorite music from three different sources**

- MP3-CD, CD-R/RW compatible
- Digital tuning with preset stations for extra convenience
- Autostop cassette deck

**PHILIPS**  
sense and simplicity

# Specifications

## Sound

- Equalizer: 3-bands
- Loudspeaker types: Bass Reflex Speaker System
- Output power (RMS): 2X4W
- Sound Enhancement: MAX Sound, Treble and Bass Control
- Sound System: Stereo
- Speaker diameter: 4"
- Volume Control: Volume Control rotary/encoder

## Loudspeakers

- Built-in speakers: 2
- Finishing: Metal
- Loudspeaker Enhancement: Max BASS Port
- Loudspeaker types: Loudspeakers

## Video Playback

- Disc Playback Modes: A-B Repeat, Fast Backward, Fast Forward, Introsan, OSD, Pause, PBC, Slow Motion, Zoom

## Audio Playback

- Cassette Deck Technology: Mechanical
- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Loader Type: Top
- Number of decks: 1
- Programmable Tracks: 20

## Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: CD Synchro Start Recording

## Tuner/Reception/Transmission

- Antenna: AM Antenna, FM Antenna
- Auto digital tuning
- Tuner Bands: FM, MW

## Connectivity

- Audio output: Stereo Audio (3.5 mm jack) 1x
- Aux in: Karaoke
- Headphone: 3.5 mm
- Video Output - Analog: Video (3.5mm jack) 1x

## Convenience

- Backlight
- Backlight color: Amber
- Display Digits: 7
- Display Type: LCD

## Accessories

- Included accessories: AC Power Cord, Audio/Video cable, User Manual, Warranty certificate

## Dimensions

- Packaging dimensions (W x H x D): 560 x 236 x 348 mm
- Product dimensions (W x H x D): 520 x 178 x 287 mm
- Weight: 4.1 kg
- Weight incl. Packaging: 6.1 kg

## Power

- Battery type: LR20
- Battery voltage: 1.5 V
- Mains power
- Number of batteries: 8

# Highlights

## Video CD2.0 playback

Video CD2.0 playback with powerful playback control function

## Karaoke

The Karaoke feature on your DVD player provides endless entertainment and maximum audio and singing enjoyment. You can enhance your performance by adding an 'echo' effect to your voice. The key controls allow you to choose the optimal key for your personal vocal range.

## PAL/NTSC compatible

PAL/NTSC compatible

## MAX Sound

MAX Sound technology produces an instant boost in bass, maximizing volume performance and instantly creating the most impressive listening experience with just the touch of a button. Its sophisticated electronic circuitry calibrates existing sound and volume settings, instantly boosting bass and volume to maximum levels without distortion. The end result is a noticeable amplifying of both sound spectrum and volume and a potent audio boost that will add mileage to any music.

## Bass Reflex Speaker System

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

## MP3-CD, CD-R/RW compatible

MP3-CD, CD-R/RW compatible

## Digital tuning with presets

Simply tune into the station that you want to preset, press and hold the preset button to memorize the frequency. With preset radio stations that can be stored, you can quickly access your favorite radio station without having to manually tune the frequencies each time.

## Autostop cassette deck

Autostop cassette deck



Issue date 2011-07-21

Version: 5.0.8

12 NC: 9073 101 01318  
EAN: 87 10895 82332 6

© 2011 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)