

Philips
DVD Player/Recorder

DVDR3305



VIDEO Plus+



Recording made easy

Record your favourite TV programmes in perfect digital quality.

TV Recording made simple!

- VPS/ PDC records a TV program precisely from start to end
- VIDEO Plus+ for quick and easy programming
- Record up to 6 hours on a single layer DVD+R/RW or DVD-R/RW
- Dual Media records on both DVD+R/RW and DVD-R/RW

Plays it all

- Music: CD, CD-R/RW and MP3-CD
- Movies: DVD, DVD+R/RW, DVD-R/RW, (S)VCD
- Photos (JPEG) with musical slideshow

PHILIPS
sense and simplicity

Specifications

Picture/Display

- **Aspect ratio:** 4:3, 16:9
- **D/A converter:** 10 bit, 54 MHz
- **A/D converter:** 10 bit, 54 MHz

Sound

- **D/A converter:** 24 bit, 96 kHz
- **A/D converter:** 24 bit, 96 kHz
- **Signal to noise ratio:** 105
- **Distortion and Noise (1kHz):** 90 dB
- **Crosstalk (1kHz):** 105 dB
- **Dynamic Range (1kHz):** 90 dB
- **Sound System:** Dolby Digital, DTS, Dolby Digital (AC-3)

Video Recording

- **Recording system:** PAL, SECAM
- **Compression formats:** MPEG2
- **Recording Modes:** Super Long Play (SLP), Extended Play (EP), High Quality (HQ), Standard Play (SP)
- **Audio compression:** Dolby Digital
- **Max recording time on DVD:** 6 hr
- **Recording enhancements:** Chapter Marker Insertion, Divide, Erase, Manual Chapter Marking, One Touch Record (OTR), Safe Record, Selectable Index Pictures

Video Playback

- **Playback Media:** DVD-Video, DVD, DVD+RW, DVD+R, DVD-RW (Video mode), DVD-R, SVCD, Video CD
- **Compression formats:** MPEG2, MPEG I
- **Video disc playback system:** NTSC, PAL
- **Disc Playback Modes:** A-B Repeat, Disc Menu, Fast Backward, Fast Forward, Framestep forward, Pause, PBC, Resume Playback from Stop, Search forward/reverse, Shuffle Play, Slow Motion, Title repeat, Zoom

Audio Playback

- **Playback Media:** MP3-CD, CD, CD-R, CD-RW, MP3-DVD
- **Compression format:** Dolby Digital, MP3, MPEG2 Multichannel, PCM, DTS
- **MP3 bit rates:** 32-256 kbps and VBR
- **File systems supported:** ISO-9660

Still Picture Playback

- **Playback Media:** DVD+R/+RW, DVD-R/-RW, CD-R/RW, Picture CD
- **Picture compression format:** JPEG
- **Picture enhancement:** Rotate, Zoom
- **Slide show:** yes, with music (MP3)

Storage Media

- **Recording media:** DVD+R, DVD+RW, DVD-R, DVD-RW

Tuner/Reception/Transmission

- **TV system:** PAL I
- **Aerial Input:** 75 ohm coaxial (IEC75)
- **Number of TV tuners:** 1
- **Auto digital tuning:** no

Connectivity

- **Front / Side connections:** Audio L/R in, CVBS in, S-video in
- **Rear Connections:** SCART I (CVBS, S-video/RGB out), SCART2 (CVBS, S-video/RGB in), Analogue audio Left/Right out, S-Video/CVBS video output, Digital coaxial out, RF antenna in / TV out

Convenience

- **Programming/Timer Enhancements:** Daily/Weekly Repeat Program, Manual Timer, One Touch Recording, VIDEO Plus+, VPS/PDC recording control
- **Programmable Events:** 8
- **Programming period:** 1 month
- **Child Protection:** Parental Control
- **Display Type:** FTD
- **On-Screen Display languages:** Danish, Dutch, English, Finnish, French, German, Italian, Norwegian, Portuguese, Spanish, Swedish

Power

- **Power supply:** 50Hz, 220-240V
- **Consumption:** 25 W (Typical)
- **Standby power consumption:** < 3 W

Accessories

- **Remote control:** 37-key Zappa (2422 549 0061 I)
- Quick start guide
- Warranty Card
- **Batteries:** 2 x AA
- **Cables:** Full SCART cable, Coax RF cable
- **Guarantee booklet:** Global version
- User Manual

Dimensions

- **Set dimensions (W x H x D):** 435 x 65 x 285 mm
- **Set weight:** 4 kg
- **Packaging dimensions (W x H x D):** 514 x 155 x 380 mm
- **Weight incl. Packaging:** 6 kg

Product highlights

VIDEO Plus+

With the VIDEO Plus+ system, all you need to do to program your video recorder is to enter the 'Pluscode' – a single code of up to nine digits (but usually less) that is printed next to each TV program in most TV guides.

VPS/ PDC

With 'VPS' (Video Programming System) and 'PDC' (Program Delivery Control), the TV station controls the beginning and the length of the programmed recording. This means that your recording device switches itself on and off at the right time even if a TV program you have programmed begins earlier or finishes later than expected.

6 hours video recording

The 6-hour record mode available on specific DVD recorder models lets you record up to six hours of video on a single layer DVD+R/RW and DVD-R/RW discs.

Dual Media

Philips DVD Recorders support 'dual media' recording - the ability to create recordings on DVD+R/RW and DVD-R/RW discs. Now you can buy any disc and the Philips recorder will always create fully compatible recordings, which can be played by any DVD player.

Multi-format Movies

Multi format playability allows you to play most disc formats for maximum disc compatibility and viewing pleasure.

Multi-format Music

Multi format playability allows you to play most disc formats for maximum disc compatibility and listening pleasure.

Photos with musical slideshow

Make sharing photos with family and friends more fun! Run a photo slideshow with music playing in the background. This Philips product supports simultaneous playback of JPEG pictures and MP3 music. Make sure the files for the musical slideshow are stored in the same media. Select your favourite MP3 music and start a slideshow of JPEG pictures.



Issue date 2007-12-07

Version: 12.0

12 NC: 8622 810 12455
EAN: 87 10895 88682 6

© 2007 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com