

Philips  
DVD Micro Theater



MCD139B

## Enjoy great movie experience

Enjoy your favorite movies with The Philips MCD139B. Featuring Progressive Scan for optimized image quality and Dynamic Bass Boost for powerful sound output, you can now enjoy cinematic experience right at your home!

### Enjoy your favorite movies, photos and music

- Play DVD, (S)VCD, MP3-CD, WMA-CD, CD(RW) & Picture CD
- Dolby Digital for ultimate movie experience
- Progressive Scan component video for optimized image quality

### Enrich your sound experience

- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- Total 100W RMS

### Start the day your way

- Digital tuning with 40 preset stations for extra convenience
- Wake up and sleep timer functions

# PHILIPS

# Highlights

## Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

## Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



# Specifications

## Sound

- Output Power: 2x25W + 50W RMS / 1800W PMPO
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost
- Sound System: Dolby Digital

## Loudspeakers

- Main Speaker: 3" woofer
- Subwoofer type: Passive

## Video Playback

- Playback Media: DVD+RW, DVD-Video, Picture CD, Video CD/SVCD
- Disc Playback Modes: A-B Repeat, Angle, PBC, Slow Motion, Zoom, Parental control, OSD, Resume Playback from Stop
- DVD Region.: 4
- Video Enhancement: Progressive Scan

## Audio Playback

- Playback Media: WMA-CD, MP3-CD, CD, CD-R, CD-RW
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- Loader Type: Top

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- Station presets: 40

## Connectivity

- Video Output - Analog: Component Y Pb Pr (cinch), Composite CVBS (yellow cinch), S-Video (on Hosiden)
- Aux in: 1x(L/R)/ RCA
- Other connections: Digital audio coaxial out, FM Antenna, Line out, DIN connection

## Convenience

- Alarms: CD Alarm, Sleep timer, Radio Alarm
- Clock: On main display
- Display Type: White FTD
- OSD Languages: English, Simplified Chinese

## Accessories

- Included accessories: Composite video cable (Y), FM antenna
- Remote control: 38-key with Lithium battery
- Cables: Din

## Dimensions

- Set dimensions (W x H x D): 218 x 90 x 221.5 mm
- Main speaker dimensions (W x H x D): 125 x 250 x 232 mm
- Packaging dimensions (W x H x D): 550 x 314 x 330 mm
- Weight incl. Packaging: 13 kg
- Subwoofer dimensions (W x H x D): 147 x 250 x 232 mm



Issue date 2014-02-11

Version: 2.0.4

12 NC: 8670 000 33602  
EAN: 87 12581 36151 8

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)