

Philips  
Micro music system

CD, MP3-CD, USB, FM  
30 W

MCM1350



## Bring power to your tunes

Obsessed with sound

Listen to all your favourites on your portable music player with USB Direct and Audio in. This Philips Micro music system also plays MP3-CD and CD-R/RW. 30 RMS max output power and Bass Reflex speakers deliver big sound and powerful bass.

### Enrich your sound experience

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Digital Sound Control for optimised music style settings
- 30 W RMS Maximum output power

### Enjoy your music from multiple sources

- Play MP3-CD, CD and CD-R/RW
- USB Direct for easy MP3 music playback
- Audio-in for portable music playback

### Easy to use

- Motorised CD loader for convenient access
- Digital tuning with preset stations for extra convenience

# PHILIPS

# Highlights

## Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimise the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by causing the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a completely new dimension of deep bass.

## Audio-in



The Audio-in connectivity allows direct playback of Audio-in content from portable media players. Besides the benefit of enjoying your favourite music in the superior sound quality delivered by the audio system, the Audio in is also extremely convenient as

all you have to do is to plug your portable MP3 player into the audio system.

## Digital Sound Control



Digital Sound Control offers you a choice of pre-set Balance, Clear, Powerful, Warm and Bright controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## USB Direct for easy MP3 music



Thanks to the complete file transferability, you can easily enjoy the convenience and fun of accessing more digital music via the built-in USB Direct.

# Specifications

## Sound

- Sound enhancement: digital sound control
- Maximum output power (RMS): 30 W

## Loudspeakers

- Speaker drivers: 3.5" woofer
- Speaker types: bass reflex speaker system

## Audio playback

- Disc playback modes: fast forward/reverse, next/previous track search, repeat/shuffle/programme
- Playback media: CD, CD-R/RW, MP3-CD, USB flash drive
- USB Direct playback modes: fast reverse/fast forward, play/pause, previous/next, repeat, shuffle, stop

## Tuner/Reception/Transmission

- Tuner bands: FM stereo
- Station presets: 20
- Antenna: FM fixed pigtail antenna
- Tuner enhancement: auto digital tuning, auto scan

## Connectivity

- Audio in (3.5 mm)
- USB: USB host

## Convenience

- Alarms: CD Alarm, Radio Alarm, USB alarm
- Clock: On main display, sleep timer
- Display type: LED display
- Loader type: tray

## Accessories

- Included accessories: User Manual
- Remote control: 21-key remote

## Dimensions

- Gross weight: 4.3 kg
- Main speaker dimensions (W x D): 120 x 143 mm
- Main speaker height: 195 mm
- Main unit depth: 227 mm
- Main unit height: 121 mm
- Main unit width: 180 mm
- Net weight: 3.16 kg
- Packaging depth: 171 mm
- Packaging height: 295 mm
- Packaging width: 543 mm

## Power

- Power supply: 220-240 V, 50 Hz



Issue date 2016-09-15

Version: 3.0.7

12 NC: 8670 001 22352  
EAN: 04 89518 56057 46

© 2016 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)