



Philips
USB power bank

20,000 mAh

3 USB charging ports
QC 3.0 and PD 3.0
PPS

DLP7721C



Powerful power bank

with a portable back-up power pack

Big 20,000mAh capacity with safe Li-polymer battery. No more hassle when your cellphone is out of battery. Fast charge your device with USB-C PD 3.0 Max 20W or USB-A port with QC 3.0 Max 18W output.

Superior Charging Design

- 50% charge in 30 minutes
- Charging using USB-C Programmable Power Supply (PPS)
- Smart protection against overheat, overvoltage & overcurrent
- Quick Charge technology to optimize charging speed
- 3 USB ports charge three devices simultaneously

Portable power

- Works anywhere - great when you're not near a power source

Confirm operation at a glance

- LED power-indicator light

PHILIPS

USB power bank
20,000 mAh 3 USB charging ports, QC 3.0 and PD 3.0, PPS

DLP7721C/00

Specifications

Compatibility

- Works with the following: USB charged devices

Power

- Output: USB-C Max 20W USB-A Max 18w
- Power input: USB-C 5V/3A
- Battery Capacity: 20,000mAh 74Wh

Packaging dimensions

- Number of products included: 1
- Type of shelf placement: Both
- Packaging dimensions (W x H x D): 9.5 x 17 x 3.5 cm
- Packaging dimensions (W x H x D): 3.7 x 6.7 x 1.4 inch
- EAN: 48 95229 13553 6

Inner Carton

- Number of consumer packagings: 6
- Inner carton (L x W x H): 22 x 10.7 x 20.5 cm
- Inner carton (L x W x H): 8.7 x 4.2 x 8.1 inch
- GTIN: 2 48 95229 13553 0

Outer Carton

- Number of consumer packagings: 18
- Outer carton (L x W x H): 34 x 24 x 22.5 cm
- Outer carton (L x W x H): 13.4 x 9.4 x 8.9 inch
- GTIN: 1 48 95229 13553 3

Product dimensions

- Product dimensions (W x H x D): 6.8 x 13.6 x 2.75 cm
- Product dimensions (W x H x D): 2.7 x 5.4 x 1.1 inch
- Weight: 0.355 kg
- Weight: 0.783 lb

Accessories

- Cables: USB-C charging cable

Design and finishing

- Materials: PC + ABS

Highlights

LED power-indicator light

The discreet LED light glows softly to let you know at a glance that the unit is powered.

3 USB charging ports

3 USB ports to charge three devices simultaneously

50% charge in 30 min

Fast charging - Charge your mobile phone empty to 50% in 30 minutes time.

Programmable Power Supply PPS

PPS (Programmable Power Supply) is a standard for fast charging technology for USB-C devices. This technology adjusts the voltage and current in real-time, depending on a device's charging status, feeding it with maximum power. A smart way to safely reduce charging time.

Smart Protection

Smart protection against overheating, overvoltage and overcurrent



Issue date 2023-05-03

Version: 2.3.2

12 NC: 8670 001 89995
EAN: 48 95229 13553 6

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com