



Philips
HiFi Stereo Headphone

SHP895

HiFi

XXL speaker driver

With an auto-fit headband and soft velvet ear cushions for extra comfort, and a huge 'XXL' size speaker driver for a full-bodied sound, the SHP 895 HiFi stereo headphone provides the perfect listening experience.

The perfect listening experience

- 50mm speaker driver for sound without audible distortion
- High quality Linear Crystal Oxygen Free Copper cable

You'll forget you're wearing them!

- Headband automatically adjusts to fit your head
- Breathable headband improves comfort for prolonged use

Always ready

- A 4m detachable cable for extended life & simplified storage
- Unique detachable cable locking mechanism
- Single-sided cable reduces tangling and improves comfort

PHILIPS

Specifications

Sound

- Acoustic system: Open
- Magnet type: Neodymium
- Frequency response: 5 - 30 000 Hz
- Voice coil: CCAW
- Impedance: 32 Ohm
- Maximum power input: 1500 mW
- Sensitivity: 106 dB
- Speaker diameter: 50

Connectivity

- Cable Connection: One-sided
- Cable length: 4 m
- Connector: 3.5 & 6.3 mm stereo
- Detachable cable
- Finishing of connector: 24k Gold-plated
- Type of cable: LC-OFC

Accessories

- Adaptor plug: 3.5-6.3 mm
- Stand: Matching stand included

Inner Carton

- EAN/UPC/GTIN: 87 10895 86657 6
- Height: 310 mm
- Length: 500 mm

- Quantity: 3
- Width: 245 mm
- Gross weight: 4.336 kg
- Net weight: 1.169 kg
- Tare weight: 3.167 kg

Outer Carton

- EAN/UPC/GTIN: 87 10895 86658 3
- Height: 660 mm
- Length: 520 mm
- Quantity: 12
- Width: 520 mm
- Gross weight: 19.059 kg
- Net Weight: 4.675 kg
- Tare weight: 14.384 kg

Packaging Data

- 12NC: 908210003928
- EAN/UPC/GTIN: 87 10895 86656 9
- Height: 308 mm
- Length: 237 mm
- Net weight: 0.390 kg
- Width: 145 mm
- Gross weight: 1.254 kg
- Tare weight: 0.864 kg

Highlights

50 mm speaker driver

The 50 mm speaker driver combines the sensitivity of composite Mylar material with the power of neodymium for the magnetic circuit to deliver powerful, distortion-free sound.

LC-OFC cable

The extremely pure copper used for this cable minimizes transmission losses and delivers superb signal quality to the headphone, and pure sound to your ears.

Auto-fit headband

The auto-fit headband ensures a perfect fit every time you put the headphone on. You don't have to adjust anything, just get straight into the game.

Breathable headband

The extensively cushioned 'Auto Fit' head band with integrated breathable mesh, ensures you stay cool & comfortable during prolonged periods of use.

4m cable

A detachable cable is convenient to connect or store away depending on your needs.

Unique cable locking mechanism

Paying attention to even the smallest detail, the acoustic engineers refined the design of the locking mechanism to ensure the detachable cable does not accidentally come loose.

Single-sided cable

The cable is conveniently connected to just one side, considerably reducing the risk of tangling and simplifying winding the cable up for storage.



Issue date 2014-02-07

Version: 2.0.4

12 NC: 9082 100 03928
EAN: 87 10895 86656 9

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com