



Philips
Headphones

8.6mm drivers/closed-back
In-ear

SHE3550BK

Big beats, pumping bass

Compact design

Ultra small, big bass Philips MyJam Beamers in-ear headphones feature oval tube inserts for comfort.

Revel in quality sound

- Big bass and clear sound through efficient drivers
- A perfect in-ear seal blocks out external noise

Listen for longer

- Oval sound tube insert provides an ergonomic comfort fit
- 2 interchangeable rubber ear caps offer an optimal fit

Always ready to go

- Reinforced cable relief enhances durability and connectivity

PHILIPS

Headphones
8.6mm drivers/closed-back In-ear

Specifications

Accessories

- Eartips: 3 sizes S, M, L

Sound

- Acoustic system: Closed
- Frequency response: 20 -20 000 Hz
- Magnet type: Neodymium
- Maximum power input: 10mW
- Sensitivity: 101 dB
- Speaker diameter: 8.6 mm
- Impedance: 16 ohm

Connectivity

- Type of cable: copper
- Cable Connection: two-parallel, symmetric
- Cable length: 1.2 m
- Connector: 3.5 mm
- Finishing of connector: chrome-plated

Inner Carton

- Gross weight: 0.125 kg
- GTIN: 2 69 51613 99137 8
- Inner carton (L x W x H): 18.1 x 8.1 x 6 cm
- Nett weight: 0.036 kg
- Number of consumer packagings: 3
- Tare weight: 0.089 kg

Outer Carton

- Gross weight: 1.127 kg
- GTIN: 1 69 51613 99137 1
- Outer carton (L x W x H): 37.5 x 17.9 x 13.9 cm
- Nett weight: 0.288 kg
- Number of consumer packagings: 24
- Tare weight: 0.839 kg

Packaging dimensions

- Packaging dimensions (W x H x D):
5 x 17.3 x 2.7 cm
- EAN: 69 51613 99137 4
- Gross weight: 0.026 kg
- Nett weight: 0.012 kg
- Number of products included: 1
- Packaging type: Blister
- Tare weight: 0.014 kg
- Type of shelf placement: Both

Product dimensions

- Product dimensions (W x H x D):
2.1 x 1.85 x 1.2 cm
- Weight: 0.011 kg

Design

- Color: Black

SHE3550BK/00

Highlights

2 sizes of ear caps

Ear caps come in a choice of 2 sizes for a personalized and perfect fit.

Efficient drivers

Philips Vibes in-ear headphones house efficient drivers inside a compact design. They fit perfectly while pumping out clear sound and booming bass.

Oval sound tube

An oval sound tube insert provides ergonomic comfort to fit the true shape of the ear.

Perfect in-ear fit

Ultra small earphones fit perfectly inside the ear, creating a seal that blocks out external noise.

Reinforced cable relief

To extend the life of your headphones, a soft rubber relief between them and the cable protects the connection from damage through repeated bending.



Issue date 2022-04-24

Version: 4.1.7

12 NC: 8670 001 08887
EAN: 69 51613 99137 4

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com