



Philips
Cordless telephone

SE4301S

SIM-plify your life

Make your home phone an extension of your mobile, with the SIM copying facility offered by the SE4 series. Texting, backlights and caller display make this phone as complete as your mobile.

Be In Line With Your Mobile

- SIM-card copying facility
- Keep in touch by SMS texting

Pure convenience

- Display indicates the caller's name and number
- Speakerphone - Talk handsfree
- Backlit display & keypad

PHILIPS

Specifications

Picture/Display

- Backlight
- Backlight color: Amber
- Display colors: Black & White
- Lines of text: 2
- Main Display Resolution: n.a. pixel
- Main Display Technology: CSTN
- Main Display Type: Dot-Matrix

Convenience

- Alarms: Alarm Clock
- Base Station keys: Paging key
- Base Station Mem. Card Reader: SIM Card Reader
- Battery charging indication
- Call Management: Call Waiting, Caller ID, Microphone mute
- Ease of Use: Hands free mode, Keypad Lock, Menu Control
- Function: Babysit function, Baby Call
- Multi base capability: 1
- Multi handset capability: Up to 5 handsets
- Signal strength indication
- VIP group with own melody: Yes, 3 groups
- Backlit keypad: Yes (Amber)

Network Features

- Antenna: Integrated on base, Integrated on handset
- Compatible: GAP
- Dialing: Tone, Pulse
- Messaging: SMS (Short Message Service)

Operator Requirements

- Name and Caller ID
- Caller ID on call waiting

Sound

- Handset ringers: Instrumental, Polyphonic
- Volume Control: Volume Control up/down

Memory Capacity

- SMS storage capacity: 25
- Call log entries: 50
- Phonebook: 250 names and numbers
- Number of SMS Boxes: 10

Power

- Battery capacity: 650 mAh
- Battery type: AAA
- Battery Type: NiMH
- Kind of Battery: Rechargeable
- Mains power: AC 220-240V - 50Hz
- Number of batteries: 2
- Standby time: Up to 150 hours
- Talk time: Up to 12 hours

Dimensions

- Base dimensions: 117 x 84 x 66 mm
- Handset dimensions: 140 x 46 x 25 mm

Highlights

SIM-card copying facility

With the SIM-card copying facility, you can transfer your whole mobile-phonebook on to your home telephone in a matter of seconds.

Keep in touch by SMS texting

The SMS is a simple way to exchange information over the telephone line. You first type your text off-line and when you are ready, you send it to as many people as you like.

Caller name & number display

The name of the person or company calling is shown on the telephone display. The names of first-time callers can be displayed as well as those that are programmed into the telephone beforehand.

Speakerphone - Talk handsfree

Handsfree mode uses a built-in loud speaker to amplify the voice of the caller, allowing you to speak and listen during a call without holding the phone to your ear. This is especially useful if you want to share the call with others or take notes during a call.

Backlit display & keypad

Backlit display & keypad ensures easy viewing and operation in low light conditions



Issue date 2014-02-10

Version: 1.1.3

12 NC: 9961 400 06256
EAN: 87 10895 95350 4

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com