



Philips
Micro Hi-Fi System

CD playback
wall-mountable

MC235B

Unique Style - Great Sound - Wall Mountable

Trendy and progressive, unique innovation and style appeals to you. And so will the vividly chic MC235B with dynamic sound performance packed in a sleek design that can also be wall mounted.

Enrich your sound experience

- Play CD, CD-R and CD-RW discs
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 2x5W RMS/2x10W music power/400W PMPO

Start the day your way

- Wake up and sleep timer functions
- Digital tuning with 40 preset stations for extra convenience

Design that blends into your interior

- Wall-mountable option for flexible placement
- Motorized sliding front door adding style and elegance

PHILIPS

Specifications

Sound

- Output Power: 2x10W Music Power
- Output power (RMS): 2 x 5 W
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost

Loudspeakers

- Main Speaker: 3" woofer, Bass Reflex Speaker System, Piezo tweeter

Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: Repeat/one/all/program, Shuffle Play, 20-Track Programmable
- Loader Type: Front, Motorised

Tuner/Reception/Transmission

- Auto digital tuning
- Tuner Bands: FM Stereo, MW
- Tuner Enhancements: Auto Store
- Station presets: 40

Connectivity

- Headphone: 3.5 mm
- Other connections: FM Antenna, MW Antenna
- Aux in: Line in

Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer
- Backlight color: Blue
- Clock: On main display
- Display Type: LCD

Accessories

- Included accessories: Screws for wall mounting x2, AM/FM Antenna, Stand, Guarantee booklet, Quick Use Guide
- Remote control: 23-key with battery
- User Manual: 16 languages

Dimensions

- Packaging dimensions (W x H x D): 328 x 313 x 300 mm
- Set dimensions (W x H x D): 250 x 245 x 96 mm
- Main speaker dimensions (W x H x D): 166 x 245 x 90 mm
- Weight incl. Packaging: 5.3 kg

Power

- Power supply: 220-240V, 50Hz

Highlights

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Issue date 2017-04-04

Version: 1.1.8

12 NC: 8670 000 31643
EAN: 87 12581 34694 2

© 2017 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com