

Philips Streamium Wireless Music Station

**Stream**ium

**WAS700** 

# Access your entire music collection in every room

Access your entire CD collection from the 40 GB hard disk on your wireless music center and listen in every room. You can listen to different music in every room. Now music can finally follow you wherever you are in your home

# Unlimited listening pleasure - wirelessly

- Wireless streaming between Music Center and Station(s)
- Wireless streaming from PC via UPnP

# Easy navigation and control

- Music Follows Me: take your music with you from room to room
- Music Broadcast for simultaneous playback to all Stations

# **Quality sound performance**

- Super Sound Panel for clear and deep bass sound
- Class 'D' digital amplifier for quality sound performance





# Highlights

# Wireless streaming



With wireless streaming, you don't need to download and store large music files on our audio device. Instead, you can listen to favorite songs as they are continuously streamed to all the Music Stations - at the same time. Have your music follow you from room to room with Music Follows Me - no need to restart

navigation and playback. Music Broadcast simultaneously broadcasts your desired music from the Center to all Stations. And with My Room, My Music, any family member can enjoy selected music from the stored collection in any room that is equipped with a Wireless Music Center or Station.

# **Universal Plug & Play**

Universal Plug & Play is an industry standard technology that lets you connect to any Universal Plug & Play enabled device to receive or transmit music. Your Wireless Music Center utilizes Universal Plug & Play to ensure an easy and standard way to connect to other Universal Plug & Play enabled devices. You can easily connect your Wireless Music Center to

other media devices to receive or to transfer content.

# **Super Sound Panel**



Super Sound Panel is an innovative, flat speaker panel that uses cutting-edge technology to provide high quality, full-range audio from a flat and compact speaker unit.















# Specifications

- Equalizer settings: Classic, Jazz, Pop, Rock, Techno,
- Output Power: Total Power 20W RMS
- Output power (RMS): 2 x 10 W RMS
- Sound Enhancement: Dynamic Bass Boost 3 steps, Equalizer, Incredible Surround, Treble and Bass Control, Smart equalizer
- Type: Super Sound Panel Speakers
- Volume Control: Volume Control up/down

## Loudspeakers

- Built-in speakers: 2
- · Loudspeaker types: Integrated subwoofer, Super Sound Panel, Non-detachable

# **Audio Playback**

- · Compression format: MP3, PCM, WMA
- ID3-tag support
- Sample frequencies: 8-48 kHz (MP3)
- · Hard Disk Playback Mode: Album, Genre, Playlist, All tracks, Same Artist, Same Genre, Uncompressed tracks
- $\bullet$  Hard Disk Streaming Mode: Wi-Fi streaming to 5 stations, "My Room, My Music", "Music Follows Me", "Music Broadcast"

# Tuner/Reception/Transmission

- · Auto digital tuning
- Auto store
- Number of Preset Channels: 40
- Tuner Bands: FM

## **Connectivity**

- Antenna: FM Dipole
- · Aux in: Line in
- Headphone: 3.5 mm
- Power: 110V, 60Hz
- Wireless connections: Wireless LAN(802.11g)
- Wireless Universal Plug & Play: Enabled
- Audio cinch in: Analog AUX (Center/Station)

# Convenience

- Backlight
- Backlight color: White
- Display Type: LCD, 128 x 96 dot matrix, 48 mm x 42 mm (Station)
- Eco Power Standby: 1 watt
- Headphone jack
- On-Screen Display languages: Dutch, English, French, German, Italian, Spanish
- Remote control: Slim Card
- · Signal strength indication
- Wall mountable / Ceiling Throw: Wall Mountable

- Batteries: 1 x Lithium Coin Cell
- Remote control: card type
- Warranty Card: Warranty Card

# **Audio Recording**

• Bit rate: 128, 160 kbps




Issue date 2009-05-06

Version: 9.1.14

© 2009 Koninklijke Philips Electronics N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 9073 100 12644 EAN: 87 10895 88451 8 www.philips.com



\* Windows logo are trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries. \* Avoid extensive use of the set in a volume higher than 85 decibel because this may damage your hearing.