



Philips  
Universal Remote Control

4-in-1 UK SAT

SRU540



## Share the comfort

Stylish silver universal remote control that gives maximum functionality for most brands of TV, VCR, DVD, satellite receiver or cable set-top box.

### Single control solution for most devices & brands

- 4-in-1 remote for your TV, VCR, STB and DVD player/recorder.
- Ready for use with Philips equipment

### Great convenience

- Drop it, splash it and just keep on using it!
- Eye-catching chrome finish
- Dedicated SKY keys for easy Digital SAT box control
- Low battery indication shows when to refresh batteries

### Quick and easy set-up

- Automatically searches for your equipment brand
- Batteries are included for unwrap & zap
- For questions and assistance call our URC service line
- URC support service via dedicated website

**PHILIPS**  
sense and simplicity

## Specifications

### Convenience

- **Universal IR database:** TV, VCR, DVD, SAT, CABLE
- **TV functions:** Program up/down, Volume up/down, mute, Power/standby, Digit keys, AV selection, external, Menu control, Colour / brightness control, Teletext keys, Fast text keys, Previous program, Sleep/timer, 16:9, Guide, info
- **Teletext enhancements:** Fast text
- **VCR functions:** Transport keys (6), Showview, VCR plus, Menu control
- **DVD functions:** Transport keys, System menu control, Disc menu control, Digit keys
- **SAT/CBL functions:** Digit keys, Menu control, Guide, info, Favourites, Text functions, Unique SAT provider functions
- **Ease of installation:** Auto search
- **Installation steps:** 2
- **Copy key function**
- **Language support:** GB
- **Languages in manual:** GB
- **Number of keys:** 40
- Pre-programmed for Philips

- **Regulatory approvals:** CE Mark
- Splash proof

### Accessories

- **Battery:** Yes, 1.5V Battery R03/AAA

### Power

- **Battery lifetime:** 12
- **Number of batteries:** 2

### Dimensions

- **Blister dimensions (WxDxH):** 148 x 28 x 290 mm
- **Carton dimensions (WxDxH):** 181 x 170 x 310 mm
- **Folded:** Single blister/back carton
- **Materials:** Recycled PET A

### Infrared Capabilities

- **Operating distance:** 7 m
- **Transmitting LEDs:** 1
- Universal infra red code database
- **Number of brands in database:** Over 1100
- **Carrier frequency range:** 24 - 55 kHz
- **Transmission angle:** 90 degree

## Product highlights

### 4 in 1 remote control

Replace a table full of remote controls with one robust unit that'll operate your TV, VCR, satellite receiver (or cable STB set-top box) and DVD, regardless of the brand or model.

### Pre programmed for Philips

If you have Philips equipment, you can use your universal remote control without programming it because all keys are preset for Philips.

### Splash and shock resistant

The tough housing can withstand splashes and spilled drinks, and is able to withstand a drop of at least one meter onto a hard floor.

### Chrome finish

Stylish chrome finish that looks good and complements the latest equipment design.

### Dedicated SKY keys

Specially labelled function keys on the remote control make operating your SKY digital set-top box easier than ever before.

### Low battery indication

To know in time when the batteries need to be recharged or replaced.

### Auto brand search

Getting your new remote control working is simply a case of having your remote automatically search for the most suitable code for your equipment.



Issue date 2007-08-04

Version: 3.0

12 NC: 9082 100 03875  
EAN: 87 10895 86548 7

© 2007 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)