

Philips Streamium

Streamium



Access all your CDs in every room

Store your entire CD collection on a 40 GB hard disk and listen in every room. You can listen to different music in every room and your music can finally follow you wherever you are in your home. The Remote Control has a built-in display

Wireless unlimited listening pleasure

- Wireless streaming between music centre and station(s)
- Multiple user access streams to up to 5 stations streaming
- 40 GB hard disk to store and playback up to 750 CDs
- Wireless streaming from PC via UPnP

Easy navigation and control

- 2-way Remote Control for user friendly navigation
- Direct Content Access to artist, album or playlists
- Music Follows Me anywhere, everywhere in the home
- Music Broadcast for simultaneous playback to all Stations

Quality sound performance

- Super Sound Panel with deep bass and clarity
- Class 'D' digital amplifier for quality sound performance

Expandable

- Add 4 additional Wi-Fi Stations

PHILIPS

Technical specifications

Sound

- **Equaliser settings:** Classic, Jazz, Pop, Rock, Techno, Neutral
- **Sound enhancement:** Dynamic Bass Boost 3 steps, Equaliser, Incredible surround, Treble and bass control, Class "D" digital amplifier, Smart equaliser
- **Output power:** 80W+80W Music Power (Centre), 20W+20W Music Power (Station)
- **Volume Control:** Volume control up / down

Loudspeakers

- **Built-in speakers:** 2
- **Loudspeaker types:** Integrated subwoofer, Super Sound Panel, Non-detachable

Audio Playback

- **Compression format:** WMA, MP3, PCM
- **Playback Media:** CD, CD-R, CD-RW, MP3-CD, WMA-CD
- **Disc playback modes:** Next / previous track search, Next / previous album search, 99 track programmable, Repeat/Shuffle/Program, Fast forward / backward
- ID3 tag support
- **Loader type:** Slot
- **MP3 bit rates:** 8-320 kbps and VBR
- **WMA bit rates:** 16-128 kbps
- **Hard Disc Playback Mode:** Album, Genre, Playlist, All tracks, Same Artist, Same Genre, Uncompressed tracks
- **Hard Disc Streaming Mode:** "My Room, My Music", "Music Follows Me", Wi-Fi streaming to 5 stations, "Music Broadcast"
- **Sample frequencies:** 8-48 kHz (MP3), 16-48 kHz (WMA)

Audio Recording

- **Recording media:** HDD
- **Recording speed:** 1 x, 4 x
- **Audio file format:** MP3

Storage Media

- **Hard disk capacity:** 40 GB
- **Built-in Memory Capacity:** (40) GB
- **Expandable:** Hard Disc Service Swap

Tuner / Reception / Transmission

- **Tuner bands:** FM
- Auto digital tuning
- Auto store
- **Number of preset channels:** 40

Connectivity

- **Audio cinch in:** Analogue AUX (Centre/Station)
- **Audio cinch out:** Analogue Line-out (Centre)
- **Other connections:** Ethernet
- **Headphone:** 3.5 mm
- **Wireless connections:** Wireless LAN Adapter 802.11g
- **Antenna:** FM Dipole
- **Wireless Universal Plug & Play:** Enabled
- **Power:** 220 V 50 Hz

Convenience

- Backlight
- **Backlight colour:** White
- **On-screen display languages:** English, Dutch, French, German, Italian, Spanish
- **Digital content management:** DMM software included
- **Eco power standby:** 1 watt
- Signal strength indication
- **Display type:** LCD, 128 x 96 dot matrix, 60.7 mm x 52.3 mm (Centre), 48 mm x 42 mm (Station)
- **Wall mountable / Ceiling Throw:** Wall Mountable

Accessories

- **Cables:** Ethernet Cable
- **CD-ROM:** Installation CD-ROM
- **Remote control:** 2-way 6-line Display, Card
- **Batteries:** 4 x AAA
- **Warranty card:** Warranty card

Dimensions

- **Carton dimensions (WxDxH):** 674mm x 381mm x 376mm
- **Set weight:** 11.9 kg
- **Product dimensions (WxDxH):** 608mm x 175mm x 303mm (Centre) 360mm x 128mm x 283mm (Station)
- **Master carton weight:** 14 kg

Product highlights

Wireless Streaming

With wireless streaming, you don't have to wait to download and store a large file on your audio device before listening to your favourite songs. Instead, the music is sent in a continuous stream and is played as it arrives to up to five music stations at the same time. Your music can now follow you everywhere in your home.

Multiple User Access

Different family members in five different rooms can access & listen to their own choice of music from the Wireless Audio Centre at the same time.

2-way Remote Control

With Philips 2-way remote control, you can now navigate through hundreds of songs easily with the one simple press of the remote control. Displaying six lines info listed according to playlist, album, artist, genre or track, this intuitive navigation offers speedy yet simple scrolling through hundreds of files. It allows one handed operation and guarantees a unique user experience.

Music Broadcast - Party mode!

Be your own DJ at your home party and simultaneously broadcast your favourite dance music from the Wireless Music Centre to all Wireless Music Stations installed in various parts of your home. Great for parties!

Music Follows Me between rooms

Music follows Me feature allows you to bring your favourite music from room to room in your house without having to restart navigation and playback of that particular track. By simply pressing a button, your favourite song will follow you anywhere you go in your house.

Super Sound Panel

Super Sound Panel is an innovative, flat speaker panel that uses cutting-edge technology to provide high quality, full-range audio from a flat and compact speaker unit.

* Windows logo are trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries.

* Actual capacity less



Date of issue 2006-10-06

Version: 7.0

12 NC: 9073 100 12626
EAN: 87 10895 88440 2

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.
© 2006 Koninklijke Philips Electronics N.V.
All Rights reserved.
www.philips.com

