



Philips Harmony
Component micro Hi-Fi
system

Hi-Fi dome tweeter

Harmony



MCM7000



Enjoy high fidelity music

Obsessed with sound

Fill your home with great sound from CDs, MP3 Link and USB Direct. Hi-Fi dome tweeters bring you detailed and natural sound while Treble and Bass Control lets you adjust tones. An aluminium cabinet adds a high-quality look and feel.

Enrich your sound experience

- Hi-Fi dome tweeter for detailed and natural sound
- Class 'D' digital amplifier for quality sound performance
- Treble and Bass Control for easy high and low tone settings
- Gold-plated speaker connector for finest signal transmission
- 60 W RMS total output power

Enjoy your music from multiple sources

- Play MP3/WMA-CD, CD and CD-RW
- USB Direct for MP3/WMA music playback
- MP3 Link for portable music playback

Premium finishing with noble materials

- Aluminium cabinet for quality look and feel

PHILIPS
sense and simplicity

Highlights

Treble and Bass Control

Treble and bass are equalizer features that control the high and low frequency sound levels of your audio respectively. Treble specifically regulates the amplification of the high tones in the music, while bass controls the amplification level of the low tones. Using the up and down keys, the listener can conveniently place more or less emphasis on the low and high tones, or leave treble and bass flat to play back music according to its original recorded setting. Treble and Bass Control lets you listen to your music the way you like it.

MP3 Link



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favourite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player into the audio system.

USB Direct



With the USB Direct mode, you can simply select the music on a USB device and play back all your

content. All you have to do is plug in your USB device to play back music or export content from the device.

Class 'D' Amplifier

The Class 'D' Digital Amplifier takes an analogue signal, converts it into a digital signal and then amplifies the signal digitally. The signal then enters a demodulation filter to give the final output. The amplified digital output delivers all the advantages of digital audio, including improved sound quality. In addition, the Class 'D' Digital Amplifier has over 90% efficiency compared to traditional AB amplifiers. This high efficiency translates into a powerful amplifier with a small footprint.

Gold-plated speaker connector



The gold-plated speaker connector ensures better audio signal transmission compared to traditional click-fit connections. It also minimises the electrical signal loss from the amplifier to the speaker box, resulting in sound reproduction that's as close to reality as possible.

Specifications

Sound

- Output power (RMS): 2 x 30 W
- Sound Enhancement: Treble and Bass Control, Loudness, Class "D" Digital Amplifier

Loudspeakers

- Loudspeaker types: Dome tweeter
- Main Speaker: 5" woofer, 2-way, Bass Reflex Speaker System, Speaker grilles detachable
- Loudspeaker enhancement: Gold-plate speaker connectors

Audio playback

- Disc playback modes: repeat/shuffle/programme, fast forward/reverse, next/previous album search, next/previous track search
- USB Direct playback modes: play/pause, fast reverse/fast forward, previous/next, programme play, repeat, shuffle, stop
- Playback media: CD, CD-R/RW, MP3-CD, WMA-CD, USB flash drive
- Others: ID3-tag support

Tuner/Reception/Transmission

- Station presets: 20
- RDS: station name, programme type, radio text, RDS clock set
- Antenna: FM antenna (75 ohm)
- Tuner enhancement: Easy set (plug and play), auto digital tuning, auto scan
- Tuner bands: FM mono, FM stereo

Connectivity

- Front/Side connections: USB 2.0
- MP3 Link: 3.5 mm stereo line in
- Headphones: 3.5 mm
- Rear Connections: AUX in, Line out, FM Antenna, Left and right speakers

Convenience

- Alarms: CD Alarm, Radio Alarm, USB alarm
- Clock: On main display
- Display Type: VFD display
- Indications: DIM mode

Accessories

- Included accessories: AC Power Cord, FM antenna, 3.5 mm stereo line-in cable, Warranty certificate
- Remote control: 44-key remote with 2 x AAA batteries
- User Manual: 16 languages

Dimensions

- Main unit width: 250 mm
- Main unit height: 92 mm
- Main unit depth: 285 mm
- Main speaker dimensions (W x D): 174 x 240 mm
- Main speaker height: 260 mm
- Packaging width: 425 mm
- Packaging height: 441 mm
- Packaging depth: 310 mm
- Gross weight: 10 kg
- Net weight: 8.5 kg

Power

- Power supply: 220-240 V, 50 Hz



Issue date 2012-08-28

Version: 2.1.5

12 NC: 8670 000 71442
EAN: 87 12581 57915 9

© 2012 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com