

Philips Car audio system

CD

CEM1000

# Seamless music enjoyment on the road

## with CD, MP3 & WMA music playback

Philips CEM1000 lets you seamlessly enjoy digital music from CD & portable MP3 players in your car. It features anti-theft detachable front panel for security, and anti-shock protection for smooth grooves on the go.

### Enjoy your digital music in car

• CD player and MP3 Link for music playback

### Superb performance in a compact design

- Dynamic Bass Boost electronically enhances the low tones
- Super anti-shock protection for smooth music enjoyment
- 2-band parametric equalizer with 8 presets
- · Audio out for amplifier addition
- $\bullet\,$  Built-in 45W x 4 amplifier for excellent sound quality

### Design that blends into your car

- · Diffused indicating light for easy CD insertion
- High contrast LCD for perfect viewing
- Browse by folder or song for instant search or quick access
- · Detachable front panel and blackout for anti-theft security



### CEM1000/00

## Highlights

### **DBB Dynamic Bass Boost**



Activate the Dynamic Bass Boost (DBB), and the low-end bass frequencies are electronically enhanced to achieve consistent sound reproduction, especially when the speaker volume is set at a low level. You hear impressive bass at all times.

### Diffused indicating light



Find difficulty inserting a CD into your car audio in the dark? With the innovative design from Philips, you will have a clear guide with lights spreading around the disc opening to help you insert a CD faster and easier.

### **High contrast LCD** High contrast LCD











### Browse by folder or song



This function allows you to find a track or album much faster by letting you browse through songs and folders, which are the usual contents of USB/SDHC devices. With the dedicated folder/song button, only three simple steps are needed to make a search press folder/song, rotate the volume knob and push to select. This simple process lets you search through your music quickly and easily, letting you to focus on your driving.

### **Detachable front panel**



Detachable front panel and blackout for anti-theft



## Specifications

- Type: High contrast B/W LCD (8 characters)
- · Key illumination: Red

### **Audio Playback**

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA, WMA-CD
- · Compression format: MP3, WMA
- Disc Playback Modes: Fast Forward/Backward, Introscan, Next/Previous Album Search, Next/ Previous Track Search
- ID3 Tag support: Song title, artist, album
- MP3 bit rates: 32-320kbps and variable bit rate

### Tuner/Reception/Transmission

- Tuner Bands: AM, FM Stereo
- Auto digital tuning
- Tuner Enhancements: Auto search and store
- No. of preset stations: 18(FM), 12(AM)
- · RDS: Station Name, Station Information, Radio Text, Program Type, News, News & Traffic, RDS

### Sound

- · Equalizer: 2-bands
- · Equalizer settings: Classic, Jazz, Pop, Rock, Flat, Optimal, Techno, User defined
- · Sound Enhancement: Dynamic Bass Boost
- Output power (MAX): 45Wx4 channels
- Output power (RMS): 22Wx4 channels (4 ohms, 10% T.H.D.)

### **Connectivity**

- MP3-Link: For portable MP3 music playback
- Preamp output: 2 pairs RCA(L/R)

### Security/Anti-theft

- · Front panel: Detachable
- Display blackout: 10/20 sec selectable

### Accessories

- · Remote control: Slim remote with battery
- · User Manual: English, Brazilian Portuguese, Spanish, Traditional Chinese
- · Quick start guide: English, Traditional Chinese, Brazillian Portuguese, Spanish

• Power supply: 12V DC

### **Dimensions**

- Product dimensions (W x H x D): 188 x 58 x 190 mm
- · Chassis: 1 Din



Issue date 2014-02-12

© 2014 Koninklijke Philips N.V. All Rights reserved.

Version: 4.0.2

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 65573 EAN: 69 23410 70366 5

www.philips.com