

Philips  
Portable CD Player



AX5303

## Slim and Jogproof

with Wearable Remote Control

The AX5303 CD players are the absolute latest in urban portable music. Rugged sophistication meets solid performance in this slim and Jogproof player. Long battery life and a wearable remote control enhance your music enjoyment on the go.

### Designed for motion

- na
- Ease-to-read dual LCD display
- Wearable remote control for easy access
- Savor up to 45 hours music playback

### Jogproof

- 45-second ESP™

### Enhanced bass performance

- Digital Dynamic Bass Boost for optimized bass at any volume
- Stereo headphone with Bass Wave Tech for enhanced bass

### Enjoy all kinds of discs

- Play CD, CD-R and CD-RW discs

# PHILIPS

# Specifications

## Sound

- Acoustic Feedback
- D/A converter: 1-bit
- Frequency response: 20 - 20 000 Hz
- Output Power: 2 x 5mW RMS
- Signal to noise ratio: > 85dB
- Sound Enhancement: Digital Dynamic Bass Boost
- Volume Control: digital

## Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: 30-Track Programmable, Fast Forward/Backward, Hold, Introsan, Repeat Play, Resume Playback from stop, Shuffle Play
- Electronic Skip Protection(CD): 45

## Connectivity

- DC in: 4.0 mm, 4.5V, centre +
- Headphone: 3.5 mm
- Line-out: 3,5 mm

## Convenience

- Display Type: LCD
- Indications: battery status, Cd functions, DBB, ESP, time, track
- Remote control: Wearable incord remote control



## Accessories

- AC/DC Adaptor: AY3170(300mA)
- Batteries: AY3363(Ni-MH rechargeable)
- Headphones: SBC HE570/77S
- Included accessories: User Manual
- Pouch: AY3267
- Remote control: AY3785(6 key incord)

## Dimensions

- Ebox dimensions (W x H x D): 0 x 0 x 0 mm
- Housing: Heat Resistant Body
- Master carton dimensions: 252 x 310 x 160 mm
- Master carton quantity: 6
- Master carton weight: 4.18 kg
- Packaging dimensions (W x H x D): 243 x 49 x 148 mm
- Packaging type: D-box
- Product dimension (WxDxH) inch: 137.5x137.5x23.3mm
- Product weight: 0.2 kg

## Power

- Battery Playing Time CD: 40
- Battery type: AA, AAA, LR03, LR6, UM3, UM4
- Kind of Battery: Rechargeable
- Rechargeable

# Highlights

## Slim, sturdy and compact

## Ease-to-read dual LCD display

Ease-to-read dual LCD display

## Wearable remote control

Wearable remote control for easy access

## Up to 45-hour playback

Savor up to 45 hours music playback

## 45-second ESP™

Electronic Skip Protection is a convenient feature that ensures skip-free music even when your CD player is subjected to knocks and jolts while you're jogging or on the move. Devices with Electronic Skip Protection have an intelligent electronic buffer that adjusts both its contents and laser spin speeds automatically to guarantee uninterrupted music listening.

## Digital Dynamic Bass Boost

Digital Dynamic Bass Boost is an intelligent bass booster that delivers maximum bass enhancement at high volumes without sound distortion and at low volumes without compromising on bottom-end bass frequencies. Technologically advanced electronics constantly monitor volume and bass levels, precisely calibrating both to prevent sound distortion, thus producing optimized bass. Digital Dynamic Bass Boost enables the enjoyment of superb bass performance - regardless of the chosen volume level.

## Bass enhanced stereo headphone

Stereo headphone with Bass Wave Tech for enhanced bass

## Play CDs, CD-R and CD-RW

Philips is known for making products which are compatible with many discs available in the market. This audio system lets you enjoy music from CD, CD-R and CD-RW. CD-RW (CD-Rewritable Compatible) means that your audio system can play both CD-Recordable (CD-R) and CD-Rewritable (CD-RW) discs. CD-R discs are recordable once and can be played on any audio CD player while CD-RW discs can be recorded and rewritten multiple times and can only be played back on compatible audio CD players.



Issue date 2014-02-06

Version: 2.0.3

12 NC: 9073 101 00973  
EAN: 87 10895 79650 7

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)