

Philips
Multimedia Speaker 2.0



MMS121



Simply superior performance

Great sound from compact speakers

Enjoy stereo sound with your music, Internet and multimedia PC applications. The compact MMS121 Harmonic Pulse speaker system has unbelievable bass performance for their size.

Experience true multimedia

- Compatible with music, games, film & Internet audio sources
- Easy to connect to either a PC or a laptop

Hear every detail

- Bass Reflex speakers deliver a powerful, deeper bass
- Dynamic Bass Boost for deep and dramatic bass

Easy to use

- Labelled and colour coded connectors get you going in minutes
- Headphone jack for better personal music enjoyment
- Magnetic Shielding eliminates computer screen distortion

PHILIPS
sense and simplicity

Specifications

Sound

- **Bass enhancement:** Bass Boost
- **Frequency response:** 50 Hz - 20 kHz Hz
- **Music Power:** 3 W
- **Output power (RMS):** 2 x 0.75W
- **Volume Control:** Analogue Volume Control
- **Wires:** Fixed Wires

Loudspeakers

- **Loudspeaker Enhancement:** Magnetic Shielded LSB

Connectivity

- **Cable length:** 2 m
- **Connector:** 3.5 mm stereo
- **Headphone:** 3.5 mm
- **Power:** Built in transformer

Convenience

- Power on indication

Packaging content

- **Number of satellites:** 2
- Quick installation guide

Packaging Data

- **I2NC:** 908210004672
- **EAN/UPC/GTIN:** 8710895889650
- **Gross weight:** 1.08 kg
- **Height:** 180 mm
- **Length:** 200 mm
- **Width:** 115 mm
- **Quantity:** 1
- **Tare weight:** 0.12 kg

Outer Carton

- **Quantity:** 8
- **EAN/UPC/GTIN:** 8710895889667
- **Tare weight:** 0.76 kg
- **Gross weight:** 9.4 kg
- **Length:** 415 mm
- **Width:** 250 mm
- **Height:** 380 mm
- **I2NC:** 908210004672

Product highlights

Music, games, films, Internet

All types of music, games, films and Internet audio sources can be played, so no matter what you want to hear, we make your multimedia experiences sound more involving than ever.

For PC or laptop

Can be connected to either a PC or a laptop

Bass Reflex Speaker System

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Quick set up

Colour coded cables, clear labelling and easy to understand documentation mean you'll be up and running in minutes

Headphone jack

Magnetic Shielding

Because the powerful magnets in speaker drivers are magnetically shielded, there's no danger of image distortion or damage when placed close to your PC monitor screen.



Issue date 2007-12-06

Version: 3.0

I2 NC: 9082 100 04672
EAN: 87 10895 88965 0

© 2007 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com