

Philips Pronto
Home Control Panel

Pronto

TSU9600



Designed by installers, made by Philips

The sensational looking Philips Pronto gives you complete control of your AV entertainment, lighting and music throughout your entire home. So why not complement it with the comfort, convenience and control that Philips Pronto brings.

A touch of elegance

- 9.4 cm/3.7" VGA screen with superb contrast and vivid colors
- Cutting-edge design with flush-mounted display
- Ergonomic design for both one- and two-handed control
- Built-in stylus for accurate control

Personalized convenience

- User interface matching your personal taste and preferences
- System feedback via dynamic 2-way user interface
- Control hidden equipment and devices in other rooms
- Control multiple devices with a single touch

Music, mood and ambiance

- Music server control with intuitive rotary cursor
- Pre-configured lighting control (Lutron RadioRa)
- Access digital files from any Windows MCE PC

PHILIPS
sense and simplicity

Specifications

Picture/Display

- Diagonal screen size (inch): 3.7 inch
- Display colors: 65,536
- Resolution: 640 x 480 pixels
- Display backlight: White
- Display screen type: LCD TFT
- Touch panel

Loudspeakers

- Built-in speakers: 1

Connectivity

- Connector: Mini USB
- Power: 100-240V, 50/60Hz
- Built-in wireless technology: 802.11g
- Encryption / security: WEP 128 bit, WEP 64 bit
- Network mode: DHCP, Fixed IP
- USB: USB 2.0

Convenience

- Automatic power off
- Multi language: English, Spanish, French, German, Dutch
- Clock with calendar
- Cradle/ docking station
- Cursor key
- Pick up sensor
- Rotary wheel
- Soft touch back for extra grip

Accessories

- AC/DC Adaptor
- CD-ROM
- Docking Station
- Printed User Guide
- USB cable
- Warranty Card

System Requirements

- Hard disk space: 512 MB free
- PC OS: Windows 2000, XP, Vista
- CD-ROM drive
- RAM memory: 512 MB free
- USB: Free USB port

Power

- Battery capacity: 2100 mAh
- Charging time: Up to 3 hr
- Battery Type: Li-ion
- On/Off switch

Customization

- On screen customization
- Full screen configurability
- Alpha-blending
- Macros: Up to 250 steps
- Database: Configurable personal database, Model number based database
- Sound: WAV format 44 kHz, 16 bit mono

System Specifications

- CPU: Freescale 32 bit RISC
- CPU speed: 266 MHz
- Flash memory size: 64 MB
- Ram size: 64 MB

Infrared Capabilities

- Operating distance: 36 ft (12 m)
- Learning IR codes
- Learning frequency range: 25 kHz - 1 MHz
- Transmitting LEDs: 5
- Universal IR code database
- Number of brands in database: Over 3000

RF Capabilities

- Frequency (GHz): 2.4
- WiFi based

Outer Carton

- Gross weight: 1.184 kg
- Outer carton (L x W x H): 35.8 x 21.8 x 10.1 cm
- Nett weight: 0.804 kg
- Tare weight: 0.38 kg
- EAN: 87 10895 94953 8
- Number of consumer packagings: 1

Packaging dimensions

- Packaging dimensions (W x H x D): 21.8 x 35.8 x 10.1 cm
- Gross weight: 1.184 kg
- Nett weight: 0.804 kg
- Tare weight: 0.38 kg
- EAN: 87 10895 94953 8
- Number of products included: 1
- Packaging type: Carton
- Type of shelf placement: Laying

Product dimensions

- Product dimensions (W x H x D): 15.7 x 10 x 3.4 cm
- Weight: 0.295 kg

Highlights

Flush-mounted display

Flush-mounted display means that the screen is not recessed anymore, but instead flows smoothly with the casing.

Customizable UI

User interface can be created to fully incorporate the end user's personal taste and preferences. So, only the devices and buttons that are used most, will be visible on the touchscreen. Also, the graphical design (backgrounds, icons, buttons, colors used) can be chosen by the user.

ProntoScript

ProntoScript, a JavaScript based software tool, enables installers to create a dynamic 2-way user interface for system control over RS232 or IP with full graphical flexibility. The tool is incorporated in the ProntoEdit Professional software. Ready-made ProntoScript modules with Pronto partners are available via the website. For typical installations, you may opt to use standard installation reference files and simply re-assign the various components. More advanced JavaScript programmers will be able to create their own ProntoScript modules for complete system operation and feedback.

Extended control

A range of extenders is available, both wired and wireless versions, that extend the range of transmission of the remote control. This enables the user to control equipment hidden in cabinets or in other rooms with one and the same control unit.

One-touch convenience

One-touch control allows you to perform multiple commands with one press of a button via a macro. A macro combines a string of pre-programmed commands under one single button. Therefore, it simply takes one button press to execute a series of functions.

Music server control

Out-of-the-box, a user can control his music server e.g. Escient Fireball. The user interface of the music server is built into the remote control. It facilitates listening to music without being in view of a TV, which is normally required to display a music server's user interface. This, in combination with an ergonomic thumb wheel on the remote, simplifies selecting tracks and playlists, & also frees up the TV screen for other activities.

Lighting control

Pre-configured lighting control includes a full on-screen user interface for controlling lighting scenes, moods and individual dimmers. With on-screen feedback from lighting throughout the house, the end user knows if the light is actually on or off.

MCE PC functionality

Through 3rd party software, the Pronto control panel can incorporate Windows MCE PC functionality. This means you are able to access any digital files from your MCE PC via the control panel.



Issue date 2011-07-12

Version: 5.1.14

12 NC: 9082 100 07344
EAN: 87 10895 94953 8

© 2011 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com