



Philips
Surge protector

PowerSquid
5 outlets

SPR5500BN



General Purpose Power Protection

918 Joules/ 36,000 Ampere

This surge protector offers flexible power. Engineered to be the most sophisticated and complete power multiplier, its flexible arms transform the static power strip into a dynamic power delivery device.

Built-in convenience

- Power indicator light
- Protection indicator light
- Right angle plug
- 1 m power cord

Dependable protection

- £50,000 equipment warranty
- V3 Advanced Surge Technology
- Power blocker
- 40 dB EMI/RFI noise filtration
- Master on/off switch

Ideal for office equipment, appliances and more

- 5 flexible outlets

PHILIPS

Specifications

Packaging dimensions

- Packaging dimensions (W x H x D):
17.1 x 48.3 x 10.2 cm
- Nett weight: 1.111 kg
- Gross weight: 1.27 kg
- Tare weight: .159 kg

Outer Carton

- Outer carton (L x W x H): 50.5 x 19.1 x 32.7 cm
- Nett weight: 3.333 kg
- Gross weight: 3.856 kg
- Tare weight: .523 kg

Highlights

5 flexible outlets

Five outlets on separate cords that are all adapter spaced accommodate multiple devices without crowding.

£50,000 equipment warranty

Protects your connected equipment for the life of the product.

V3 Advanced Surge Technology

This new surge protection technology provides 27% greater surge protection capacity and better heat dissipation for safe, more reliable and longer lasting surge protection.

Power blocker

This automatic shutdown technology senses when the device has reached capacity and automatically shuts down electricity to your equipment. It protects against subsequent surges, even if you are not present

40 dB EMI/RFI noise filtration

Built-in filtering technology ensures the best performance from your components. It guards against signal interference and loss of data. The higher the dB rating the better the noise reduction.

Master on/off switch

This master switch controls power to the outlets on the surge protector.

Power indicator light

This LED alert lights up to indicate that the surge protector is drawing power from the AC outlet.

Protection indicator light

This LED alert lights up to indicate the surge protector is working properly.

1 m power cord

Provides power to the unit which can be 1m from the AC outlet.



Issue date 2014-02-10

Version: 1.0.7

12 NC: 8670 000 35637
EAN: 87 12581 38395 4

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com