

Philips DVD player

**DVP1120** 

# Simply plays it all

Does size matter? Ever heard of less is more? Introducing the best value DVD player. No complications! Just a simple set that plays practically any disc format, including your digital photos with absolutely no compromise to picture quality.

## Bring audio and video to life

- 12-bit/108MHz video processing for sharp and natural images
- 192kHz/24 bit audio DAC enhances analogue sound input
- · High quality outputs for analog and digital audio
- Progressive Scan component video for optimized image quality

## Play all your movies and music

- $\bullet \ \, \text{Plays CD, (S)VCD, DVD, DVD+R/RW, DVD-R/RW}$
- Plays MP3, WMA and JPEG digital camera photos

## Fits any space, any lifestyle

• Ultra-slim design that fits anywhere



### DVP1120/37

## Specifications

#### Picture/Display

- D/A converter: 12 bit, 108 MHz
- Picture enhancement: Progressive scan, Video upsampling

#### Sound

- D/A converter: 24 bit, 192 kHz
- Frequency response: 30-20000 Hz
- Signal to noise ratio: 90
- Distortion and Noise (1kHz): 65 dB
- Crosstalk (1kHz): 70 dB
- Dynamic Range (1kHz): 80 dB
- Sound System: Dolby Digital

## Video Playback

- Playback Media: CD, CD-R/CD-RW, Video CD/ SVCD, DVD, DVD+R/+RW, DVD-R/-RW, DVD-Video
- Compression formats: MPEG1, MPEG2
- · Video disc playback system: PAL, NTSC

## **Audio Playback**

- Playback Media: CD, MP3-CD, MP3-DVD, WMA-CD, CD-R/RW, Audio CD
- MP3 bit rates: 32 320 kbps
- Compression format: MP3, Dolby Digital, PCM, WMA

## **Still Picture Playback**

 Playback Media: DVD+R/+RW, DVD-R/-RW, CD-R/RW, Picture CD, Kodak Picture CD

- Picture Compression Format: JPEG
- Picture Enhancement: Flip photos, Rotate, Zoom, Slideshow

## **Connectivity**

 Rear Connections: Analog audio Left/Right out, ComponentVideo out Progressive, Digital coaxial out, CVBS & analog audio L/R output

### Convenience

- Child Protection: Child Lock, Parental Control
- On-Screen Display languages: English, Canadian French, Mexican Spanish

## **Power**

- Power consumption: < 10 W
- Standby power consumption: < 0.8 W
- Power supply: 120V, 60Hz

#### **Accessories**

 Included accessories: 2 x AAA Batteries, Remote Control, User Manual, Audio/Video cable, Product Registration Card, Warranty Leaflet

#### **Dimensions**

- Packaging dimensions (W  $\times$  H  $\times$  D): 300  $\times$  335  $\times$  92 mm
- Set dimensions (W  $\times$  H  $\times$  D): 252  $\times$  52  $\times$  250 mm

#### **Multimedia Applications**

• Playback Formats: JPEG Still pictures, MP3











Issue date 2013-01-26

Version: 1.0.7

© 2013 Koninklijke Philips Electronics N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 33189 UPC: 6 09585 14137 7

www.philips.com

## Highlights

### 192kHz/24 bit audio DAC

192KHz sampling enables you to have an accurate representation of the original sound curves. Together with a 24-bit resolution, more information is captured from the original analogue sound wave form, giving a much richer audio reproduction.

#### **Progressive Scan**

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

#### Plays it all

Play MP3s, WMA and JPEGs, and experience the convenience of sharing media files on your TV or home theater system - in the comfort of your living room.