
Register your product and get support at
www.philips.com/welcome

BDP3282





EN User manual




































Table of contents

1	Hookup and play	2-7
2	Use your Blu-ray disc/ DVD player	10
	Basic play control	10
	Video, audio and picture options	11
	DivX videos	13
	Play a musical slideshow	13
	BonusView on Blu-ray	14
	BD-Live on Blu-ray	14
	Play a Blu-ray 3D video	15
	Set up a network	15
	YouTube videos	16
	Picasa (online photos)	17
	Use Philips EasyLink	18
3	Change settings	19
-	Picture	19
	Sound	20
	Network (installation, status)	20
	Preference (languages, parental control)	20
	Advanced options (clear memory)	21
4	Update software	
-	Update software via the Internet	22
	Update software via USB	22
5	Specifications	23
6	Troubleshooting	25

2 Use your Blu-ray disc/ DVD player

Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers (e.g. product software upgrade), register your product at www.philips.com/welcome.

Basic play control



During play, press the following buttons to control.

Button	Action
▲ / ■	Stop play. Press and hold (more than 4 seconds) to open or close the disc compartment.
	Pause play. Press repeatedly to slow forward frame by frame.
•	Start or resume play.
◀ / ▶	Skip to the previous or next track, chapter or file.
◀◀ / ▶▶	Fast backward or forward. Press repeatedly to change the search speed. Press ∎ once, and then press ▶ to slow forward.
AUDIO	Select an audio language or channel.
SUBTITLE	Select a subtitle language.
DISC MENU / POP-UP MENU	Access or exit the disc menu.
TOP MENU	Access the main menu of a video disc.
Color buttons	Select tasks or options for Blu-ray discs.
AV4>	Navigate the menus. Press ▲▼ to rotate a picture clockwise or counter-clockwise during slideshow.
ОК	Confirm a selection or entry.
5	Return to a previous display menu.
=	Access more options during play.

Video, audio and picture options

More options are available for video or picture play from a disc or USB storage device.

Video options



Access more options during video play.


- [Audio Language]: Select an audio language.
- [Subtitle Language]: Select a subtitle language.
- [Subtitle Shift]: Change the subtitle position on the screen. Press ▲▼ to change the subtitle position.
- [Info]: Display play information.
- [Character Set]: Select a character set that supports the DivX video subtitle (only for DivX videos).
- [Time Search]: Skip to a specific time via the numeric buttons on the remote control.
- [2nd Audio Language]: Select the second audio language (only for Blu-ray discs that support BonusView).
- [2nd Subtitle Language]: Select the second subtitle language (only for Blu-ray discs that support BonusView).
- [Titles]: Select a title.
- [Chapters]: Select a chapter.
- [Angle List]: Select a camera angle.
- [Menus]: Display a disc menu.
- [PIP Selection] : Display a picture-in-picture window (only for Blu-ray discs that support BonusView).
- **[Zoom]** : Zoom into a video picture. Press **◆** to select a zoom factor.
- [Repeat] : Repeat a chapter or title.
- [Repeat A-B] : Mark two points within a chapter for repeat play, or turn off repeat mode.
- [Picture Settings] : Select a predefined color setting.

- Note

• Available video options depend on the video source.

EN 11

Picture options



Access more options during slideshow.

- [Rotate +90]: Rotate a picture 90 degrees clockwise.
- [Rotate -90]: Rotate a picture 90 degrees counter-clockwise.
- **[Zoom]**: Zoom into a picture. Press **◄**▶ to select a zoom factor.
- **[Info]**: Display picture information.
- [Duration per slide]: Set a display interval for a slideshow.
- [Slide Animation]: Select a transition effect for a slideshow.
- [Picture Settings]: Select a predefined color setting.
- [Repeat]: Repeat a selected folder.

Audio options



 ${\sf Press} \coloneqq {\sf repeatedly to cycle through the following options.}$

- Repeat the current track.
- Repeat all the tracks on the disc or folder.
- Play audio tracks in a random loop.
- Turn off a repeat mode.

DivX videos

You can play DivX videos from a disc or a USB storage device. VOD code for DivX

- Before you purchase DivX videos and play them on this player, register this player on www. divx.com using the DivX VOD code.
- Display the DivX VOD code: press ♠, and select [Setup] > [Advanced] > [DivX® VOD Code].

DivX subtitles

- Press **SUBTITLE** to select a language.
- If the subtitle does not appear correctly, change the character set that supports the DivX subtitle. Select a character set: press ≔ , and select [Character Set].

Character set	Languages
[Standard]	English, Albanian, Danish, Dutch, Finnish, French, Gaelic, German, Italian, Kurdish (Latin), Norwegian, Portuguese, Spanish, Swedish, and Turkish
[Central Europe]	Albanian, Croat, Czech, Dutch, English, German, Hungarian, Irish, Polish, Romanian, Slovak, Slovene, and Serbian
[Cyrillic]	Bulgarian, Belorussian, English, Macedonian, Moldavian, Russian, Serbian, and Ukrainian
[Greek]	Greek
	UIECK

Note

- To play DivX DRM protected files from a USB storage device, connect this player to a TV through HDMI.
- . To use the subtitles, make sure that the subtitle file has the same name as the DivX video file name. For
- example, if the DivX video file is named "movie.avi", save the subtitle file as "movie.srt", or "movie.sub". • This player can play subtitle files in the following formats: .srt, .sub, .txt, .ssa, and .smi.

Play a musical slideshow

Play music and pictures simultaneously to create a musical slideshow.

- 1 From a disc or connected USB storage device, play a music file.
- 2 Press 5, and go to the picture folder.
- 3 Select a picture from the same disc or USB, and press **OK** to start slideshow.
- 4 Press to stop slideshow.
- 5 Press again to stop music play.

BonusView on Blu-ray

View special content (such as commentaries) in a small screen window.

This feature is only applicable to Blu-ray discs compatible with BonusView (also known as picture in picture).

- 1 During play, press ≔
 - → The options menu is displayed.
- 2 Select [PIP Selection] > [PIP], and press OK.
 - \mapsto PIP options [1]/[2] depend on the video contents.
 - → The secondary video window is displayed.
- 3 Select [2nd Audio Language] or [2nd Subtitle Language], and press OK.

BD-Live on Blu-ray

Access exclusive online services, such as movie trailers, games, ringtones and other bonus contents. This feature is only applicable to Blu-ray discs that are BD-Live enabled.

- Prepare the Internet connection and set up a network (see "Set up a network").
- 2 Connect a USB storage device to the \leftarrow (USB) connector on this player.
 - A USB storage device is used to store the downloaded BD-Live content.
 - If you connect this player to the Internet through a Wi-Fi USB adapter (sold separately), connect a USB hub (not supplied) to this player to make multiple USB ports available.
 - To delete the BD-Live previously downloaded on the USB storage device for memory release, press ♠ and select [Setup] > [Advanced] > [Clear memory].
- **3** Play a disc that is BD-Live enabled.
- **4** On the disc menu, select the BD-Live icon, and press **OK**.
 - → BD-Live starts to load. The loading time depends on the disc and the Internet connection.
- 5 On the BD-Live interface, select an item to access.

Note

- BD-Live services vary from discs and countries.
- When you use BD-Live, data on the disc and this player are accessed by the content provider
- Use a USB storage device with at least 1GB of free space to store the download.

Play a Blu-ray 3D video

Before you start, make sure that:

- the TV is 3D compliant, and is connected to this player through HDMI
- the disc is a Blu-ray 3D disc
- you have 3D glasses compatible with the TV.
- 1 Make sure that 3D output is turned on: press ♠, and select [Setup] > [Video] > [Watch 3D video] > [Auto].
- 2 Play a Blu-ray 3D video.
- **3** Put on the 3D glasses for 3D effects.
 - To play 3D video in 2D, turn off Blu-ray 3D output (press ♠, and select [Video] > [Watch 3D video] > [Off]).

Set up a network

Connect this player to the Internet to access the services:

- **BD-Live:** access online bonus features (applicable to Blu-ray discs that are BD-Live enabled)
- Update software: update the software of this player via the Internet.
- YouTube: access YouTube website.
- **Picasa:** access Picasa website.

- Note

For wireless connection, you need to use an optional Philips Wi-Fi USB adapter (named WUB1110).
The Wi-Fi USB Adapter (WUB1110) is not included. To purchase this adapter, visit shop.philips.com. If the Philips online shop is not available in your country, please contact Philips customer service. For contact details, go to www.philips.com/support.

- 1 Connect this player to the Internet through wired (Ethernet) or wireless connection.
 - For wired connection, connect a network cable (not supplied) to the LAN port on the rear panel of this player.
 - For Wi-Fi, connect a Philips Wi-Fi USB adapter (named WUB1110) to the ↔ (USB) connector on the front panel of this player.





2 Perform the network installation.

1), Press 🔒.

- 2), Select [Setup], and press OK.
- 3), Select [Network] > [Network Installation], and press OK.
- **4),** Follow the instructions on the TV screen to complete the installation. If necessary, use the Alphanumeric buttons on the remote control to enter a password.

Caution

Before you connect to a network, familiarize yourself with the network router, and networking principles. If necessary, read documentation accompanying network components. Philips is not responsible for lost, damaged or corrupt data.

YouTube videos

With this player connected to the Internet, you can browse, search and watch YouTube videos.

- 1 Connect this player to the Internet (see "Set up a network").
- 2 Press A.
- **3** Select **[YouTube]**, and press **OK**.

→ The default YouTube page is displayed on the TV screen.

- 4 Use the remote control to navigate and select options.
 - To exit YouTube, press **f**.

Button	Action	
▲▼◀►	Press ▲ to display the onscreen keyboard for video search. Press ▼ to display the onscreen play buttons. Press ◀▶ to navigate the onscreen play buttons or the video playlist.	
ОК	Confirm an entry or selection.	
•	Start or resume play.	
	Pause play.	
	Stop play.	
◀ / ▶	Skip to the previous or next video.	
~~ / >>	Skip backward or forward during video play.	

- Note

• If you don't press any button for few seconds, the onscreen buttons and menu disappear.

Picasa (online photos)

With this player, you can access, search and view photos stored in your Picasa Web Albums. What you need

- On your computer, visit www.picasa.com to create an account with Picasa Web Albums.
- Connect this player to the Internet.
- 1 Connect this player to the Internet (see "Set up a network").
- 2 Press A.
- 3 Select [Picasa], and press OK.

→ The default Picasa page is displayed on the TV screen.

- 4 Log in to the Picasa Web Albums with your Picasa web account.
 - For the first time you log in, select "New User".
 - To enter your user name and password, press the alphanumeric keys on the remote control.
- **5** Use the remote control to navigate to select:
 - My Photos: display the photos stored in your Picasa Web Albums.
 - Featured: display the featured photos from Picasa website.
 - Friends: display the list of friends.
 - Search: search photos based on keywords.
 - Favorites: display the favorite photos from your Picasa Web Albums.
 - Tag: display the photos that have been tagged in your Picasa Web Albums.
- 6 To exit the Picasa page, press ♠.

Play a slideshow

- Use the remote control to select "My Photos" from the Picasa page, and press OK.
 → The photos in your Picasa Web Albums are displayed in thumbnails.
- 2 Select a photo, and press OK to view the photo in full screen.
- **3** Press **OK** again to start a photo slideshow.
- 4 During slideshow, press ≔ to access the following options, and then press OK to select an option:
 - Current playing: display the index of the current photo.
 - Slideshow pause/ play: pause or play a slideshow.
 - Rotate: rotate the current photo.
 - Zoom: zoom in or zoom out the photo.
 - Effect: select a slideshow effect.
 - Speed: select a slideshow speed.
 - Friends: add the owner of the current photo to the friends list.
- 5 To return to the previous screen, press 5.

Use Philips EasyLink

This player supports Philips EasyLink which uses the HDMI CEC (Consumer Electronics Control) protocol. You can use a single remote control to control EasyLink compliant devices that are connected through HDMI. Philips does not guarantee 100% interoperability with all HDMI CEC devices.

- 1 Connect the HDMI CEC compliant devices through HDMI, and turn on the HDMI CEC operations on the TV and other connected devices (see the user manual of the TV or other devices for details).
- 2 Press ♠.
- 3 Select [Setup]> [EasyLink].
- 4 Select [On] under the options: [EasyLink], [One Touch Play] and [One Touch Standby].
 → EasyLink function is turned on.

One Touch Play

When you play a disc on this player, the TV automatically switches to the correct video input source.

One Touch Standby

When a connected device (for example TV) is put to standby with its own remote control, this player is put to standby automatically.

3 Change settings

This section helps you to change the settings of this player.





Note

- •
- You cannot change a menu option that is grayed out. To return to the previous menu, press \mathfrak{I} . To exit the menu, press \mathfrak{A} . •

Picture

- 1 Press 🏫.
- 2 Select [Setup] > [Video] to access the video setup options.
- [TV Display]: Select a picture display format to fit the TV screen.
- [HDMI Video]: Select an HDMI video resolution.
- [HDMI Deep Color]: Display colors with more shades and hues when the video content is • recorded in Deep Color and the TV supports this feature.
- [Picture Settings]: Select a predefined color setting.
- [Watch 3D video]: Set to 3D or 2D output when playing a Blu-ray 3D disc. The player must be connected to a 3D TV through HDMI.

B Note

- •
- If you change a setting, make sure that the TV supports the new setting. For settings related to HDMI, the TV must be connected through HDMI. •
- For the composite connection (via the VIDEO connector), select a video resolution of 480i/576i or 480p/576p under **[HDMI Video]** to enable video output. •

Sound

1 Press 🛧.

- 2 Select [Setup] > [Audio] to access the audio setup options.
- **[Night Mode]**: Select quiet or full dynamic sound. Night mode decreases the volume of loud sound and increases the volume of soft sound (such as speech).
- [Neo 6]: Enable or disable a surround sound effect which is converted from 2.0 channel audio.
- **[HDMI Audio]**: Set an HDMI audio format when this player is connected through HDMI.
- [Digital Audio]: Select an audio format for the sound output when this player is connected through a digital connector (coaxial).
- **[PCM Downsampling]**: Set the sampling rate for PCM audio output when this player is connected through a digital connector (coaxial).

Note

For settings related to HDMI, the TV must be connected through HDMI.Night mode is only available for Dolby encoded DVD and Blu-ray discs.

Network (installation, status...)

- 1 Press 🔒.
- 2 Select [Setup] > [Network] to access the network setup options.
- [Network Installation]: Start a wired or wireless installation to make the network work.
- [View Network Settings]: Display the current network status.
- [View Wireless Settings]: Display the current Wi-Fi status.

Preference (languages, parental control...)

1 Press 🔒.

- 2 Select [Setup] > [Preference] to access the preference setup options.
- [Menu language]: Select an onscreen display menu language.
- [Audio]: Select an audio language for video.
- [Subtitle]: Select a subtitle language for video.
- [Disc Menu]: Select a menu language for a video disc.
- [Parental Control]: Restrict access to discs that are encoded with ratings. Input "0000" to access the restriction options. To play all discs irrespective of the rating, select level "8".
- [Screen Saver]: Enable or disable screen saver mode. If enabled, the screen enters idle mode after 10 minutes of inactivity (for example, in pause or stop mode).
- [Auto Subtitle Shift]: Enable or disable subtitle shift. If enabled, the subtitle position is changed automatically to fit the TV screen (this feature works with some Philips TVs only).
- [Change Password]: Set or change a password to play a restricted disc. Input "0000" if you do not have a password or if you have forgotten your password.

- [Display Panel]: Change the brightness of the display panel of the player.
- **[Auto Standby]**: Enable or disable auto standby. If enabled, the player switches to standby after 30 minutes of inactivity (for example, in pause or stop mode).
- [VCD PBC]: Display or skip the content menu for VCD and SVCD.

English

- Note

- If your preferred language is not available for disc language, audio or subtitle, you can select [Other] from
- the menu options and input 4-digit language code which can be found at the back of this user manual. • If you select a language which is not available on a disc, this player uses the default language of the disc.

Advanced options (clear memory...)

- 1 Press 🔒.
- 2 Select [Setup] > [Advanced] to access the advanced setup options.
- **[BD-Live Security]**: Restrict or allow access to BD-Live (only for non-commercial, userscreated BD-Live discs).
- [Software Update]: Select to update software from a network or from USB storage device.
- [Clear memory]: Delete the previous BD-Live download on the USB storage device. A "BUDA" folder is automatically created to store the BD-Live download.
- [DivX® VOD Code]: Display the DivX® registration code or the deregistration code for this player.
- [Version Info.]: Display the software version of this player.
- [Restore default settings]: Reset this player to the default settings made at the factory.

- Note

- You cannot restrict Internet access on commercial Blu-ray discs.
- Before you purchase DivX videos and play them on this player, register this player on www.divx.com with the DivX VOD code.
- You cannot reset a parental control setting to the default value.

4 Update software

Before you update the software of this player, check the current software version:

• Press ♠, and then select [Setup] > [Advanced] > [Version Info.], and press OK.

Update software via the Internet

- 1 Connect the player to the Internet (see "Set up a network").
- 2 Press A, and select [Setup].
- 3 Select [Advanced] > [Software Update] > [Network].
 → If an upgrade media is detected, you are prompted to start the update.
- 4 Follow the instructions on the TV screen to update the software.
 → When the update is complete, this player automatically turns off and on again.

Update software via USB

- Check the latest software version on www.philips.com/support.
 Search for your model and click on "Software and drivers".
- 2 Download the software into a USB storage device.
 - (1) Unzip the download, and make sure that the unzipped folder is named "UPG_ALL".
 - (2) Put the "UPG_ALL" folder in the root directory.
- 3 Connect the USB storage device to the ⊷↔ (USB) connector on this player.
- 4 Press ♠, and select [Setup].
- 5 Select [Advanced] > [Software Update] > [USB].
 - → If an upgrade media is detected, you are prompted to start the update.
- 6 Follow the instructions on the TV screen to update the software.
 → When the update is complete, this player automatically turns off and on again.

Caution

• Do not turn off the power or remove the USB storage device when the software update is in progress because you might damage this player.

5 Specifications

English

- Note

• Specifications are subject to change without notice

Region code

This player can play discs with the following region codes.

DVD	Blu-ray	Countries Europe, United Kingdom	
		Lurope, Onited Kingdom	

Playable media

- BD-Video
- DVD-Video, DVD+R/+RW, DVD-R/-RW, DVD+R/-R DL (Dual Layer)
- VCD/SVCD
- Audio CD, CD-R/CD-RW, MP3 media, WMA media, JPEG files
- DivX (Ultra)/DivX Plus HD media, MKV media
- USB storage device

File format

- Video: .avi, .divx, .mp4, .mkv
- Audio: .mp3, .wma, .wav
- Picture: .jpg, .gif, .png

Video

- Signal system: PAL / NTSC
- Composite video output: 1 Vp-p (75 ohm)
- HDMI output 480p, 576p, 720p, 1080i, 1080p, 1080p24

Audio

- 2 Channel analog output
- Audio Front L&R : 2 Vrms (> 1 kohm)
- Digital output: 0.5 Vp-p (75 ohm)
 - Coaxial
 - HDMI output
- Sampling frequency:
 - MP3: 32 kHz, 44.1 kHz, 48 kHz
 - WMA: 44.1 kHz, 48 kHz
- Constant bit rate:
 - MP3: 112 kbps 320 kpbs
 - WMA: 48 kpbs 192 kpbs

USB

- Compatibility: Hi-Speed USB (2.0)
- Class support: USB Mass Storage Class (UMS)
- File system: FAT16, FAT32
- Support HDD (a portable hard disc drive): an external power source may be needed.

Main unit

- Power supply rating: AC 100-240V~, 50/60 Hz
- Power consumption: 18 W
- Power consumption in standby mode: < 0.5 W
- Dimensions (w x h x d): 435 x 41 x 195.5 (mm)
- Net Weight: 1.4 kg

Accessories supplied

- Remote control and batteries
- An HDMI cable
- User manual

Optional accessory

- A wireless Philips USB adapter(named WUB1110, sold separately)
- Multimedia connections: Wi-Fi 802.11b/g/n
- Connectivity: Rear connection (USB)
- Ambient temperature: 5 deg C to 40 deg C.
- Dongle dimensions (W x H x D): 28.4 x 82 x 13.4 mm

Laser Specification

- Laser Type (Diode): AlGalnN (BD), AlGalnP (DVD/CD)
- Wave length: 405+7nm/-7nm (BD), 655+10nm/-10nm (DVD), 790+10/-20nm (CD)
- Output power: 1mW (BD), 0.26mW (DVD), 0.3mW (CD)

6 Troubleshooting

Warning

• Risk of electric shock. Never remove the casing of the player.

To keep the warranty valid, never try to repair the player yourself.

If you have problems using this player, check the following points before you request service. If you still have a problem, register your player and get support at www.philips.com/welcome.

If you contact Philips, you will be asked for the model and serial number of this player. The model number and serial number are on the back of this player. Write the numbers here:

Model No. _

Serial No. _

Main unit

The buttons on this player do not work.

• Disconnect this player from the power supply for a few minutes, and then reconnect.

Picture

No picture.

- Make sure that the TV is switched to the correct source input for this player.
- For the composite connection (via the VIDEO connector) to the TV, on this player select a video resolution of 480i/576i or 480p/576p under [HDMI Video] to enable video output.

No picture on HDMI connection.

- Make sure that the HDMI cable is not faulty. If it is faulty, replace with a new HDMI cable.
- If this player is connected to an unauthorized display device with an HDMI cable, the audio and video signals may not be output.

The disc does not play high-definition video.

- Make sure that the disc contains high-definition video.
- Make sure that the TV supports high-definition video.

Sound

No audio output from the TV.

- Make sure that the audio cables are connected to the audio input of the TV.
- Make sure that the TV is switched to the correct source input for this player.
- No audio output from the loudspeakers of the external audio device (home theater or amplifier).
- Make sure that the audio cables are connected to the audio input of the audio device.
- Switch the external audio device to the correct audio source input.

No sound on HDMI connection.

 You may not hear any sound from the HDMI output if the connected device is non-HDCP compliant or only DVI-compatible.

No secondary audio output for picture-in-picture feature.

 When [Bitstream] under the [HDMI Audio] or [Digital Audio] menu is selected, interactive sound like secondary sound for picture-in-picture feature is muted. Deselect [Bitstream].

Play

Cannot play a disc.

- Clean the disc.
- Make sure that the disc is correctly loaded.
- Make sure that this player supports the disc. See "Specifications".
- Make sure that this player supports the region code of the DVD or BD.
- For DVD±RW or DVD±R, make sure that the disc is finalized.

Cannot play DivX video files.

- Make sure that the DivX video file is complete.
- Make sure that the video file name extension is correct.
- To play DivX DRM protected files from a USB storage device, connect this player to a TV through HDMI.

DivX subtitles do not display correctly.

- Make sure that the subtitle file has the same name as the DivX video file.
- Make sure that the subtitle file has an extension name supported by this player (.srt, .sub, .txt, .ssa, or .smi).

Cannot read the contents of a connected USB storage.

- Make sure that the format of the USB storage device is compatible with this player.
- Make sure that the file system on the USB storage device is supported by this player.
- For a portable hard disc drive (HDD), an external power source may be needed.

'No entry' or 'x' sign appears on the TV.

• The operation is not possible.

EasyLink feature does not work.

• Make sure that this player is connected to the Philips brand EasyLink TV, and the EasyLink option is turned on (see "Use your Blu-ray disc/ DVD player" > "Use Philips EasyLink").

Cannot access BD-Live features.

- Make sure that this player is connected to the network (see "Use your Blu-ray disc/ DVD player" > "Set up a network").
- Make sure that the network installation is made (see "Use your Blu-ray disc/ DVD player" > "Set up a network").
- Make sure that the Blu-ray disc supports BD-Live features.
- Clear memory storage (see "Change settings" > "Advanced options (clear memory...)").

Network

Wireless network is not found or distorted.

- Make sure that the network is correctly connected (see "Use your Blu-ray disc/ DVD player" > "Set up a network").
- Make sure that the network installation is made (see "Use your Blu-ray disc/ DVD player" > "Set up a network").
- Make sure that the wireless network is not disturbed by microwave ovens, DECT phones, or other neighboring Wi-Fi devices.
- If the wireless network does not work properly, try a wired network installation (see "Use your Blu-ray disc/ DVD player" > "Set up a network").

YouTube and Picasa do not work.

- Make sure that the network is correctly connected (see "Use your Blu-ray disc/ DVD player" > "Set up a network").
- Make sure that the network installation is made (see "Use your Blu-ray disc/ DVD player" > "Set up a network").
- Check the router connection (refer to the user manual for the router).

YouTube and Picasa work slowly.

- Look in your wireless router's user manual for information on indoor range, transfer rate, and other factors of signal quality.
- You need a high speed Internet connection for your router.

3D videos

Cannot see 3D effects

- Make sure that 3D output is turned on(see "Use your Blu-ray disc/ DVD player" > "Play a Blu-ray 3D video").
- Make sure that the disc title being played is Blu-ray 3D compliant.
- Make sure that the TV is 3D and HDMI compliant, and the TV is set to 3D mode (refer to the TV's user manual).
- Make sure that the 3D glasses are activated (refer to the TV's user manual).

7 Safety and important notice

Read and understand all instructions before you use this Blu-ray disc/ DVD player. If damage is caused by failure to follow the instructions, the warranty does not apply.

Safety

Risk of electric shock or fire!

- Never expose the product and accessories to rain or water. Never place liquid containers, such as vases, near the product. If liquids are spilt on or into the product, disconnect it from the power outlet immediately. Contact Philips Consumer Care to have the product checked before use.
- Never place the product and accessories near naked flames or other heat sources, including direct sunlight.
- Never insert objects into the ventilation slots or other openings on the product.
- Where the mains plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
- Disconnect the product from the power outlet before lightning storms.
- When you disconnect the power cord, always pull the plug, never the cable.

Risk of short circuit or fire!

Before you connect the product to the power outlet, make sure that the power voltage
matches the value printed on the back or bottom of the product. Never connect the product
to the power outlet if the voltage is different.

Risk of injury or damage to the product!

- Visible and invisible laser radiation when open. Avoid exposure to beam.
- Do not touch the disc optical lens inside the disc compartment.
- Never place the product or any objects on power cords or on other electrical equipment.
- If the product is transported in temperatures below 5°C, unpack the product and wait until its
- temperature matches room temperature before connecting it to the power outlet.

Risk of overheating!

• Never install this product in a confined space. Always leave a space of at least four inches around the product for ventilation. Make sure that curtains or other objects never cover the ventilation slots on the product.

Risk of contamination!

- Do not mix batteries (old and new or carbon and alkaline, etc.).
- Remove batteries if they are exhausted or if the remote control is not to be used for a long time.
- Batteries contain chemical substances, so they should be disposed of properly.

Risk of swallowing batteries!

- The product/remote control may contain a coin type battery, which can be swallowed.
- Keep the battery out of reach of children at all times!



28 EN

3D health warning

- If you or your family has a history of epilepsy or photosensitive seizures, consult a medical professional before exposing yourself to flashing light sources, rapid image sequences or 3D viewing.
- To avoid discomfort such as dizziness, headache or disorientation, we recommend not watching 3D for extended periods of time. If you experience any discomfort, stop watching 3D and do not immediately engage in any potentially hazardous activity (for example driving a car) until your symptoms have disappeared. If symptoms persist, do not resume watching 3D without consulting a medical professional first.
- Parents should monitor their children during 3D viewing and ensure they do not experience any discomfort as mentioned above. Watching 3D is not recommended for children under 6 years of age as their visual system is not fully developed yet.

Important notes for users in the U.K.

Mains fuse

This information applies only to products with a UK mains plug.

- This product is fitted with an approved non-molded plug. If you replace the fuse, use one with:
- the ratings shown on the plug,
- a BS 1362 approval, and
- the ASTA approval mark.

Contact your dealer if you are not sure about what type of fuse to use. Caution: To conform with the EMC directive (2004/108/EC), do not detach the plug from the power cord.

How to connect a plug

The wires in the power cord are colored as follows: blue = neutral (N), brown = live (L). If the colors do not correspond with the colors on your plug, identify the terminals in your plug as follows:

- 1 Connect the blue wire to the terminal marked N or colored black.
- 2 Connect the brown wire to the terminal marked L or colored red.
- **3** Do not connect either wire to the earth terminal in the plug, marked E (or e) or colored green (or green and yellow).

Before you replace the plug cover, make sure that the cord grip is clamped over the sheath of the cable and not just over the two wires in the cable.

Care for your product

- Do not insert any objects other than discs into the disc compartment.
- Do not insert warped or cracked discs into the disc compartment.
- Remove discs from the disc compartment if you are not using the product for an extended period of time.
- Only use microfiber cloth to clean the product.

Care of the environment

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



When this crossed-out wheeled bin symbol is attached to a product it means that the product is covered by the European Directive 2002/96/EC. Please inform yourself about the local separate collection system for electrical and electronic products.

Please act according to your local rules and do not dispose of your old products with your normal household waste. Correct disposal of your old product helps to prevent potential negative consequences for the environment and human health.

Your product contains batteries covered by the European Directive 2006/66/EC, which cannot be disposed with normal household waste.

Please inform yourself about the local rules on separate collection of batteries because correct disposal helps to prevent negative consequences for the environmental and human health.

Compliance

C This product complies with the radio interference requirements of the European Community.

Copyright

Be responsible Respect copyrights

This item incorporates copy protection technology that is protected by U.S. patents and other intellectual property rights of Rovi Corporation. Reverse engineering and disassembly are prohibited. **Open source software**

Philips Electronics Hong Kong Ltd. hereby offers to deliver, upon request, a copy of the complete corresponding source code for the copyrighted open source software packages used in this product for which such offer is requested by the respective licenses.

This offer is valid up to three years after product purchase to anyone in receipt of this information. To obtain source code, please contact <u>open.source@philips.com</u>. If you prefer not to use email or if you do not receive confirmation receipt within a week after mailing to this email address, please write to "Open Source Team, Philips Intellectual Property & Standards, PO. Box 220, 5600 AE Eindhoven, The Netherlands." If you do not receive timely confirmation of your letter, please email to the email address above.

Trademarks



Blu-ray Disc **3D** TM 'Blu-ray', 'Blu-ray Disc', 'Blu-ray Disc' logo, 'Blu-ray 3D' and 'Blu-ray 3D' logo are the trademarks of Blu-ray Disc Association.

HDMI, and HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI licensing LLC in the United States and other countries.

DIGITAL PLUS Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.

Master Audio Manufactured under license under U.S. Patent #'s: 5,451,942; 5,956,674; 5,974,380; 5,978,762; 6,226,616; 6,487,535; 7,212,872; 7,333,929; 7,392,195; 7,272,567 & other U.S. and worldwide patents issued & pending. DTS and the Symbol are registered trademarks, & DTS-HD, DTS-HD Master Audio, and the DTS logos are trademarks of DTS, Inc. Product includes software. © DTS, Inc. All Rights Reserved.

DIVX+

HD ABOUT DIVX VIDEO: DivX[®] is a digital video format created by DivX, Inc. This is an official DivX Certified[®] device that plays DivX video. Visit divx.com for more information and software tools to convert your files into DivX video.

ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified[®] device must be registered in order to play purchased DivX Video-on-Demand (VOD) movies. To obtain your registration code, locate the DivX VOD section in your device setup menu. Go to vod.divx.com for more information on how to complete your registration.

DivX[®], DivX Certified[®], DivX Plus[™] HD and associated logos are registered trademarks of DivX, Inc. and are used under license.

DivX Certified® to play DivX® and DivX PlusTM HD (H.264/MKV) video up to 1080p HD including premium content.



BONUSVIEW™ 'BD LIVE' and 'BONUSVIEW' are trademarks of Blu-ray Disc Association.

32 EN



'DVD Video' is a trademark of DVD Format/Logo Licensing Corporation.

Java and all other Java trademarks and logos are trademarks or registered trademarks of Sun

Microsystems, Inc. in the United States and/or other countries.

Language Code

Abkhazian	6566
Afar	6565
Afrikaans	6570
Amharic	6577
Arabic	6582
Armenian	7289
Assamese	6583
Avestan	6569
Aymara	6589
Azerhaijani Bahasa Malawa	6590
Bahasa Melayu Bashkir	7783 6665
Belarusian	6669
Bengali	6678
Bihari	6672
Bislama	6673
Bokmål, Norwegian	7866
Bosanski	6683
Brezhoneg	6682
Bulgarian	6671
Burmese	7789
Castellano, Español	6983
Catalán	6765
Chamorro	6772
Chechen	6769
Chewa; Chichewa; Nyanj	
中文	9072
Chuang; Zhuang	9065
Church Slavic; Slavonic	6785
Chuvash	6786
Corsican	6779
Česky	6783
Dansk	6865
Deutsch	6869
Dzongkha	6890
English	6978
Esperanto	6979
Estonian	6984
Euskara	6985
Ελληνικά	6976
Faroese	7079
Français	7082
Frysk	7089
Fijian	7074
Gaelic; Scottish Gaelic	7168
Gallegan	7176
Georgian	7565
Gikuyu; Kikuyu	7573
Guarani	7178
Gujarati	7185
Hausa	7265
Herero	7290
Hindi	7273
Hiri Motu	7279
Hrwatski	6779
Ido	7379
Interlingua (Internationa	
Interlingue	7365
Inuktitut	7385

Inupiaq	7375
Irish	7165
Islenska	7383
Italiano	7384
lvrit	7269
Japanese	7465
Javanese	7486
Kalaallisut	7576
Kannada	7578
Kashmiri	7583
Kazakh	7575
Kernewek	7587
Khmer	7577
Kinyarwanda	8287
Kirghiz	7589
Komi	7586
Korean	7579
Kuanyama; Kwanyama	7574
Kurdish	7585
Lao	7679
Latina	7665
Latvian	7686
Letzeburgesch;	7666
Limburgan; Limburger	7673
Lingala	7678
Lithuanian	7684
Luxembourgish;	7666
Macedonian	7775
Malagasy	777
Magyar	7285
Malayalam	7776
Maltese	7784
Manx	7186
Maori	7773
Marathi	7782
Marshallese	7772
Moldavian	7779
Mongolian	7778
Nauru	7865
Navaho; Navajo	7886
Ndebele, North	7868
Ndebele, South	7882
Ndonga	787
Nederlands	7876
Nepali	7869
Norsk	7879
Northern Sami	8369
North Ndebele	7868
Norwegian Nynorsk;	7878
Occitan; Provencal	7967
Old Bulgarian; Old Slavonic	6785
Oriya	7982
Oromo	7977
Ossetian; Ossetic	7983
Pali	8073
Panjabi	8065
Persian	7065
Polski	8076
Português	8084

Pushto	8083
Russian	8285
Quechua	8185
Raeto-Romance	8277
Romanian	8279
Rundi	8278
Samoan	8377
Sango	8371
Sanskrit	8365
Sardinian	8367
Serbian	8382
Shona Shoria	8378
Shqip Sindhi	8381 8368
Sinhalese	
Slovensky	8373 8373
Slovenian	8376
Somali	8379
Sotho; Southern	8384
South Ndebele	7882
Sundanese	8385
Suomi	7073
Swahili	8387
Swati	8383
Svenska	8386
Tagalog	8476
Tahitian	8489
Tajik	8471
Tamil	8465
Tatar	8484
Telugu	8469
Thai	8472
Tibetan	6679
Tigrinya	8473
Tonga (Tonga Islands)	8479
Tsonga	8483
Tswana	8478
Türkçe	8482
Turkmen	8475
Twi	8487
Uighur	8571
Ukrainian	8575
Urdu	8582
Uzbek	8590
Vietnamese	8673
Volapuk Walloon	8679 8765
Welsh	6789
Wolof	
Xhosa	8779 8872
Yiddish	8973
Yoruba	8979
Zulu	9085

icense Texts and Acknowledgements for any open source software used ir this Philips product

structions to obtain source code for this software can be found in the user manual, or in the supplied safety leaflet (if vailable).

. U-boot

(C) Copyright 2000 - 2008 Wolfgang Denk, DENX Software Engineering, wd@denx.de.

See file CREDITS for list of people who contributed to this project.

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

copy of the GPL is included below at item 2.

. Linux kernel

IOTE! This copyright does *not* cover user programs that use kernel services by normal system calls - this is merely onsidered normal use of the kernel, and does *not* fall under the heading of "derived work". Iso note that the GPL below is copyrighted by the Free Software Foundation, but the instance of code that it refers to he linux kernel) is copyrighted by me and others who actually wrote it. Iso note that the only valid version of the GPL as far as the kernel is concerned is _this_ particular version of the ense (ie v2, not v2.2 or v3.x or whatever), unless explicitly otherwise stated.

Linus Torvalds

GNU GENERAL PUBLIC LICENSE Version 2, June 1991 Copyright (C) 1989, 1991 Free Software Foundation, Inc. 675 Mass Ave, Cambridge, MA 02139, USA

veryone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed. **Preamble**

he licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU ieneral Public License is intended to guarantee your freedom to share and change free software--to make sure the oftware is free for all its users. This General Public License applies to most of the Free Software Foundation's software nd to any other program whose authors commit to using it. (Some other Free Software Foundation software is overed by the GNU Library General Public License instead.) You can apply it to your programs, too.

Vhen we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to take sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that ou receive source code or can get it if you want it, that you can change the software or use pieces of it in new free rograms; and that you know you can do these things.

o protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to urrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the oftware, or if you modify it.

or example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the ghts that you have. You must make sure that they, too, receive or can get the source code. And you must show them rese terms so they know their rights.

Ve protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal ermission to copy, distribute and/or modify the software.

.lso, for each author's protection and ours, we want to make certain that everyone understands that there is no arranty for this free software. If the software is modified by someone else and passed on, we want its recipients to now that what they have is not the original, so that any problems introduced by others will not reflect on the original uthors' reputations.

nally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors f a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we ave made it clear that any patent must be licensed for everyone's free use or not licensed at all.

he precise terms and conditions for copying, distribution and modification follow.

GNU GENERAL PUBLIC LICENSE

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modification: and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification"). Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; anc give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

- You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:
- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date o any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensee sected to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

- You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:
- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- c) Accompany it with the information you received as to the offer to distribute corresponding source code. (Thi alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

- . You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under thi License will not have their licenses terminated so long as such parties remain in full compliance.
- . You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program) you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.
- Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradic the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

0. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

- 1. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.
- 2. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

Appendix: How to Apply These Terms to Your New Programs

you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve is is to make it free software which everyone can redistribute and change under these terms.

o do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most ffectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to 'here the full notice is found.

one line to give the program's name and a brief idea of what it does.>

opyright (C) 19yy <name of author>

his program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public cense as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later ersion.

his program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the nplied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public cense for more details.

ou should have received a copy of the GNU General Public License along with this program; if not, write to the Free oftware Foundation, Inc., 675 Mass Ave, Cambridge, MA 02139, USA.

.Iso add information on how to contact you by electronic and paper mail.

the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) 19yy name of author

Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type `show w'.

This is free software, and you are welcome to redistribute it under certain conditions; type `show c' for details.

he hypothetical commands `show w' and `show c' should show the appropriate parts of the General Public License. If course, the commands you use may be called something other than `show w' and `show c'; they could even be nouse-clicks or menu items--whatever suits your program.

ou should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" or the program, if necessary. Here is a sample; alter the names:

oyodyne, Inc., hereby disclaims all copyright interest in the program 'Gnomovision' (which makes passes at compilers) ritten by James Hacker.

signature of Ty Coon>, 1 April 1989

y Coon, President of Vice

his General Public License does not permit incorporating your program into proprietary programs. If your program is subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is that you want to do, use the GNU Library General Public License instead of this License.

. Busybox, the Linux IR control package and SquashFS

usybox, the Linux IR control package and SquashFS are subject to the GPL, a copy of which is included at item 2.

. DirectFB, glibc, libusb-compat, libusb and mtd-utils

virectFB glibc, libmtp and libusb are subject to the following license:

GNU LESSER GENERAL PUBLIC LICENSE Version 2.1, February 1999

version 2.1, redruary 1

opyright (C) 1991, 1999 Free Software Foundation, Inc.

9 Temple Place, Suite 330, Boston, MA 02111-1307 USA

veryone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed. This is the first released version of the Lesser GPL. It also counts as the successor of the GNU Library Public License, ersion 2, hence the version number 2.1.]

Preamble

he licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU ieneral Public Licenses are intended to guarantee your freedom to share and change free software--to make sure the oftware is free for all its users.

his license, the Lesser General Public License, applies to some specially designated software packages--typically praries--of the Free Software Foundation and other authors who decide to use it. You can use it too, but we suggest pu first think carefully about whether this license or the ordinary General Public License is the better strategy to use in ny particular case, based on the explanations below.

Vhen we speak of free software, we are referring to freedom of use, not price. Our General Public Licenses are esigned to make sure that you have the freedom to distribute copies of free software (and charge for this service if ou wish); that you receive source code or can get it if you want it; that you can change the software and use pieces of in new free programs; and that you are informed that you can do these things.

o protect your rights, we need to make restrictions that forbid distributors to deny you these rights or to ask you o surrender these rights. These restrictions translate to certain responsibilities for you if you distribute copies of the prary or if you modify it.

or example, if you distribute copies of the library, whether gratis or for a fee, you must give the recipients all the rights nat we gave you. You must make sure that they, too, receive or can get the source code. If you link other code with ne library, you must provide complete object files to the recipients, so that they can relink them with the library after naking changes to the library and recompiling it. And you must show them these terms so they know their rights.

Ve protect your rights with a two-step method: (1) we copyright the library, and (2) we offer you this license, which ves you legal permission to copy, distribute and/or modify the library.

o protect each distributor, we want to make it very clear that there is no warranty for the free library. Also, if the prary is modified by someone else and passed on, the recipients should know that what they have is not the original ersion, so that the original author's reputation will not be affected by problems that might be introduced by others.

nally, software patents pose a constant threat to the existence of any free program. We wish to make sure that a ompany cannot effectively restrict the users of a free program by obtaining a restrictive license from a patent holder. herefore, we insist that any patent license obtained for a version of the library must be consistent with the full eedom of use specified in this license.

lost GNU software, including some libraries, is covered by the ordinary GNU General Public License. This license, ne GNU Lesser General Public License, applies to certain designated libraries, and is quite different from the ordinary ieneral Public License. We use this license for certain libraries in order to permit linking those libraries into non-free rograms.

Vhen a program is linked with a library, whether statically or using a shared library, the combination of the two is gally speaking a combined work, a derivative of the original library. The ordinary General Public License therefore

ermits such linking only if the entire combination fits its criteria of freedom. The Lesser General Public License permit tore lax criteria for linking other code with the library.

Ve call this license the "Lesser" General Public License because it does Less to protect the user's freedom than the rdinary General Public License. It also provides other free software developers Less of an advantage over competing on-free programs. These disadvantages are the reason we use the ordinary General Public License for many libraries. lowever, the Lesser license provides advantages in certain special circumstances.

or example, on rare occasions, there may be a special need to encourage the widest possible use of a certain library, o that it becomes a de-facto standard. To achieve this, non-free programs must be allowed to use the library. A more equent case is that a free library does the same job as widely used non-free libraries. In this case, there is little to gain y limiting the free library to free software only, so we use the Lesser General Public License.

I other cases, permission to use a particular library in non-free programs enables a greater number of people to use large body of free software. For example, permission to use the GNU C Library in non-free programs enables many lore people to use the whole GNU operating system, as well as its variant, the GNU/Linux operating system.

Ithough the Lesser General Public License is Less protective of the users' freedom, it does ensure that the user of program that is linked with the Library has the freedom and the wherewithal to run that program using a modified ersion of the Library.

he precise terms and conditions for copying, distribution and modification follow. Pay close attention to the difference etween a "work based on the library" and a "work that uses the library". The former contains code derived from the prary, whereas the latter must be combined with the library in order to run.

GNU LESSER GENERAL PUBLIC LICENSE

ERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

. This License Agreement applies to any software library or other program which contains a notice placed by the copyright holder or other authorized party saying it may be distributed under the terms of this Lesser General Public License (also called "this License").

Each licensee is addressed as "you".

A "library" means a collection of software functions and/or data prepared so as to be conveniently linked with application programs (which use some of those functions and data) to form executables.

The "Library", below, refers to any such software library or work which has been distributed under these terms. A "work based on the Library" means either the Library or any derivative work under copyright law: that is to say, a work containing the Library or a portion of it, either verbatim or with modifications and/or translated straightforwardly into another language. (Hereinafter, translation is included without limitation in the term "modification")

"Source code" for a work means the preferred form of the work for making modifications to it. For a library, complete source code means all the source code for all modules it contains, plus any associated interface definitior files, plus the scripts used to control compilation and installation of the library.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running a program using the Library is not restricted, and output from such a program is covered only if its contents constitute a work based on the Library (independent of the use of the Library in a tool for writing it). Whether that is true depends on what the Library does and what the program that uses the Library does.

You may copy and distribute verbatim copies of the Library's complete source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty and distribute a copy of this License along with the Library.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

- You may modify your copy or copies of the Library or any portion of it, thus forming a work based on the Library, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:
- a) The modified work must itself be a software library.
- b) You must cause the files modified to carry prominent notices stating that you changed the files and the date o any change.
- c) You must cause the whole of the work to be licensed at no charge to all third parties under the terms of this License.

d) If a facility in the modified Library refers to a function or a table of data to be supplied by an application program that uses the facility, other than as an argument passed when the facility is invoked, then you must make a good faith effort to ensure that, in the event an application does not supply such function or table, the facility still operates, and performs whatever part of its purpose remains meaningful.
 (For example, a function in a library to compute square roots has a purpose that is entirely well-defined

(For example, a function in a library to compute square roots has a purpose that is entirely well-defined independent of the application. Therefore, Subsection 2d requires that any application-supplied function or table used by this function must be optional: if the application does not supply it, the square roots function must still compute square roots.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Library, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Library, the distribution of the whole must be on the terms of this License, whose permissions for other licensee extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather the intent is to exercise the right to control the distribution of derivative or collective works based on the Library.

In addition, mere aggregation of another work not based on the Library with the Library (or with a work based on the Library) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

. You may opt to apply the terms of the ordinary GNU General Public License instead of this License to a given copy of the Library. To do this, you must alter all the notices that refer to this License, so that they refer to the ordinary GNU General Public License, version 2, instead of to this License. (If a newer version than version 2 of the ordinary GNU General Public License has appeared, then you can specify that version instead if you wish.) Do not make any other change in these notices.

Once this change is made in a given copy, it is irreversible for that copy, so the ordinary GNU General Public License applies to all subsequent copies and derivative works made from that copy.

This option is useful when you wish to copy part of the code of the Library into a program that is not a library.

. You may copy and distribute the Library (or a portion or derivative of it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange.

If distribution of object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place satisfies the requirement to distribute the source code, even though third parties are not compelled to copy the source along with the object code.

A program that contains no derivative of any portion of the Library, but is designed to work with the Library by being compiled or linked with it, is called a "work that uses the Library". Such a work, in isolation, is not a derivative work of the Library, and therefore falls outside the scope of this License.

However, linking a "work that uses the Library" with the Library creates an executable that is a derivative of the Library (because it contains portions of the Library), rather than a "work that uses the library". The executable is therefore covered by this License.

Section 6 states terms for distribution of such executables.

When a "work that uses the Library" uses material from a header file that is part of the Library, the object code for the work may be a derivative work of the Library even though the source code is not. Whether this is true is especially significant if the work can be linked without the Library, or if the work is itself a

library. The threshold for this to be true is not precisely defined by law.

If such an object file uses only numerical parameters, data structure layouts and accessors, and small macros and small inline functions (ten lines or less in length), then the use of the object file is unrestricted, regardless of whether it is legally a derivative work. (Executables containing this object code plus portions of the Library will stil fall under Section 6.)

Otherwise, if the work is a derivative of the Library, you may distribute the object code for the work under the terms of Section 6.

Any executables containing that work also fall under Section 6, whether or not they are linked directly with the Library itself.

. As an exception to the Sections above, you may also combine or link a "work that uses the Library" with the Library to produce a work containing portions of the Library, and distribute that work under terms of your choice, provided that the terms permit modification of the work for the customer's own use and reverse engineering for debugging such modifications.

You must give prominent notice with each copy of the work that the Library is used in it and that the Library and its use are covered by this License. You must supply a copy of this License. If the work during execution displays copyright notices, you must include the copyright notice for the Library among them, as well as a reference directing the user to the copy of this License. Also, you must do one of these things:

- a) Accompany the work with the complete corresponding machine-readable source code for the Library including whatever changes were used in the work (which must be distributed under Sections 1 and 2 above); and, if the work is an executable linked with the Library, with the complete machine-readable "work that uses the Library", as object code and/or source code, so that the user can modify the Library and then relink to produce a modified executable containing the modified Library. (It is understood that the user who changes the contents of definitions files in the Library will not necessarily be able to recompile the application to use the modified definitions.)
- b) Use a suitable shared library mechanism for linking with the Library. A suitable mechanism is one that (1) uses at run time a copy of the library already present on the user's computer system, rather than copying library functions into the executable, and (2) will operate properly with a modified version of the library, if the user installs one, as long as the modified version is interface-compatible with the version that the work was made with.
- c) Accompany the work with a written offer, valid for at least three years, to give the same user the materials specified in Subsection 6a, above, for a charge no more than the cost of performing this distribution.
- d) If distribution of the work is made by offering access to copy from a designated place, offer equivalent access to copy the above specified materials from the same place.
- e) Verify that the user has already received a copy of these materials or that you have already sent this user a copy.

For an executable, the required form of the "work that uses the library" must include any data and utility program needed for reproducing the executable from it. However, as a special exception, the materials to be distributed need not include anything that is normally distributed (in either source or binary form) with the major component (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

It may happen that this requirement contradicts the license restrictions of other proprietary libraries that do not normally accompany the operating system. Such a contradiction means you cannot use both them and the Library together in an executable that you distribute.

You may place library facilities that are a work based on the Library side-by-side in a single library together with other library facilities not covered by this License, and distribute such a combined library, provided that the separate distribution of the work based on the Library and of the other library facilities is otherwise permitted, and provided that you do these two things:

- a) Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities. This must be distributed under the terms of the Sections above.
- b) Give prominent notice with the combined library of the fact that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.
- . You may not copy, modify, sublicense, link with, or distribute the Library except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, link with, or distribute the Library is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.
- You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Library or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Library (or any work based on the Library), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Library or works based on it.
- D. Each time you redistribute the Library (or any work based on the Library), the recipient automatically receives a license from the original licensor to copy, distribute, link with or modify the Library subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties with this License.
- If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradic the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Library at all. For example, if a patent license would not permit royalty-

free redistribution of the Library by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Library.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply, and the section as a whole is intended to apply in other circumstances. It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

- 2. If the distribution and/or use of the Library is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Library under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.
- 3. The Free Software Foundation may publish revised and/or new versions of the Lesser General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Library specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Library does not specify a license version number, you may choose any version ever published by the Free Software Foundation.

4. If you wish to incorporate parts of the Library into other free programs whose distribution conditions are incompatible with these, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation, write to the Software Foundation, we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

- 5. BECAUSE THE LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE LIBRARY, TC THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE LIBRARY "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE LIBRARY IS WITH YOU. SHOULD THE LIBRARY PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.
- 5. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE LIBRARY AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE LIBRARY (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE LIBRARY TO OPERATE WITH ANY OTHER SOFTWARE), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Libraries

you develop a new library, and you want it to be of the greatest possible use to the public, we recommend making it ee software that everyone can redistribute and change. You can do so by permitting redistribution under these terms or, alternatively, under the terms of the ordinary General Public License).

o apply these terms, attach the following notices to the library. It is safest to attach them to the start of each source e to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a ointer to where the full notice is found.

one line to give the library's name and a brief idea of what it does.>

opyright (C) <year> <name of author>

his library is free software; you can redistribute it and/or modify it under the terms of the GNU Lesser General Public cense as published by the Free Software Foundation; either version 2.1 of the License, or (at your option) any later ersion.

his library is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the nplied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU Lesser General ublic License for more details.

ou should have received a copy of the GNU Lesser General Public License along with this library; if not, write to the ree Software Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Iso add information on how to contact you by electronic and paper mail. ou should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" or the library, if necessary. Here is a sample; alter the names:

oyodyne, Inc., hereby disclaims all copyright interest in the library `Frob' (a library for tweaking knobs) written by mes Random Hacker.

signature of Ty Coon>, 1 April 1990

y Coon, President of Vice

hat's all there is to it!

. IJG: JPEG software decoder

he authors make NO WARRANTY or representation, either express or implied, with respect to this software, its uality, accuracy, merchantability, or fitness for a particular purpose. This software is provided "AS IS", and you, its user ssume the entire risk as to its quality and accuracy.

his software is copyright (C) 1991-1998, Thomas G. Lane.

Il Rights Reserved except as specified below.

ermission is hereby granted to use, copy, modify, and distribute this software (or portions thereof) for any purpose, rithout fee, subject to these conditions:

-) If any part of the source code for this software is distributed, then this README file must be included, with this copyright and no-warranty notice unaltered; and any additions, deletions, or changes to the original files must be clearly indicated in accompanying documentation.
- If only executable code is distributed, then the accompanying documentation must state that "this software is based in part on the work of the Independent JPEG Group".
- 3) Permission for use of this software is granted only if the user accepts full responsibility for any undesirable consequences; the authors accept NO LIABILITY for damages of any kind.

. WPA Supplicant

opyright (c) 2003-2009, Jouni Malinen <j@w1.fi> and contributors

II Rights Reserved.

edistribution and use in source and binary forms, with or without modification, are permitted provided that the sllowing conditions are met:

- . Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- . Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- . Neither the name(s) of the above-listed copyright holder(s) nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

HIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY XPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES IF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT HALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, ICIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, ROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS ITERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, TRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF HE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

. Unicode Bidirectional Algorithm

or the general privacy policy governing access to this site, see the Unicode Privacy Policy. For trademark usage, see the Inicode Consortium® Trademarks and Logo Policy.

lotice to End User: Terms of Use

arefully read the following legal agreement ("Agreement"). Use or copying of the software and/or codes provided ith this agreement (The "Software") constitutes your acceptance of these terms

Inicode Copyright.

opyright © 1991-2009 Unicode, Inc. All rights reserved.

ertain documents and files on this website contain a legend indicating that "Modification is permitted." Any person hereby authorized, without fee, to modify such documents and files to create derivative works conforming to the Inicode® Standard, subject to Terms and Conditions herein.

ny person is hereby authorized, without fee, to view, use, reproduce, and distribute all documents and files solely or informational purposes in the creation of products supporting the Unicode Standard, subject to the Terms and conditions herein.

urther specifications of rights and restrictions pertaining to the use of the particular set of data files known as the Jnicode Character Database'' can be found in Exhibit 1.

ach version of the Unicode Standard has further specifications of rights and restrictions of use. For the book editions, nese are found on the back of the title page. For the online edition, certain files (such as the PDF files for book napters and code charts) carry specific restrictions. All other files are covered under these general Terms of Use. To equest a permission to reproduce any part of the Unicode Standard, please contact the Unicode Consortium. Io license is granted to "mirror" the Unicode website where a fee is charged for access to the "mirror" site.

lodification is not permitted with respect to this document. All copies of this document must be verbatim.

estricted Rights Legend. Any technical data or software which is licensed to the United States of America, its agencies nd/or instrumentalities under this Agreement is commercial technical data or commercial computer software eveloped exclusively at private expense as defined in FAR 2.101, or DFARS 252.227-7014 (June 1995), as applicable. or technical data, use, duplication, or disclosure by the Government is subject to restrictions as set forth in DFARS 2.227-7015 Technical Data, Commercial and Items (Nov 1995) and this Agreement. For Software, in accordance ith FAR 12-212 or DFARS 227-7202, as applicable, use, duplication or disclosure by the Government is subject to the strictions set forth in this Agreement.

Varranties and Disclaimers.

his publication and/or website may include technical or typographical errors or other inaccuracies. Changes are eriodically added to the information herein; these changes will be incorporated in new editions of the publication and/ r website. Unicode may make improvements and/or changes in the product(s) and/or program(s) described in this ublication and/or website at any time.

this file has been purchased on magnetic or optical media from Unicode, Inc. the sole and exclusive remedy for any aim will be exchange of the defective media within ninety (90) days of original purchase.

XCEPT AS PROVIDED IN SECTION C.2, THIS PUBLICATION AND/OR SOFTWARE IS PROVIDED "AS IS" VITHOUT WARRANTY OF ANY KIND EITHER EXPRESS, IMPLIED, OR STATUTORY, INCLUDING, BUT NOT IMITED TO, ANY WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-VFRINGEMENT. UNICODE AND ITS LICENSORS ASSUME NO RESPONSIBILITY FOR ERRORS OR OMISSIONS V THIS PUBLICATION AND/OR SOFTWARE OR OTHER DOCUMENTS WHICH ARE REFERENCED BY OR INKED TO THIS PUBLICATION OR THE UNICODE WEBSITE.

Vaiver of Damages. In no event shall Unicode or its licensors be liable for any special, incidental, indirect or onsequential damages of any kind, or any damages whatsoever, whether or not Unicode was advised of the possibility f the damage, including, without limitation, those resulting from the following: loss of use, data or profits, in connection ith the use, modification or distribution of this information or its derivatives.

rademarks

Inicode and the Unicode logo are registered trademarks of Unicode, Inc.

his site contains product names and corporate names of other companies. All product names and company names nd logos mentioned herein are the trademarks or registered trademarks of their respective owners. Other products nd corporate names mentioned herein which are trademarks of a third party are used only for explanation and for the wners' benefit and with no intent to infringe.

Ise of third party products or information referred to herein is at the user's risk.

liscellaneous.

rrisdiction and Venue. This server is operated from a location in the State of California, United States of America. Inicode makes no representation that the materials are appropriate for use in other locations. If you access this server om other locations, you are responsible for compliance with local laws. This Agreement, all use of this site and any aims and damages resulting from use of this site are governed solely by the laws of the State of California without •gard to any principles which would apply the laws of a different jurisdiction. The user agrees that any disputes •garding this site shall be resolved solely in the courts located in Santa Clara County, California. The user agrees said

ourts have personal jurisdiction and agree to waive any right to transfer the dispute to any other forum. Iodification by Unicode Unicode shall have the right to modify this Agreement at any time by posting it to this site.

he user may not assign any part of this Agreement without Unicode's prior written consent. axes. The user agrees to pay any taxes arising from access to this website or use of the information herein, except for tose based on Unicode's net income.

everability. If any provision of this Agreement is declared invalid or unenforceable, the remaining provisions of this greement shall remain in effect.

ntire Agreement. This Agreement constitutes the entire agreement between the parties.

XHIBIT 1

INICODE, INC. LICENSE AGREEMENT - DATA FILES AND SOFTWARE

Inicode Data Files include all data files under the directories http://www.unicode.org/Public/, http://www.unicode.org/ sports/, and http://www.unicode.org/cldr/data/. Unicode Software includes any source code published in the Unicode tandard or under the directories http://www.unicode.org/Public/, http://www.unicode.org/reports/, and http://www. nicode.org/cldr/data/.

IOTICE TO USER: Carefully read the following legal agreement. BY DOWNLOADING, INSTALLING, COPYING OF)THERWISE USING UNICODE INC.'S DATA FILES ("DATA FILES"), AND/OR SOFTWARE ("SOFTWARE"), YOU INEQUIVOCALLY ACCEPT, AND AGREE TO BE BOUND BY, ALL OF THE TERMS AND CONDITIONS OF THIS .GREEMENT. IF YOU DO NOT AGREE, DO NOT DOWNLOAD, INSTALL, COPY, DISTRIBUTE OR USE THE PATA FILES OR SOFTWARE.

OPYRIGHT AND PERMISSION NOTICE

opyright © 1991-2009 Unicode, Inc. All rights reserved. Distributed under the Terms of Use in http://www.unicode. rg/copyright.html.

ermission is hereby granted, free of charge, to any person obtaining a copy of the Unicode data files and any sociated documentation (the "Data Files") or Unicode software and any associated documentation (the "Software")) deal in the Data Files or Software without restriction, including without limitation the rights to use, copy, modify, lerge, publish, distribute, and/or sell copies of the Data Files or Software, and to permit persons to whom the Data les or Software are furnished to do so, provided that (a) the above copyright notice(s) and this permission notice opear with all copies of the Data Files or Software, (b) both the above copyright notice(s) and this permission notice opear in associated documentation, and (c) there is clear notice in each modified Data File or in the Software as well s in the documentation associated with the Data File(s) or Software that the data or software has been modified. HE DATA FILES AND SOFTWARE ARE PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS IR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR PARTICULAR PURPOSE AND NONINFRINGEMENT OF THIRD PARTY RIGHTS. IN NO EVENT SHALL THE OPYRIGHT HOLDER OR HOLDERS INCLUDED IN THIS NOTICE BE LIABLE FOR ANY CLAIM, OR ANY PECIAL INDIRECT OR CONSEQUENTIAL DAMAGES, OR ANY DAMAGES WHATSOEVER RESULTING FROM OSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER ORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE VATA FILES OR SOFTWARE.

xcept as contained in this notice, the name of a copyright holder shall not be used in advertising or otherwise to romote the sale, use or other dealings in these Data Files or Software without prior written authorization of the pyright holder.

Inicode and the Unicode logo are trademarks of Unicode, Inc., and may be registered in some jurisdictions. All other ademarks and registered trademarks mentioned herein are the property of their respective owners.

. OpenSSL.

)pen SSL is an Open Source toolkit implementing the Secure Sockets Layer (SSL v2/v3) and Transport Layer Security Γ LS v1) protocols as well as a full-strength general purpose cryptography library.

ee http://www.openssl.org/, and in particular http://www.openssl.org/source/license.html.

he license conditions are copied below.

he OpenSSL toolkit stays under a dual license, i.e. both the conditions of the OpenSSL License and the original SSLeay zense apply to the toolkit. ee below for the actual license texts. Actually both licenses are BSD-style)pen Source licenses. In case of any license issues related to OpenSSL, please contact openssl-core@openssl.org.

)penSSL License

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- All advertising materials mentioning features or use of this software must display the following acknowledgment: "This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit. (http://www.openssl.org/)"
- 4. The names "OpenSSL Toolkit" and "OpenSSL Project" must not be used to endorse or promote products derived from this software without prior written permission. For written permission, please contact openssl-core@openssl.org.
- Products derived from this software may not be called "OpenSSL" nor may "OpenSSL" appear in their names without prior written permission of the OpenSSL Project.
- Redistributions of any form whatsoever must retain the following acknowledgment: "This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (http://www.openssl.org/)"

THIS SOFTWARE IS PROVIDED BY THE OpenSSL PROJECT "AS IS" AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE OpenSSL PROJECT OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

л

This product includes cryptographic software written by Eric Young (eay@cryptsoft.com). This product includes software written by Tim Hudson (tjh@cryptsoft.com).

Priginal SSLeay License

⁺ Copyright (C) 1995-1998 Eric Young (eay@cryptsoft.com) All rights reserved.

This package is an SSL implementation written by Eric Young (eay@cryptsoft.com). The implementation was written so as to conform with Netscapes SSL.

This library is free for commercial and non-commercial use as long as the following conditions are aheared to. The following conditions apply to all code found in this distribution, be it the RC4, RSA, lhash, DES, etc., code; not just the SSL code. The SSL documentation included with this distribution is covered by the same copyright terms except that the holder is Tim Hudson (tjh@cryptsoft.com).

Copyright remains Eric Young's, and as such any Copyright notices in the code are not to be removed. If this package is used in a product, Eric Young should be given attribution as the author of the parts of the library used. This can be in the form of a textual message at program startup or in documentation (online or textual) provided with the package.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- All advertising materials mentioning features or use of this software must display the following acknowledgement:
- "This product includes cryptographic software written by Eric Young (eay@cryptsoft.com)"
- The word 'cryptographic' can be left out if the rouines from the library being used are not cryptographic related :-).
- 4. If you include any Windows specific code (or a derivative thereof) from the apps directory (application code) you must include an acknowledgement: "This product includes software written by Tim Hudson (tjh@cryptsoft.com)"

THIS SOFTWARE IS PROVIDED BY ERIC YOUNG ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The licence and distribution terms for any publically available version or derivative of this code cannot be changed. i.e. this code cannot simply be copied and put under another distribution licence [including the GNU Public Licence.]

. Zlib general purpose compression library

ee http://www.zlib.net/, and in particular http://www.zlib.net/zlib_license.html.

^e zlib.h -- interface of the 'zlib' general purpose compression library version 1.2.3, July 18th, 2005

Copyright (C) 1995-2005 Jean-loup Gailly and Mark Adler

his software is provided 'as-is', without any express or implied warranty. In no event will the authors be held liable for ny damages arising from the use of this software.

ermission is granted to anyone to use this software for any purpose, including commercial applications, and to alter it nd redistribute it freely, subject to the following restrictions:

- The origin of this software must not be misrepresented; you must not claim that you wrote the original software. I you use this software in a product, an acknowledgment in the product documentation would be appreciated but is not required.
- . Altered source versions must be plainly marked as such, and must not be misrepresented as being the original software.
- This notice may not be removed or altered from any source distribution.

an-loup Gailly jloup@gzip.org

lark Adler madler@alumni.caltech.edu

0. cURL

OPYRIGHT AND PERMISSION NOTICE

Copyright (c) 1996 - 2010, Daniel Stenberg, <daniel@haxx.se>.

.ll rights reserved.

ermission to use, copy, modify, and distribute this software for any purpose with or without fee is hereby granted, rovided that the above copyright notice and this permission notice appear in all copies.

HE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, VCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR URPOSE AND NONINFRINGEMENT OF THIRD PARTY RIGHTS. IN NO EVENT SHALL THE AUTHORS OR OPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN CTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE OFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

xcept as contained in this notice, the name of a copyright holder shall not be used in advertising or otherwise to romote the sale, use or other dealings in this Software without prior written authorization of the copyright holder.

1. Freetype, a Free, High-Quality, and Portable Font Engine

he software is based in part of the work of the FreeType Team. ee http://freetype.sourceforge.net/, and in particular http://freetype.sourceforge.net/FTL.TXT. ortions of the relevant license conditions are copied below. he FreeType Project LICENSE 2006-Jan-27 .opyright 1996-2002, 2006 by David Turner, Robert Wilhelm, and Werner Lemberg

No Warranty

THE FREETYPE PROJECT IS PROVIDED 'AS IS' WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT WILL ANY OF THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY DAMAGES CAUSED BY THE USE OR THE INABILITY TO USE, OF THE FREETYPE PROJECT.

. Redistribution

This license grants a worldwide, royalty-free, perpetual and irrevocable right and license to use, execute, perform, compile, display, copy, create derivative works of, distribute and sublicense the FreeType Project (in both source and

object code forms) and derivative works thereof for any purpose; and to authorize others to exercise some or all of the rights granted herein, subject to the following conditions:

 Redistribution in binary form must provide a disclaimer that states that the software is based in part of the work of the FreeType Team, in the distribution documentation. We also encourage you to put an URL to the FreeType web page in your documentation, though this isn't mandatory.

2. International Components for Unicode

OPYRIGHT AND PERMISSION NOTICE

Copyright (c) 1995-2009 International Business Machines Corporation and others

Il rights reserved.

ermission is hereby granted, free of charge, to any person obtaining a copy of this software and associated ocumentation files (the "Software"), to deal in the Software without restriction, including without limitation the right: > use, copy, modify, merge, publish, distribute, and/or sell copies of the Software, and to permit persons to whom we Software is furnished to do so, provided that the above copyright notice(s) and this permission notice appear in l copies of the Software and that both the above copyright notice(s) and this permission notice appear in supporting ocumentation.

HE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, VCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR URPOSE AND NONINFRINGEMENT OF THIRD PARTY RIGHTS. IN NO EVENT SHALL THE COPYRIGHT IOLDER OR HOLDERS INCLUDED IN THIS NOTICE BE LIABLE FOR ANY CLAIM, OR ANY SPECIAL INDIRECT IR CONSEQUENTIAL DAMAGES, OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA IR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, RISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

xcept as contained in this notice, the name of a copyright holder shall not be used in advertising or otherwise to romote the sale, use or other dealings in this Software without prior written authorization of the copyright holder.

3. Expat

opyright (c) 1998, 1999, 2000 Thai Open Source Software Center Ltd and Clark Cooper

opyright (c) 2001, 2002, 2003, 2004, 2005, 2006 Expat maintainers.

ermission is hereby granted, free of charge, to any person obtaining a copy of this software and associated ocumentation files (the "Software"), to deal in the Software without restriction, including without limitation the right: o use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to 'hom the Software is furnished to do so, subject to the following conditions:

he above copyright notice and this permission notice shall be included in all copies or substantial portions of the oftware.

HE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, VCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR URPOSE AND NONINFRINGEMENT.

NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR THER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT FOR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

4. DNS Resolver

he DNS resolver code, taken from BIND 4.9.5, is copyrighted both by UC Berkeley and by Digital Equipment Corporation. The DEC portions are under the following license:

ortions Copyright (C) 1993 by Digital Equipment Corporation.

ermission to use, copy, modify, and distribute this software for any purpose with or without fee is hereby granted, rovided that the above copyright notice and this permission notice appear in all copies, and that the name of Digital quipment Corporation not be used in advertising or publicity pertaining to distribution of the document or software rithout specific, written prior permission.

HE SOFTWARE IS PROVIDED ``AS IS" AND DIGITAL EQUIPMENT CORP. DISCLAIMS ALL WARRANTIES VITH REGARD TO THIS SOFTWARE, INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND

TNESS. IN NO EVENT SHALL DIGITAL EQUIPMENT CORPORATION BE LIABLE FOR ANY SPECIAL, DIRECT, JDIRECT, OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF ISE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS .CTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

5. getnameinfo, getaddrinfo

he files inet/getnameinfo.c and sysdeps/posix/getaddrinfo.c are copyright (C) by Craig Metz and are distributed under ne following license:

[•] The Inner Net License, Version 2.00

he author(s) grant permission for redistribution and use in source and binary forms, with or without modification, of re software and documentation provided that the following conditions are met:

- If you receive a version of the software that is specifically labelled as not being for redistribution (check the versior message and/or README), you are not permitted to redistribute that version of the software in any way or form.
 All terms of the all other applicable copyrights and licenses must be followed.
- . Redistributions of source code must retain the authors' copyright notice(s), this list of conditions, and the following disclaimer.
- . Redistributions in binary form must reproduce the authors' copyright notice(s), this list of conditions, and the following disclaimer in the documentation and/or other materials provided with the distribution.
- . [The copyright holder has authorized the removal of this clause.]
- . Neither the name(s) of the author(s) nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

HIS SOFTWARE IS PROVIDED BY ITS AUTHORS AND CONTRIBUTORS ``AS IS'' AND ANY EXPRESS)R IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF IERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL HE AUTHORS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, XEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF UBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) IOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, IR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS OFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

these license terms cause you a real problem, contact the author. */

6. libpng

his copy of the libpng notices is provided for your convenience. In case of any discrepancy between this copy and the otices in the file png.h that is included in the libpng distribution, the latter shall prevail.

OPYRIGHT NOTICE, DISCLAIMER, and LICENSE:

you modify libpng you may insert additional notices immediately following this sentence.

his code is released under the libpng license.

ppng versions 1.2.6, August 15, 2004, through 1.2.41, December 3, 2009, are Copyright (c) 2004, 2006-2009 Glenn anders-Pehrson, and are distributed according to the same disclaimer and license as libpng-1.2.5 with the following idividual added to the list of Contributing Authors

Cosmin Truta

opng versions 1.0.7, July 1, 2000, through 1.2.5 - October 3, 2002, are

opyright (c) 2000-2002 Glenn Randers-Pehrson, and are distributed according to the same disclaimer and license as ppg-1.0.6 with the following individuals added to the list of Contributing Authors

mon-Pierre Cadieux

ric S. Raymond

illes Vollant

nd with the following additions to the disclaimer:

here is no warranty against interference with your enjoyment of the library or against infringement. There is no arranty that our efforts or the library will fulfill any of your particular purposes or needs. This library is provided with I faults, and the entire risk of satisfactory quality, performance, accuracy, and effort is with the user. ppng versions 0.97, January 1998, through 1.0.6, March 20, 2000, are Copyright (c) 1998, 1999 Glenn Randersehrson, and are distributed according to the same disclaimer and license as libpng-0.96, with the following individuals dded to the list of Contributing Authors:

om Lane

ilenn Randers-Pehrson

Villem van Schaik

ppng versions 0.89, June 1996, through 0.96, May 1997, are Copyright (c) 1996, 1997 Andreas Dilger

vistributed according to the same disclaimer and license as libpng-0.88, with the following individuals added to the list f Contributing Authors:

hn Bowler

evin Bracey

am Bushell

lagnus Holmgren

ireg Roelofs

om Tanner

ppng versions 0.5, May 1995, through 0.88, January 1996, are Copyright (c) 1995, 1996 Guy Eric Schalnat, Group 42, IC.

or the purposes of this copyright and license, "Contributing Authors" is defined as the following set of individuals: .ndreas Dilger

ave Martindale

iuv Eric Schalnat

aul Schmidt

im Wegner

he PNG Reference Library is supplied "AS IS". The Contributing Authors and Group 42, Inc. disclaim all warranties, xpressed or implied, including, without limitation, the warranties of merchantability and of fitness for any purpose. he Contributing Authors and Group 42, Inc. assume no liability for direct, indirect, incidental, special, exemplary, or onsequential damages, which may result from the use of the PNG Reference Library, even if advised of the possibility f such damage.

ermission is hereby granted to use, copy, modify, and distribute this source code, or portions hereof, for any purpose, ithout fee, subject to the following restrictions:

The origin of this source code must not be misrepresented.

. Altered versions must be plainly marked as such and must not be misrepresented as being the original source.

. This Copyright notice may not be removed or altered from any source or altered source distribution.

he Contributing Authors and Group 42, Inc. specifically permit, without fee, and encourage the use of this source ode as a component to supporting the PNG file format in commercial products. If you use this source code in a roduct, acknowledgment is not required but would be appreciated.

. "png_get_copyright" function is available, for convenient use in "about" boxes and the like:

rintf("%s",png_get_copyright(NULL));

.lso, the PNG logo (in PNG format, of course) is supplied in the files "pngbar.png" and "pngbar.jpg (88x31) and pngnow.png" (98x31).

bpng is OSI Certified Open Source Software. OSI Certified Open Source is a certification mark of the Open Source itiative.

ilenn Randers-Pehrson

ennrp at users.sourceforge.net

ecember 3, 2009

7. SQLite

Il of the deliverable code in SQLite has been dedicated to the HYPERLINK "http://en.wikipedia.org/wiki/Public_ vomain"public domain by the authors. All code authors, and representatives of the companies they work for, have gned affidavits dedicating their contributions to the public domain and originals of those signed affidavits are stored a firesafe at the main offices of HYPERLINK "http://www.hwaci.com"Hwaci. Anyone is free to copy, modify, publish, se, compile, sell, or distribute the original SQLite code, either in source code form or as a compiled binary, for any urpose, commercial or non-commercial, and by any means.

he previous paragraph applies to the deliverable code in SQLite - those parts of the SQLite library that you actually undle and ship with a larger application. Portions of the documentation and some code used as part of the build rocess might fall under other licenses. The details here are unclear. We do not worry about the licensing of the ocumentation and build code so much because none of these things are part of the core deliverable SQLite library.

Il of the deliverable code in SQLite has been written from scratch. No code has been taken from other projects or from ne open internet. Every line of code can be traced back to its original author, and all of those authors have public domain edications on file. So the SQLite code base is clean and is uncontaminated with licensed code from other projects.

8. libxml2

xcept where otherwise noted in the source code (e.g. the files hash.c, list.c and the trio files, which are covered by a milar licence but with different Copyright notices) all the files are:

opyright (C) 1998-2003 Daniel Veillard. All Rights Reserved.

ermission is hereby granted, free of charge, to any person obtaining a copy of this software and associated ocumentation files (the "Software"), to deal in the Software without restriction, including without limitation the right:) use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to 'hom the Software is fur- nished to do so, subject to the following conditions:

he above copyright notice and this permission notice shall be included in all copies or substantial portions of the oftware.

HE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, JCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FIT- NESS FOR A PARTICULAF URPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE DANIEL VEILLARD BE LIABLE FOR ANY 1. LAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, RISING FROM, OUT OF OR IN CON- NECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS 1 THE SOFTWARE.

xcept as contained in this notice, the name of Daniel Veillard shall not be used in advertising or otherwise to promote resale, use or other deal- ings in this Software without prior written authorization from him.

OSS_2011_HTS3531/3551/3541/5131_V1.0_SC

NOTICE SOFTWARE END USER LICENSE AGREEMENT

SOFTWARE END USER LICENSE AGREEMENT ("THIS AGREEMENT") IS A LEGAL AND BINDING EMENT BETWEEN YOU (EITHER AN INDIVIDUAL OR ENTITY) AND PHILIPS CONSUMER LIFESTYLE B TCH LIMITED LIABILITY COMPANY, WITH ITS PRINCIPAL OFFICE AT HIGH TECH CAMPUS 37, 5656 AE HOVEN, THE NETHERLANDS AND ITS SUBSIDIARY COMPANIES (INDIVIDUALLY AND COLLECTIVEL' IPS"). THIS AGREEMENT GIVES YOU THE RIGHT TO USE CERTAIN SOFTWARE (THE "SOFTWARE") JDING USER DOCUMENTATION IN ELECTRONIC FORM WHICH MAY HAVE BEEN PROVIDED VATELY OR TOGETHER WITH A PHILIPS PRODUCT (THE "DEVICE") OR A PC. BY DOWNLOADING, ILLING OR OTHERWISE USING THE SOFTWARE, YOU ACCEPT AND AGREE TO BE BOUND BY ALL 1E TERMS AND CONDITIONS OF THIS AGREEMENT. IF YOU DO NOT AGREE TO THESE TERMS AND DITIONS, DO NOT DOWNLOAD, INSTALL OR OTHERWISE USE THE SOFTWARE. IF YOU ACQUIRED WARE IN TANGIBLE MEDIA E.G. CD WITHOUT THE OPPORTUNITY TO REVIEW THIS LICENSE AND ACCEPT THESE TERMS, YOU MAY RECEIVE A FULL REFUND OF THE AMOUNT, IF ANY, THAT YOU PA THE SOFTWARE IF YOU RETURN THE SOFTWARE UNUSED WITH PROOF OF PAYMENT WITHIN 30 I I THE DATE OF PURCHASE.

rant of License. This Agreement grants you a non-exclusive, nontransferable, non-sub licensable license to ins id use, on the Device or a PC, as applicable, one (1) copy of the specified version of the Software in object cormat as set out in the user documentation solely for your personal use. The Software is "in use" when it is loa to the temporary or permanent memory (i.e. RAM, hard disk, etc.) of the PC or the Device.

wnership. The Software is licensed and not sold to you. This Agreement grants you only the right to use the oftware, but you do not acquire any rights, express or implied, in the Software other than those specified in th greement. Philips and its licensors retain all right, title, and interest in and to the Software, including all patents opyrights, trade secrets, and other intellectual property rights incorporated therein. The Software is protected *r* copyright laws, international treaty provisions, and other intellectual property laws. Therefore, other than as opressly set forth herein, you may not copy the Software without prior written authorization of Philips, except ou may make one (1) copy of the Software for your back-up purposes only. You may not copy any printed mate: rompanying the Software, nor print more than one (1) copy of any user documentation provided in electronic rm, except that you may make one (1) copy of such printed materials for your back-up purposes only.

cense Restrictions. Except as provided otherwise herein, you shall not rent, lease, sublicense, sell, assign, loan, ⁻ otherwise transfer the Software. You shall not, and you shall not permit any third party, to reverse engineer, ecompile, or disassemble the Software, except to the extent that applicable law expressly prohibits the forego striction. You may not remove or destroy any product identification, copyright notices, or other proprietary arkings or restrictions from the Software. All titles, trademarks, and copyright and restricted rights notices sha produced on your back up copy of the Software. You may not modify or adapt the Software, merge the Softw to another program or create derivative works based upon the Software.

ermination of certain functionality. The Software may contain components of certain licensed software include oftware licensed from Microsoft Corporation ("Microsoft") which implements Microsoft's digital rights manage chnology for Windows Media. Content providers are using the digital rights management technology for Wind edia ("WM-DRM") to protect the integrity of their content ("Secure Content") so that their intellectual prop cluding copyright, in such content is not misappropriated. Your Device may also use WM-DRM software to tra play Secure Content ("WM-DRM Software"). If the security of such WM-DRM Software is compromised, icrosoft may revoke (either on its own or upon the request of the owners of Secure Content ("Secure Conter where'')) the WM-DRM Software's right to acquire new licenses to copy, store, transfer, display and/or play Se ontent. Revocation does not alter the WM-DRM Software's ability to play unprotected content. A list of revol /M-DRM Software is sent to your PC and/or your Device whenever you download a license for Secure Conte icrosoft may, in conjunction with such license, also download revocation lists onto your Device on behalf of Se ontent Owners, which may disable your Device's ability to copy, store, display, transfer, and/or play Secure Cor scure Content Owners may also require you to upgrade some of the WM-DRM components distributed with oftware ("WM-DRM Upgrades") before accessing their content. When you attempt to play Secure Content, V LILL HE HE N - - - fr + - \A/NA DDNA | |atures that access the Internet, such as acquiring new licenses and/or performing a required WM-DRM Upgraun be switched off. When these features are switched off, you will still be able to play Secure Content if you havalid license for such content already stored on your Device. However, you will not be able to use certain of the /M-DRM Software features that require Internet access such as the ability to download content that requires 1 /M-DRM Upgrade. All title and intellectual property rights in and to the Secure Content is the property of the spective Secure Content owners and may be protected by applicable copyright or other intellectual property ws and treaties. This Agreement grants you no rights to use such Secure Content. To summarize, if the Softw ansfer, and/or play is protected by the Microsoft WM-DRM components of the Software. Microsoft WM-DRM components may deny you access, or restrict your access, to Secure ontent even after you have paid for, and/or obtained, it. Neither your consent nor the consent or approval atlips is necessary for any of them to deny, withhold or otherwise restrict your access to Secure Content. P ses not guaranty that you will be able to download, copy, store, display, transfer, and/or play Secure Content.

pen Source Software. (a) This software may contain components that are subject to open-source terms, as st the documentation accompanying the Device. This Agreement does not apply to this software as such. (b) Yo ense rights under this Agreement do not include any right or license to use, distribute or create derivative wo e Software in any manner that would subject the Software to Open Source Terms. "Open Source Terms" me e terms of any license that directly or indirectly (1) create, or purport to create, obligations for Philips with res the Software and/or derivative works thereof; or (2) grant, or purport to grant, to any third party any rights c munities under intellectual property or proprietary rights in the Software or derivative works thereof.

ermination. This Agreement shall be effective upon installation or first use of the Software and shall terminate e discretion of Philips, due to your failure to comply with any term of this Agreement; or (ii) upon destruction pies of the Software and related materials provided to you by Philips hereunder. Philips's rights and your oblig. I survive the termination of this Agreement.

pgrades. Philips may, at its sole option, make upgrades to the Software available by general posting on a websi *i* any other means or methods. Such upgrades may be made available pursuant to the terms of this Agreement e release of such upgrades to you may be subject to your acceptance of another agreement.

Ipport Services. Philips is not obligated to provide technical or other support ("Support Services") for the oftware. If Philips does provide you with Support Services, these will be governed by separate terms to be agree tween you and Philips.

mited Software Warranty. Philips provides the Software 'as is' and without any warranty except that the Soft ill perform substantially in accordance with the documentation accompanying the Software for a period of one ter your first download, installation or use of the Software, whichever occurs first. Philips' entire liability and yc (clusive remedy for breach of this warranty shall be, at Philips' option, either (i) return of the price paid by you e Software (if any); or (b) repair or replacement of the Software that does not meet the warranty set forth he id that is returned to Philips with a copy of your receipt. This limited warranty shall be void if failure of the Soft is resulted from any accident, abuse, misuse or wrongful application. Any replacement Software will be warrant r the remainder of the original warranty period or thirty (30) days, whichever is longer. This limited warranty sit apply to you if the Software was provided to you free of charge on an evaluation only basis.

O OTHER WARRANTIES. EXCEPT AS SET FORTH ABOVE, PHILIPS AND ITS LICENSORS DO NOT /ARRANT THAT THE SOFTWARE WILL OPERATE ERROR FREE OR UNINTERRUPTED, OR WILL MEET DUR REQUIREMENTS. YOU ASSUME ALL RESPONSIBILITIES FOR SELECTION OF THE SOFTWARE TO CHIEVE YOUR INTENDED RESULTS, AND FOR THE INSTALLATION OF, USE OF, AND RESULTS OBTAI ROM THE SOFTWARE. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, PHILIPS AND S LICENSORS DISCLAIM ALL WARRANTIES AND CONDITIONS, WHETHER EXPRESS OR IMPLIED, ICLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR PARTICULAR PURPOSE, AND ACCURACY OR COMPLETENESS OF RESULTS WITH RESPECT TO THE DFTWARE AND THE ACCOMPANYING MATERIALS. THERE IS NO WARRANTY AGAINST INFRINGEM HILIPS DOES NOT WARRANT THAT YOU WILL BE ABLE TO DOWNLOAD, COPY, STORE, DISPLAY, RANSFER, AND/OR PLAY SECURE CONTENT. JCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF PROFITS OR REVENUES, BUSINESS JTERRUPTION, LOSS OF BUSINESS INFORMATION, LOSS OF DATA, LOSS OF USE OR OTHER PECUNI DSS, EVEN IF PHILIPS OR ITS LICENSORS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAC J NO EVENT SHALL PHILIPS' OR ITS LICENSORS' AGGREGATE LIABILITY FOR DAMAGES ARISING OU HIS AGREEMENT EXCEED THE GREATER OF THE PRICE ACTUALLY PAID BY YOU FOR THE SOFTWAF 'R FIVE POUNDS STERLING (5.00).

***ademarks.** Certain of the product and Philips names used in this Agreement, the Software, and the printed us ocumentation may constitute trademarks of the Philips, its licensors or other third parties. You are not authority use any such trademarks.

cport Administration. You agree that you will not directly or indirectly, export or re-export the Software to y country for which the United States Export Administration Act, or any similar United States law or regulatic :quires an export license or other U.S. Government approval, unless the appropriate export license or approv 'st been obtained. By downloading or installing the Software you agree to abide by this Export provision.

overning law. This Agreement is governed by the laws of your country of residence , without reference to its pnflict of laws principles. Any dispute between you and Philips regarding this Agreement shall be subject to the «clusive jurisdiction of the courts of your country of residence.

eneral. This Agreement contains the entire agreement between you and Philips and supersedes any prior presentation, undertaking or other communication or advertising with respect to the Software and user ocumentation. If any part of this Agreement is held invalid, the remainder of this Agreement will continue in ful rce and effect. This Agreement shall not prejudice the statutory rights of any party dealing as a consumer.

EULA-Engli: Septembe





© 2011 Koninklijke Philips Electronics N.V. All rights reserved. BDP3282_05_UM_V1.0_1130