



Philips
Original radio

with 30-pin connector
for iPod/iPhone
DAB+, FM
10 W



ORD7300



The original radio

This Philips Original radio combines the iconic 50s looks of the Philips radio with today's technologies. It plays and charges your iPod/iPhone and delivers DAB+ and FM radio in high-fidelity sound.

Enrich your sound experience

- High fidelity sound
- Play and charge your iPod/iPhone simultaneously
- Bass Reflex Speaker System delivers a powerful, deeper bass

Enjoy digital quality DAB+ radio

- DAB+ and FM compatible for a complete radio experience
- DAB for a clear and crackle-free radio experience

Easy to use

- Dock any iPod/iPhone, even in its case
- Audio-in for easy portable music playback

Contemporary retro design

- Contemporary reinterpretation of the iconic Philetta design

PHILIPS

Original radio
with 30-pin connector for iPod/iPhone, DAB+, FM, 10 W

Highlights

DAB



DAB (Digital Audio Broadcasting) digital radio is a new way of broadcasting radio, in addition to FM analogue transmission, via a network of terrestrial transmitters. It provides listeners with more choices and information delivered in clear and crackle-free sound quality. The technology allows the receiver to lock on to the strongest signal it can find. With DAB digital stations there are no frequencies to remember, and sets are tuned by station name, so there is no retuning on the move.

Play and charge your iPod/iPhone



Enjoy your favourite MP3 music while charging your iPod/iPhone! The dock lets you connect your portable device directly to the Docking entertainment system so you can listen to your favourite music in superb sound. It also charges your iPod/iPhone while it plays so you can

enjoy your music and not have to worry about your portable player battery running out. The Docking entertainment system automatically charges your portable device while it is docked.

Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimise the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by causing the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a completely new dimension of deep bass.

ORD7300/10

Dock iPod/iPhone in its case



Smartly designed spring-loaded docking port effortlessly accommodates any iPod or iPhone, without special adapters. What's more, it works even when most protective cases are on – just dock your iPod or iPhone as it is. Now you can truly have fuss-free enjoyment of your music.

AUDIO-IN (3.5 mm)



Make one easy connection and enjoy all your music from portable devices and computers. Simply plug your device into the AUDIO-IN (3.5 mm) port on your Philips set. With computers, the connection is typically made from the headset output. Once linked, you can enjoy your entire music collection directly, on a set of superior speakers. Philips simply delivers better sound.



DIGITAL RADIO



Specifications

iPod compatibility

- Compatible with: iPod touch, iPod touch 2nd Generation, iPod classic, iPod nano 3rd Generation, iPod nano 4th Generation, iPod 5th Generation, iPod with colour display, iPod nano, iPod mini, iPod nano 1st Generation, iPod nano 2nd Generation

iPhone compatibility

- Compatible with: iPhone 3G, iPhone 3GS, iPhone 4, iPhone 4S

Audio Playback

- Playback mode: Charging iPod, Charging iPhone

Tuner/Reception/Transmission

- Tuner bands: DAB (Band III), FM
- Frequency range: (FM) 87.5–108 MHz
- Station presets: 30 (DAB), 30 (FM)
- Auto digital tuning
- DAB: info display, menu, smart scan

Connectivity

- Audio in (3.5 mm)
- Antenna: FM antenna (75 ohm)

Convenience

- Display Type: LCD

Sound

- Sound System: Stereo
- Volume control: rotary (digital)

Loudspeakers

- Built-in speakers: 2

Power

- Power type: AC input

Dimensions

- Product dimensions (WxDxH): 330 x 150 x 163 mm
- Packaging dimensions (WxDxH): 460 x 250 x 245 mm

Accessories

- Included accessories: Remote Control, AC power cord (VDE and UK), User Manual, Warranty certificate



Issue date 2014-07-18

Version: 3.0.5

12 NC: 8670 000 93239
EAN: 08 71258 16546 27

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com