



Philips  
DVD player

**HDMI 1080i**

DivX Ultra

**DVP6620**



## In style in any room

Be impressed with this Philips DVD player with HDMI digital video and audio connection. Step into another home entertainment arena as you immerse yourself with High Definition video (720p / 1080i).

### **Fits any space, any lifestyle**

- Slim and flexible design with optional wall-mounting

### **Play all your movies and music**

- DivX Ultra Certified for enhanced playback of DivX videos
- Plays DivX, MP3, WMA and JPEG digital camera photos
- Plays CD, (S)VCD, DVD, DVD+R/RW, DVD-R/RW
- DivX Certified for standard playback of DivX videos

### **Bring audio and video to life**

- 12-bit/108MHz video processing for sharp and natural images
- 192kHz/24 bit audio DAC enhances analogue sound input
- High quality outputs for analog and digital audio
- HDMI 1080i with high definition video upscaling
- HDMI digital output for easy connection with only one cable
- High definition JPEG playback for images in true resolution
- Progressive Scan component video for optimized image quality

**PHILIPS**  
sense and simplicity

# Highlights

## DivX Ultra Certified

With DivX support, you are able to enjoy DivX encoded videos in the comfort of your living room. The DivX media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, and DVD recordable discs. DivX Ultra combines DivX playback with great features like integrated subtitles, multiple audio languages, multiple tracks and menus into one convenient file format.

## Plays it all

Play virtually any media format you want - whether they be DivX, MP3s, WMA or JPEGs. Experience the unbeatable convenience of great playability, and the luxury of sharing media files on your TV or home theater system - in the comfort of your living room.

## 192kHz/24 bit audio DAC

192KHz sampling enables you to have an accurate representation of the original sound

curves. Together with a 24-bit resolution, more information is captured from the original analogue sound wave form, giving a much richer audio reproduction.

## HDMI 1080i

HDMI stands for High Definition Multimedia Interface. It is a direct digital connection that can carry digital HD video as well as digital multichannel audio. By eliminating the conversion to analog signals it delivers perfect picture and sound quality, completely free from noise. HDMI is fully backward-compatible with DVI (Digital Video Interface).

## HDMI for simple AV connection

HDMI stands for High Definition Multimedia Interface. It is a direct digital connection that can carry digital HD video as well as digital multichannel audio. By eliminating the conversion to analog signals it delivers perfect picture and sound quality, completely free from noise. HDMI is fully backward-compatible with (Digital Video Interface) DVI.

## High definition JPEG playback

High definition JPEG playback lets you view your pictures on your television in resolutions as high as two megapixels. Now you can view your digital pictures in absolute clarity, without loss of quality or detail - and share them with friends and family in the comfort of your living room.

## Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

## Slim and flexible design

Slim and flexible design with optional wall-mounting



# Specifications

## Picture/Display

- D/A converter: 12 bit, 108 MHz
- Picture enhancement: Progressive scan, Smart Picture, Video upsampling, Video upscaling, High Def (720p, 1080i)

## Sound

- D/A converter: 24 bit, 192 kHz
- Signal to noise ratio: 90
- Distortion and Noise (1kHz): 65 dB
- Crosstalk (1kHz): 70 dB
- Dynamic Range (1kHz): 80 dB
- Frequency response: 30-20000 Hz
- Sound System: Dolby Digital

## Video Playback

- Playback Media: CD, CD-R/CD-RW, Video CD/SVCD, DVD, DivX, DVD+R/+RW, DVD-R/-RW, DVD-Video
- Compression formats: MPEG1, MPEG2, DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0, DivX Ultra
- Video disc playback system: NTSC, PAL

## Audio Playback

- Playback Media: CD, MP3-CD, MP3-DVD, CD-R/RW, WMA-CD, Audio CD
- MP3 bit rates: 32 - 320 kbps
- Compression format: Dolby Digital, MP3, PCM, WMA

## Still Picture Playback

- Playback Media: DVD+R/+RW, DVD-R/-RW, CD-R/RW, Picture CD, Kodak Picture CD

- Picture Compression Format: JPEG
- Picture Enhancement: Flip photos, Rotate, Zoom, Slideshow with MP3 playback, High Definition Resolution

## Multimedia Applications

- Playback Formats: DivX, MP3, JPEG Still pictures

## Connectivity

- Rear Connections: HDMI output, Digital coaxial out, ComponentVideo out Progressive, CVBS & analog audio L/R output

## Convenience

- Child Protection: Parental Control, Child Lock
- On-Screen Display languages: English, Korean, Malay, Thai, Traditional Chinese

## Accessories

- Included accessories: 2 x AAA Batteries, Audio/Video cable, Quick start guide, Remote Control, World Wide Warranty leaflet, User Manual, Power cord

## Dimensions

- Set dimensions (W x H x D): 305 x 187 x 98 mm
- Packaging dimensions (W x H x D): 395 x 346 x 108 mm

## Power

- Power supply: 110-240V, 50/60 Hz
- Power consumption: < 10 W
- Standby power consumption: < 0.8 W



Issue date 2011-04-28

Version: 1.0.6

12 NC: 8670 000 34084  
EAN: 87 12581 36505 9

© 2011 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)