



Philips  
5.1 Home theater

600W RMS power  
DVD playback

HTS3265



# Power up your entertainment

with compact powerful speakers

Experience sensational home entertainment with the powerful surround sound delivered by this system. Enjoy endless entertainment with Karaoke Scoring, playback from USB drives, portable media players and practically any type of disc.

## Connect and enjoy multiple sources

- USB Link plays photos and music from USB flash drives
- MP3 Link plays music from portable media players

## Bring audio and video to life

- DTS, Dolby Digital and Pro Logic II surround sound
- Karaoke Scoring for fun and exciting song contests at home
- 12-bit/108MHz video processing for sharp and natural images

## Easy to set up and use

- Easy-fit™ connectors with color-coding for a simple set-up

## Play all your movies and music

- DivX Ultra Certified for enhanced playback of DivX videos
- Plays DivX, MP3, WMA and JPEG digital camera photos
- Plays CD, (S)VCD, DVD, DVD+R/RW, DVD-R/RW, DVD+R DL

**PHILIPS**

# Highlights

## USB Link

The Universal Serial Bus or USB is a protocol standard that is conveniently used to link PCs, peripherals and consumer electronic equipment. With USB Link, all you have to do is plug in your USB device, select the photo or music, and play away.

## DTS, DolbyDigital, ProLogic II

A built-in DTS and Dolby Digital decoder eliminates the need for an external decoder by processing all six channels of audio information to provide a surround sound experience and an astoundingly natural sense of ambience and dynamic realism. Dolby Pro Logic II provides five channels of surround processing from any stereo source.

## DivX Ultra Certified

With DivX support, you are able to enjoy DivX encoded videos in the comfort of your living room. The DivX media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/

RW, and DVD recordable discs. DivX Ultra combines DivX playback with great features like integrated subtitles, multiple audio languages, multiple tracks and menus into one convenient file format.

## Karaoke Scoring

Add a dash of fun to your Karaoke sessions with Karaoke Scoring. Allow your performance to be judged for further improvement, or for friendly competitions. Karaoke Scoring automatically rates your singing and gives you a humorous picture that is tied to how well you did. The fun never ends.

## 12-bit/108MHz video processing

12-bit Video DAC is a superior Digital-to-Analogue-Converter that preserves every detail of the authentic picture quality. It shows subtle shades and smoother graduation of colors, resulting in a more vibrant and natural picture. The limitation of the usual 10bit DAC become in particular apparent while using large screens and projectors.

## Easy-fit™ connectors

Color-coded connectors provide a simple and user-friendly solution to connect the speakers and subwoofer to the center unit of the home entertainment system simply by plugging the connectors in the matching colored interface at the rear of the center unit.

## Plays it all

Play virtually any media format you want - whether they be DivX, MP3s, WMA or JPEGs. Experience the unbeatable convenience of great playability, and the luxury of sharing media files on your TV or home theater system - in the comfort of your living room.

## Plays it all

Play virtually any disc you want - whether they be CDs, (S)VCDs, DVDs, DVD+R, DVD-R, DVD+RW, DVD-RW or DVD+R DL. Experience unbeatable flexibility and the convenience of playing all your discs on the one device.



# Specifications

## Picture/Display

- D/A converter: 12bit, 108MHz
- Picture enhancement: Progressive scan

## Sound

- Total Power (RMS): 600 W
- Output power (RMS): 4x75W, 2x150W
- D/A converter: 24 bit, 192 kHz
- Frequency response: 180-14000 Hz
- Signal to noise ratio: > 60 dB
- Sound System: Dolby Digital, Dolby Prologic II, DTS, Stereo
- Equalizer settings: Action, Classic, Concert, Drama, Gaming, Lounge, Rock, Sports
- Sound Enhancement: Class "D" Digital Amplifier, Night Mode

## Video Playback

- Compression formats: MPEG1, MPEG2, DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0, DivX Ultra
- Playback Media: DVD-Video, DVD+R/+RW, DVD-R/-RW, Video CD/SVCD, CD-R/CD-RW
- Video disc playback system: NTSC, PAL

## Audio Playback

- Compression format: MP3, WMA
- Playback Media: CD-R/RW, CD, USB flash drive
- MP3 bit rates: 32-256 kbps and VBR

## Still Picture Playback

- Picture Compression Format: JPEG
- Playback Media: DVD+R/+RW, DVD-R/-RW, CD-R/RW, USB flash drive
- Picture Enhancement: Rotate, Zoom, Slideshow with music playback

## Tuner/Reception/Transmission

- Tuner Bands: FM
- No. of preset Audio Channels: 40

## Connectivity

- Rear Connections: Component Video output, Composite video (CVBS) output, AUX in, FM Antenna, Easy-Fit Speaker Connectors
- Front / Side connections: Microphone input 3.5mm jack, MP3 Line-in, USB

## Power

- Power supply: 120/230VAC, 50/60Hz
- Standby power consumption: < 1 W
- Power consumption: 100 W

## Loudspeakers

- Satellite speaker drivers: 3" full range woofer
- Satellite speaker impedance: 4 ohm

- Satellite speaker freq range: 150-20000 Hz
- Center Speaker: Magnetically shielded
- Center speaker drivers: 3" full range woofer
- Center speaker impedance: 8 ohm
- Center freq range: 150-20000 Hz
- Subwoofer driver: 6.5" high efficiency woofer
- Subwoofer type: Passive
- Subwoofer impedance: 8 ohm
- Subwoofer freq range: 45-150 Hz

## Accessories

- Included accessories: Remote Control, 2 x AAA Batteries, CVBS video cable, FM antenna, Quick start guide, User Manual, World Wide Warranty leaflet, Power cord

## Dimensions

- Set dimensions (W x H x D): 360 x 58 x 332 mm
- Set weight: 2.8 kg
- Surround Speaker dimensions (W x H x D): 103 x 203 x 71 mm
- Surround speaker Weight: 0.656 kg
- Center speaker dimensions (W x H x D): 244 x 105 x 74 mm
- Center Speaker Weight: 0.78 kg
- Subwoofer dimensions (W x H x D): 163 x 363 x 369 mm
- Subwoofer Weight: 4.865 kg
- Packaging dimensions (W x H x D): 446 x 417 x 378 mm
- Weight incl. Packaging: 13 kg

## Outer Carton

- EAN: 87 12581 38904 8
- Gross weight: 13.605 kg
- Outer carton (L x W x H): 45.8 x 45 x 43 cm
- Nett weight: 11.645 kg
- Number of consumer packagings: 1
- Tare weight: 1.96 kg

## Packaging dimensions

- Packaging dimensions (W x H x D): 45.8 x 43 x 45 cm
- EAN: 87 12581 38904 8
- Gross weight: 13.605 kg
- Nett weight: 11.645 kg
- Number of products included: 1
- Packaging type: Carton
- Tare weight: 1.96 kg

## Product dimensions

- Cable length: 0 cm
- Product dimensions (W x H x D): 0 x 0 x 0 cm
- Weight: 0 kg



Issue date 2014-02-10

Version: 3.0.8

12 NC: 8670 000 36285  
EAN: 87 12581 38904 8

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)