Always there to help you

Register your product and get support at www.philips.com/support



DS1600



User manual



Contents

1	Important	2
	Safety	2
	Notice	2
2	Your Docking Speaker	4
	Introduction	4
	What's in the box	4
	Overview of the main unit	4
3	Get started	6
	Connect power	6
	Turn on	6
4	Play	7
	Play audio from iPod/ iPhone/ iPad	7
	Play through an audio cable	8
	Other features	9
	Update the firmware	10
5	Product information	11
	Specifications	11
6	Troubleshooting	12

1 Important

Safety

- Read these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other devices (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the device.
- Only use attachments/accessories specified by the manufacturer.
- Unplug the device during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the device has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the device, the device has been exposed to rain or moisture, does not operate normally, or has been dropped.
- The device shall not be exposed to dripping or splashing.
- Do not place any sources of danger on the device (e.g. liquid filled objects, lighted candles).
- Where the plug of the Direct Plug-in Adapter is used as the disconnect device, the disconnect device shall remain readily operable.

1 v

Warning

- · Never remove the casing of this apparatus.
- · Never lubricate any part of this apparatus.
- Never place this apparatus on other electrical equipment.
- Keep this apparatus away from direct sunlight, naked flames or heat.
- Make sure that you always have easy access to the power cord, plug, or adaptor to disconnect the apparatus from the power.

Notice

Any changes or modifications made to this device that are not expressly approved by Gibson Innovations may void the user's authority to operate the equipment.



This product complies with the radio interference requirements of the European Community.

Disposal of your old product

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

Never dispose of your product with other household waste. Please inform yourself about the local rules on the separate collection of electrical and electronic products and batteries. The correct disposal of these products helps prevent potentially negative consequences on the environment and human health.

Please visit www.recycle.philips.com for additional information on a recycling center in your area.

Environmental information

All unnecessary packaging has been omitted. We have tried to make the packaging easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet.)

Your system consists of materials which can be recycled and reused if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.



The making of unauthorized copies of copyprotected material, including computer programs, files, broadcasts and sound recordings, may be an infringement of copyrights and constitute a criminal offence. This equipment should not be used for such purposes.



"Made for iPod," "Made for iPhone," and "Made for iPad" mean that an electronic accessory has been designed to connect specifically to iPod, iPhone, or iPad, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, iPhone, or iPad may affect wireless performance.

iPod and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries. iPad is a trademark of Apple Inc.

Class II equipment symbol:



CLASS II apparatus with double insulation, and no protective earth provided.



Note

 The type plate is located on the bottom of the apparatus.

2 Your Docking Speaker

Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/support.

Introduction

With DS1600, you can:


- enjoy audio from your iPod/iPhone/iPad;
- · enjoy audio from an external audio device;
- charge any generation of iPod/iPhone/iPad and external audio devices.


What's in the box

Check and identify the contents of your package:

- Main unit
- 1 x AC adaptor
- Short user manual
- Safety and notice

Overview of the main unit





- 1 30-pin connector
- 2 Lightning connector
- (3) TIME/DATE
 - Display time and date.
 - Set time and date format.
 - · Set time manually.
- (4) AUDIO IN
 - Audio input connector for connecting an external audio device.
- (5) POWER OUT
 - USB socket for charging your mobile phone.
- 6 DC IN
 - AC power connector for the supplied AC power adapter.
- 7 Bottom light

- 8 Display panel
- 9 +/-
 - Adjust volume.
- 10 Toggle switch for lightning/30-pin control
- 11 **
 - Adjust brightness of display and bottom light.

3 Get started

Always follow the instructions in this chapter in sequence.

Connect power




Caution

- Risk of product damage! Make sure that the power supply voltage corresponds to the voltage printed on the back of the unit.
- Risk of electric shock! When you unplug the AC adapter, always pull the plug from the socket. Never pull the cord.

Connect the AC power adapter to:

- the power socket at the back of the docking speaker.
- the wall power outlet.



Turn on

In standby mode, the docking speaker turns on automatically when it detects an audio signal from docked iPod/ iPhone/ iPad.

Switch to standby mode

DS1600 switches to standby mode in the following situations:

- In dock mode: no audio signal from the docked iPod/iPhone/iPad over 15 minutes.
- In AUDIO IN mode: no audio signal detected over 15 minutes.

4 Play

Play audio from iPod/ iPhone/ iPad

You can enjoy audio from iPod/ iPhone/ iPad by connecting **DS1600**.

Compatible iPod/ iPhone/ iPad

The docking system supports the following iPod/ iPhone/ iPad models.

- iPod/ iPhone/ iPad models with a lightning connector;
 - iPod nano 7th generation
 - · iPod touch 5th generation
 - iPhone 6 Plus
 - iPhone 6
 - iPhone 5s
 - iPhone 5c
 - iPhone 5
 - iPad mini 3
 - iPad mini with Retina display
 - iPad mini
 - iPad Air 2
 - iPad Air
 - iPad (4th generation)
- iPod/ iPhone/ iPad models with a 30-pin connector:
 - iPod classic
 - iPod touch (2nd, 3rd, 4th generation)
 - · iPod with video
 - iPod nano (1st, 2nd, 3rd, 4th, 5th, and 6th generation)
 - iPod with color display
 - · iPod mini
 - iPhone 4s
 - iPhone 4
 - iPhone 3GS
 - iPhone 3G
 - iPad (3rd generation)
 - iPad 2
 - iPad

Switch the dock

Switch the dock between the lightning connector and 30-pin connector for different generation of Apple device.

- 1 Slide the $\rightarrow \triangle$ switch to the right.
 - → The dock swivels and the alternate connector is accessible.
- 2 Select your desired connector and press down until a click sound.
 - The → **a** switch slides to the left.



Load the iPod/ iPhone/ iPad

1 Connect your iPod/ iPhone/ iPad to the dock connector:




When using DS1600 for the first time, a required software application automatically pops up.



- 3 Tap [Yes] (yes) to accept the installation request.
- 4 Follow the on-screen instructions to complete the installation.
 - → DS1600 synchronizes time and date from the docked iPod/iPhone/iPad.

Remove the iPod/ iPhone/ iPad To remove the iPod/ iPhone/ iPad

 Pull your iPod/ iPhone/ iPad out of the dock.





Tip

- When placing or removing the iPod/ iPhone/ iPad, hold the iPod/ iPhone/ iPad at the same angle as that of the connector of DS1600.
- Before disconnecting the iPod/ iPhone/ iPad, pause the audio play.

Listen to the iPod/ iPhone/ iPad



Note

- Make sure that the iPod/ iPhone/ iPad is loaded correctly.
- Start music play in your iPod/ iPhone/ iPad.
 → You can hear music from DS1600.


Charge the iPod/ iPhone/ iPad

When the docking speaker is connected to power, the docked iPod/ iPhone/ iPad charges automatically.

Play through an audio cable


Through an MP3 link cable, you can also play on DS1600 from an external audio device, such as an MP3 player.

- 1 Use an MP3 link cable to connect **DS1600** with an external audio device
- 2 On **DS1600**, do the following:
 - Make sure that you have paused the music on your iPod/ iPhone/ iPad docked on DS1600.
- 3 On the external audio device, start music play and change the volume.



Charge your mobile phone

Charge your mobile phone through the USB socket in **DS1600** with a USB cable (not supplied).



Other features

Set time and date

A: If an iPod/iPhone/iPad is docked, the speaker synchronizes time and date with the iPod/ iPhone/iPad automatically. In this case, you can set time and date format.



To set time format:

1 In standby mode, press TIME/DATE to display time.

- Press and hold TIME/DATE for 2 seconds to select 12 or 24 hour format.
- 3 Press TIME/DATE to confirm.

To set date format:


- 1 In standby mode, press TIME/DATE to display date.
- Press and hold TIME/DATE for 2 seconds to select [MONTH--DAY] or [DAY--MONTH] display mode.
- 3 Press TIME/DATE to confirm.

B: If no iPod/iPhone/iPad is docked, you can set time manually.

- 1 In standby mode, press TIME/DATE to display [--:--].
- Press and hold TIME/DATE for 2 seconds to activate time setting.
 - → The hour digits blink.
- 3 Press +/- repeatedly to set the hour.
- 4 Press TIME/DATE to confirm.
 - → The minute digits blink.
- **5** Repeat steps 3 and 4 to set the minute.


Adjust volume

During play, press +/- repeatedly to increase or decrease the volume.



Adjust brightness

- Press * repeatedly to select different levels of display light.
- Press and hold * to turn on or off the bottom light.



Update the firmware

With the ClockStudioapp on your iPod/ iPhone/ iPad, you can update the firmware of DS1600.

- 1 Make sure that your iPod/ iPhone/ iPad is connected to the Internet.
- Mount the iPod/ iPhone/ iPad onto the lightning dock of **DS1600**.
 - → ClockStudio starts to search for available firmware update.
 - → When the firmware update is available, a message is displayed.



3 Follow onscreen instructions to complete firmware updating.



 During the firmware updating, keep the iPod/ iPhone/ iPad powered on and docked on DS1600.

5 Product information



Note

Product information is subject to change without prior notice.

iPod/iPhone	DC 5 V == ≤ 2100 mA
Charging	
Dimensions:	225 × 149 × 96 mm
Main Unit (W x	
$H \times D$)	
Weight: Main	0.83 kg
Unit	

Specifications

Amplifier

Rated Output Power	2×2.5 W RMS
Signal to Noise Ratio	> 55 dBA
MP3 Link Input	650mV RMS

Amplifier

Speaker Impedance	4 ohm
Speaker Driver	1.5"

General information

General information			
AC/DC switching adapter	Model: AS250-050-AE400 Input: 100-240 V~, 50/60 Hz, 1.2 A;		
адарто.	Output: 5 V === 4 A;		
	or,		
	Model: MSP-C4000IC5.0 -24M-DF		
	Input: 100-240 V~, 50/60		
	Hz, 0.6 A;		
	Output: $5 V == 4 A$;		
Operation	< 23 W		
Power			
Consumption			
Standby Power	< 1 W		
Consumption			
USB Charging	DC 5 V == ≤ 1000 mA		

6 Troubleshooting



Warning

· Never remove the casing of this product.

To keep the warranty valid, never try to repair the product yourself.

If you encounter problems when using this device, check the following points before requesting service. If the problem remains unsolved, go to the Web page (www.philips.com/support). When you contact the Consumer Care, make sure that the product is nearby and the model number and serial number are available.

No power

- Make sure that the AC power plug of the unit is connected properly.
- Make sure that there is power at the AC outlet.

No sound or poor sound

- Adjust the volume of your docking speaker.
- Adjust the volume of your iPod/iPhone or external audio device.

No response from the unit

Disconnect and reconnect the AC power plug.



2015 Gibson Innovations Limited. All rights reserved.

This product has been manufactured by, and is sold under the responsibility of Gibson Innovations Ltd., and Gibson Innovations Ltd. is the warrantor in relation to this product. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license from Koninklijke Philips N.V.