

Philips  
DVD player



DVP4050



## Fits anywhere, goes everywhere

Be in total empowerment to enjoy sharp, crystal-clear picture and sound quality movies and music wherever and whenever you desire. It's your home entertainment - at your control.

### Great audio and video performance

- Progressive Scan component video for optimized image quality
- High quality outputs for analog and digital audio
- Smart Sound optimizes audio settings

### Play it all

- Movies: DVD, DVD+R/RW, DVD-R/RW, (S)VCD
- Music: CD, MP3-CD, CD-R/RW & Windows Media™ Audio
- Photos: Picture CD (JPEG)

### Fits everywhere, goes anywhere

- Compact design
- Quick and easy set-up for no-fuss installation

# PHILIPS

# Specifications

## Picture/Display

- Aspect ratio: 4:3, 16:9
- D/A converter: 12 bit, 108 MHz
- Picture enhancement: Progressive scan, Video upsampling, 3/2 - 2/2 motion pull down

## Sound

- D/A converter: 24 bit, 192 kHz
- Frequency response: 30-20000 Hz
- Signal to noise ratio: 90
- Distortion and Noise (1kHz): 65 dB
- Crosstalk (1kHz): 70 dB
- Dynamic Range (1kHz): 80 dB
- Sound System: Dolby Digital

## Video Playback

- Playback Media: CD-R/CD-RW, CD, DVD, DVD-R/-RW, DVD+R/+RW, Video CD/SVCD
- Compression formats: MPEG1, MPEG2
- Video disc playback system: NTSC, PAL

## Audio Playback

- Playback Media: CD, MP3-CD, MP3-DVD, WMA-CD, CD-R/RW
- Compression format: MP3, WMA, PCM, Dolby Digital
- MP3 bit rates: 32 - 256 kbps

## Still Picture Playback

- Playback Media: DVD-R/-RW, DVD+R/+RW, CD-

- R/RW, Picture CD, Kodak Picture CD
- Picture Compression Format: JPEG
- Picture Enhancement: Rotate, Zoom, Slideshow, Flip photos

## Connectivity

- Rear Connections: Analog audio Left/Right out, Composite video (CVBS) output, Digital coaxial out, ComponentVideo out Progressive

## Convenience

- Child Protection: Child Lock, Parental Control
- On-Screen Display languages: English, Spanish, Brazilian Portuguese

## Power

- Power supply: 110-240V, 50/60 Hz
- Power consumption: < 10 W
- Standby power consumption: < 0.8 W

## Accessories

- Included accessories: 2 x AAA Batteries, Audio/Video cable, Quick start guide, Remote Control, World Wide Warranty leaflet, User Manual, Power cord, VDE to 2-pin Flat Adaptor

## Dimensions

- Set dimensions (W x H x D): 226 x 48 x 209 mm

# Highlights

## Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

## Smart Sound

Smart Sound provides the optimal sound settings for ultra bass, bass, treble and balance so that you can get the best entertainment experience.

## Multi-format Movies

Multi-format playability allows you to play most disc formats for maximum disc compatibility and viewing pleasure.

## Music: Windows Media™ Audio

Multi-format playability allows you to play most disc formats for maximum disc compatibility and listening pleasure.

## Picture CD (JPEG)

Multi-format playability allows you to view images in the comfort of your living room and play most disc formats for maximum disc compatibility and viewing pleasure.



Issue date 2014-02-06

Version: 4.0.9

12 NC: 8622 810 13156  
EAN: 87 10895 93968 3

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Avoid extensive use of the set in a volume higher than 85 decibel  
because this may damage your hearing.