

Philips docking speaker with Bluetooth®

for iPod/iPhone
Battery/AC powered



**DS7530** 

# Designed to go places

with this docking speaker

Compact and ultra portable, this DS7530/12 speaker is no lightweight when it comes to performance. Designed to travel it delivers sound from your iPod/iPhone that is surprisingly powerful and ensures convenience with wireless streaming.

## Sound that blows you away

- wOOx technology for rich yet precise bass without distortion
- DBB to preserve low tones for deep bass at any volume level
- Shielding technology to block mobile phone interference
- 10W RMS total output power

## Made to go places

• Elegant, slim and compact design to fit into any briefcase

## Truly portable and versatile

- Battery or AC power option for music enjoyment anywhere
- · Wireless music streaming via Bluetooth
- Dock any iPod/iPhone, even in its case
- AUX-in for easy connection to almost any electronic device
- Free DockStudio app for internet radio & other cool feature



## **Specifications**

#### iPod compatibility

 Compatible with: iPod, iPod classic, iPod mini, iPod nano 1st Generation, iPod nano 2nd Generation, iPod nano 3rd Generation, iPod nano 4th Generation, iPod nano 5th Generation, iPod nano 6th generation, iPod touch, iPod touch 2nd Generation, iPod touch 2nd Gen 8/16/32GB, iPod 5th Generation, iPod with color display

#### iPhone compatibility

 Compatible with: iPhone, iPhone 3G, iPhone 3GS, iPhone 4, iPhone 4S

### iPod/iPhone App

- App name: DockStudio, Free download from App store
- Compatibility: iPod Touch, iPhone, iPad iOS 4.3 or later
- 7000+ Internet radio stations
- · 5-day weather forecast
- Playback: album/track navigation, playback controls
- Sound settings: 5 band equalizer, DBB, DSC-Flat,Pop,Rock,Jazz,Classic
- · Clock: analog display, digital display
- · Alarm: multiple alarms, sleep timer

#### **Connectivity**

- · Bluetooth profiles: A2DP
- · Bluetooth range: line of sight, 10M or 30FT
- Bluetooth version: 2.1

#### Sound

- Output power (RMS): 10W
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo
- Volume Control: Volume Control up/down

#### Loudspeakers

· Neodynium magnet system

#### **Power**

- Power supply: 100-240VAC, 50/60Hz, Battery
- Battery type: AA size (LR6)
- Number of batteries: 4
- · Operating time on battery: 10 hr

#### **Dimensions**

- Product dimensions (WxDxH): 311 x 38 x 111 mm
- Packaging dimensions (WxDxH): 431 x 76 x 163 mm
- Product weight: 0.28 kg
- Weight incl. Packaging: 1.08 kg







## Highlights

## wOOx technology



wOOx technology is a revolutionary loudspeaker concept that allows you to hear and feel profoundly deep bass that is richer than any other audio system. Special speaker drivers work in harmony with the wOOx bass radiator, and precise tuning between the main driver and the tweeter ensures smooth transitions from low-mid to high frequencies. Dual suspension and a totally symmetrical sandwich construction deliver low and precise base without noticeable distortion. wOOx produces exceptionally deep and dynamic bass by using the speaker box full volume to truly magnify the impact of the music.

### **Dynamic Bass Boost (DBB)**



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottomend bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Issue date 2014-03-03

Version: 2.0.9

© 2014 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 92611 EAN: 87 12581 65244 9

www.philips.com